


ACTUATORS

Go with the Flow



AUDI			BUICK (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
A4, A4 ALLROAD, A4 QUATTRO			LUCERNE (Cont'd)		
01-97	1.8L 4Cyl L (1781) Adjuster Motor - Air Inlet Recirculating - (Blower Housing)	MT18534	08-06	3.8L 6Cyl V (231), Left A.T.C. - Mode Door	MT18598
	1.8L 4Cyl L (1781) Adjuster Motor - Defroster	MT18533		3.8L 6Cyl V (231), Left A.T.C. - Temperature Blend Air Door	MT18599
	2.8L 6Cyl V (2771) Adjuster Motor - Air Inlet Recirculating - (Blower Housing)	MT18534		3.8L 6Cyl V (231), Left Manual A.C. - Mode Door	MT18598
	2.8L 6Cyl V (2771) Adjuster Motor - Defroster	MT18533		3.8L 6Cyl V (231), Left Manual A.C. - Temperature Blend Air Door	MT18599
96	2.8L 6Cyl V (2771) Adjuster Motor - Defroster Flap	MT18533		3.8L 6Cyl V (231), Right A.T.C. - Mode Door	MT18605
S4				3.8L 6Cyl V (231), Right A.T.C. - Temperature Blend Air Door	MT18597
02-00	2.7L 6Cyl V (2671) Adjuster Motor - Air Inlet Recirculating - (Blower Housing)	MT18534		3.8L 6Cyl V (231), Right Manual A.C. - Mode Door	MT18596
	2.7L 6Cyl V (2671) Adjuster Motor - Defroster	MT18533		3.8L 6Cyl V (231), Right Manual A.C. - Temperature Blend Air Door	MT18597
TT, TT QUATTRO			PARK AVENUE		
08	3.2L 6Cyl V (195) Adjuster Motor - Air Inlet Recirculating - (Blower Housing)	MT18532	05-97	3.8L 6Cyl V (231), Left Temperature Blend Air Door	MT1809
	3.2L 6Cyl V (195) Adjuster Motor - Central Flap	MT18540		3.8L 6Cyl V (231), Right Temperature Blend Air Door	MT1800
	3.2L 6Cyl V (195) Adjuster Motor - Defroster	MT18539	RAINIER		
	3.2L 6Cyl V (195) Adjuster Motor - Temperature Blend Door	MT18538	07-04	4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1809
06-03	1.8L 4Cyl L (1781) Adjuster Motor - Air Inlet Recirculating - (Blower Housing)	MT18532		4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521
06-01	1.8L 4Cyl L (1781) Adjuster Motor - Central Flap	MT18540		4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612
	1.8L 4Cyl L (1781) Adjuster Motor - Defroster	MT18539		4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1800
	1.8L 4Cyl L (1781) Adjuster Motor - Temperature Blend Door	MT18538		4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521
06-04	3.2L 6Cyl V (195) Adjuster Motor - Air Inlet Recirculating - (Blower Housing)	MT18532		4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - with Rear A.C.	MT18527
	3.2L 6Cyl V (195) Adjuster Motor - Central Flap	MT18540		5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1809
	3.2L 6Cyl V (195) Adjuster Motor - Defroster	MT18539		5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521
	3.2L 6Cyl V (195) Adjuster Motor - Temperature Blend Door	MT18538		5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612
BUICK				5.3L 8Cyl V (325), Right Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1800
SWITCH HEATER BLEND DOOR ACTUATOR				5.3L 8Cyl V (325), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521
Year	Application	Part No.		5.3L 8Cyl V (325), Right Main Temperature Blend Air Door - with Rear A.C.	MT18527
CENTURY			REGAL		
05-97	3.1L 6Cyl V (189) Mode Door	MT1800	04-97	3.8L 6Cyl V (231) Temperature Blend Air Door - Electric Actuator	MT1800
	3.1L 6Cyl V (189) Temperature Blend Air Door	MT1800	96-94	3.1L 6Cyl V (189) Temperature Blend Air Door - Electric Actuator	MT18512
ENCLAVE				3.8L 6Cyl V (231) Temperature Blend Air Door - Electric Actuator	MT18512
12-08	3.6L 6Cyl V (217), Main Air Inlet Recirculating - (Blower Housing)	MT18531	RENDEZVOUS		
	3.6L 6Cyl V (217), Main Mode Door	MT18522	07-06	3.5L 6Cyl V (213), Left Mode Door	MT18529
	3.6L 6Cyl V (217), Main Temperature Blend Air Door	MT18522		3.5L 6Cyl V (213), Left Temperature Blend Air Door	MT18524
LESABRE			06-04	3.6L 6Cyl V (217), Left Mode Door	MT18529
05-00	3.8L 6Cyl V (231) A.T.C. - Mode Door	MT18614		3.6L 6Cyl V (217), Left Temperature Blend Air Door	MT18524
	3.8L 6Cyl V (231) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18530	05-02	3.4L 6Cyl V (207), Left Mode Door	MT18529
	3.8L 6Cyl V (231) Manual A.C. - Mode Door	MT18530		3.4L 6Cyl V (207), Left Temperature Blend Air Door	MT18524
	3.8L 6Cyl V (231) Manual A.C. - Temperature Blend Air Door	MT18530	RIVIERA		
	3.8L 6Cyl V (231), Left A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800	99-95	3.8L 6Cyl V (231), Left Temperature Blend Air Door - (3 Required)	MT1809
	3.8L 6Cyl V (231), Left A.T.C. - Temperature Blend Air Door	MT1809		3.8L 6Cyl V (231), Right Temperature Blend Air Door - (2 Required)	MT1800
	3.8L 6Cyl V (231), Right A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800	ROADMASTER		
	3.8L 6Cyl V (231), Right A.T.C. - Temperature Blend Air Door	MT1800	96-94	5.7L 8Cyl V (350) A.T.C. - Temperature Blend Air Door	MT1800
99-94	3.8L 6Cyl V (231) Temperature Blend Air Door - Electric Actuator - (with Lever)	MT18514		5.7L 8Cyl V (350) Manual A.C. - Temperature Blend Air Door	MT18512
LUCERNE			TERRAZA		
11-09	3.9L 6Cyl V (237), Left A.T.C. - Mode Door	MT18598	07-06	3.9L 6Cyl V (237), Main Air Inlet Recirculating - (Blower Housing)	MT18595
	3.9L 6Cyl V (237), Left A.T.C. - Temperature Blend Air Door	MT18599		3.9L 6Cyl V (237), Main Defroster Door	MT18595
	3.9L 6Cyl V (237), Left Manual A.C. - Mode Door	MT18598		3.9L 6Cyl V (237), Main Mode Door	MT18595
	3.9L 6Cyl V (237), Left Manual A.C. - Temperature Blend Air Door	MT18599		3.9L 6Cyl V (237), Main Temperature Blend Air Door	MT18595
	3.9L 6Cyl V (237), Right A.T.C. - Mode Door	MT18605		3.9L 6Cyl V (237), Main Temperature Blend Air Door	MT18595
	3.9L 6Cyl V (237), Right A.T.C. - Temperature Blend Air Door	MT18597		3.5L 6Cyl V (213), Main Air Inlet Recirculating - (Blower Housing)	MT18595
	3.9L 6Cyl V (237), Right Manual A.C. - Mode Door	MT18596	06-05	3.5L 6Cyl V (213), Main Defroster Door	MT18595
	3.9L 6Cyl V (237), Right Manual A.C. - Temperature Blend Air Door	MT18597		3.5L 6Cyl V (213), Main Mode Door	MT18595
	4.6L 8Cyl V (281), Left A.T.C. - Mode Door	MT18598		3.5L 6Cyl V (213), Main Temperature Blend Air Door	MT18595
11-06	4.6L 8Cyl V (281), Left A.T.C. - Temperature Blend Air Door	MT18599			
	4.6L 8Cyl V (281), Left Manual A.C. - Mode Door	MT18598			
	4.6L 8Cyl V (281), Left Manual A.C. - Temperature Blend Air Door	MT18599			
	4.6L 8Cyl V (281), Right A.T.C. - Mode Door	MT18605			
	4.6L 8Cyl V (281), Right A.T.C. - Temperature Blend Air Door	MT18597			
	4.6L 8Cyl V (281), Right Manual A.C. - Mode Door	MT18596			
	4.6L 8Cyl V (281), Right Manual A.C. - Temperature Blend Air Door	MT18597			
(Cont'd)					

CADILLAC			CADILLAC (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR			SWITCH HEATER BLEND DOOR ACTUATOR		
Year	Application	Part No.	Year	Application	Part No.
COMMERCIAL CHASSIS			(Cont'd)		
96-94	5.7L 8Cyl V (350) Heater Temperature Valve Control	MT1800	DTS		
CTS			11-06	4.6L 8Cyl V (281), Left Mode Door - Panel	MT18605
14	2.0L 4Cyl L (122) Air Inlet Recirculating - (Blower Housing)	MT18605		4.6L 8Cyl V (281), Left Temperature Blend Air Door	MT18597
	2.0L 4Cyl L (122) Heater Cam Kit	MT18603		4.6L 8Cyl V (281), Left Temperature Heater Blend Door	MT18599
14-10	3.0L 6Cyl V (182) Air Inlet Recirculating - (Blower Housing)	MT18605		4.6L 8Cyl V (281), Main Mode Door - Panel	MT18598
	3.0L 6Cyl V (182) Heater Cam Kit	MT18603		4.6L 8Cyl V (281), Right Mode Door - Panel	MT18598
14-08	3.6L 6Cyl V (217) Air Inlet Recirculating - (Blower Housing)	MT18605		4.6L 8Cyl V (281), Right Temperature Heater Blend Door	MT18607
	3.6L 6Cyl V (217) Heater Cam Kit	MT18603	ELDORADO		
14-10	6.2L 8Cyl V (376) Air Inlet Recirculating - (Blower Housing)	MT18605	02-96	4.6L 8Cyl V (281) Temperature Blend Air Door	MT18513
14-09	6.2L 8Cyl V (376) Heater Cam Kit	MT18603	ESCALADE, ESCALADE ESV, ESCALADE EXT		
14-12	6.2L 8Cyl V (378) Air Inlet Recirculating - (Blower Housing)	MT18605	13-09	6.0L 8Cyl V (364), Left Air Inlet Recirculating - (Blower Housing)	MT1800
	6.2L 8Cyl V (378) Heater Cam Kit	MT18603		6.0L 8Cyl V (364), Lower Temperature Blend Air Door	MT1800
13-11	3.0L 6Cyl V (183) Air Inlet Recirculating - (Blower Housing)	MT18605		6.0L 8Cyl V (364), Right Mode Door	MT18614
	3.0L 6Cyl V (183) Heater Cam Kit	MT18603		6.0L 8Cyl V (364), Upper Temperature Blend Air Door	MT1800
11-10	3.0L 6Cyl V (182), Right Temperature Blend Air Door	MT18604	13-07	6.2L 8Cyl V (376), Left Air Inlet Recirculating - (Blower Housing)	MT1800
11	3.0L 6Cyl V (183), Right Temperature Blend Air Door	MT18604		6.2L 8Cyl V (376), Lower Temperature Blend Air Door	MT1800
11-08	3.6L 6Cyl V (217), Right Temperature Blend Air Door	MT18604		6.2L 8Cyl V (376), Right Mode Door	MT18614
11-09	6.2L 8Cyl V (376), Right Temperature Blend Air Door	MT18604		6.2L 8Cyl V (376), Upper Temperature Blend Air Door	MT1800
09-08	3.6L 6Cyl V (217) Air Inlet Recirculating - (Blower Housing)	MT18602	10-07	6.2L 8Cyl V (378), Left Air Inlet Recirculating - (Blower Housing)	MT1800
09	6.2L 8Cyl V (376) Air Inlet Recirculating - (Blower Housing)	MT18602		6.2L 8Cyl V (378), Lower Temperature Blend Air Door	MT1800
07-05	2.8L 6Cyl V (170) Air Inlet Recirculating - (Blower Housing) - 1st Design	MT18600		6.2L 8Cyl V (378), Right Mode Door	MT18614
	2.8L 6Cyl V (170) Air Inlet Recirculating - (Blower Housing) - 2nd Design	MT18601		6.2L 8Cyl V (378), Upper Temperature Blend Air Door	MT1800
07-06	2.8L 6Cyl V (170) Mode Door	MT18598	06-02	6.0L 8Cyl V (364), Left Air Inlet Recirculating - (Blower Housing)	MT18527
	2.8L 6Cyl V (170) Temperature Blend Air Door	MT18606		6.0L 8Cyl V (364), Lower Temperature Blend Air Door	MT18517
07-04	3.6L 6Cyl V (217) Air Inlet Recirculating - (Blower Housing) - 1st Design	MT18600	06-03	6.0L 8Cyl V (364), Right Mode Door	MT18614
	3.6L 6Cyl V (217) Air Inlet Recirculating - (Blower Housing) - 2nd Design	MT18601	06-02	6.0L 8Cyl V (364), Upper Temperature Blend Air Door	MT1800
07-06	3.6L 6Cyl V (217) Mode Door	MT18598	05-02	5.3L 8Cyl V (325), Left Air Inlet Recirculating - (Blower Housing)	MT18527
	3.6L 6Cyl V (217) Temperature Blend Air Door	MT18606		5.3L 8Cyl V (325), Lower Temperature Blend Air Door	MT18517
	6.0L 8Cyl V (364) Air Inlet Recirculating - (Blower Housing) - 1st Design	MT18600	05-03	5.3L 8Cyl V (325), Right Mode Door	MT18614
	6.0L 8Cyl V (364) Air Inlet Recirculating - (Blower Housing) - 2nd Design	MT18601	05-02	5.3L 8Cyl V (325), Upper Temperature Blend Air Door	MT1800
	6.0L 8Cyl V (364) Mode Door	MT18598	02	5.3L 8Cyl V (325), Right Mode Door	MT18516
	6.0L 8Cyl V (364) Temperature Blend Air Door	MT18606		6.0L 8Cyl V (364), Right Mode Door	MT18516
05	2.8L 6Cyl V (170) Mode Door - 1st Design	MT18572	FLEETWOOD		
	2.8L 6Cyl V (170) Mode Door - 2nd Design	MT18598	96-94	5.7L 8Cyl V (350) Heater Temperature Valve Control	MT1800
	2.8L 6Cyl V (170) Temperature Blend Air Door - 1st Design	MT18600	SEVILLE		
	2.8L 6Cyl V (170) Temperature Blend Air Door - 2nd Design	MT18606	04-98	4.6L 8Cyl V (281) Air Inlet Recirculating - (Blower Housing)	MT1800
	3.6L 6Cyl V (217) Mode Door - 1st Design	MT18572		4.6L 8Cyl V (281), Left Temperature Blend Air Door	MT1809
	3.6L 6Cyl V (217) Mode Door - 2nd Design	MT18598		4.6L 8Cyl V (281), Right Temperature Blend Air Door - Electric Actuator - (Code 3982)	MT1800
05-04	3.6L 6Cyl V (217) Temperature Blend Air Door - 1st Design	MT18600	97-96	4.6L 8Cyl V (281) Temperature Blend Air Door	MT18513
05	3.6L 6Cyl V (217) Temperature Blend Air Door - 2nd Design	MT18606	SRX		
05-04	5.7L 8Cyl V (346) Air Inlet Recirculating - (Blower Housing) - 1st Design	MT18600	09-04	3.6L 6Cyl V (217) Air Inlet Recirculating - (Blower Housing)	MT18601
	5.7L 8Cyl V (346) Air Inlet Recirculating - (Blower Housing) - 2nd Design	MT18601	09-06	3.6L 6Cyl V (217) Mode Door	MT18598
05	5.7L 8Cyl V (346) Mode Door - 1st Design	MT18572		3.6L 6Cyl V (217) Temperature Blend Air Door	MT18606
	5.7L 8Cyl V (346) Mode Door - 2nd Design	MT18598	09-04	4.6L 8Cyl V (281) Air Inlet Recirculating - (Blower Housing)	MT18601
05-04	5.7L 8Cyl V (346) Temperature Blend Air Door - 1st Design	MT18600	09-06	4.6L 8Cyl V (281) Mode Door	MT18598
05	5.7L 8Cyl V (346) Temperature Blend Air Door - 2nd Design	MT18606		4.6L 8Cyl V (281) Temperature Blend Air Door	MT18606
04-03	3.2L 6Cyl V (197) Air Inlet Recirculating - (Blower Housing) - 1st Design	MT18600	05	3.6L 6Cyl V (217) Mode Door - 1st Design	MT18572
	3.2L 6Cyl V (197) Air Inlet Recirculating - (Blower Housing) - 2nd Design	MT18601		3.6L 6Cyl V (217) Mode Door - 2nd Design	MT18598
	3.2L 6Cyl V (197) Mode Door	MT18572		3.6L 6Cyl V (217) Temperature Blend Air Door - 1st Design	MT18600
04	3.2L 6Cyl V (197) Temperature Blend Air Door - 1st Design	MT18600		3.6L 6Cyl V (217) Temperature Blend Air Door - 2nd Design	MT18606
	3.6L 6Cyl V (217) Mode Door	MT18572		4.6L 8Cyl V (281) Mode Door - 1st Design	MT18572
03	5.7L 8Cyl V (346) Mode Door	MT18572		4.6L 8Cyl V (281) Mode Door - 2nd Design	MT18598
	3.2L 6Cyl V (194) Air Inlet Recirculating - (Blower Housing) - 1st Design	MT18600		4.6L 8Cyl V (281) Temperature Blend Air Door - 1st Design	MT18600
	3.2L 6Cyl V (194) Air Inlet Recirculating - (Blower Housing) - 2nd Design	MT18601		4.6L 8Cyl V (281) Temperature Blend Air Door - 2nd Design	MT18606
	3.2L 6Cyl V (194) Mode Door	MT18572	04	3.6L 6Cyl V (217) Mode Door	MT18572
	3.2L 6Cyl V (194) Temperature Blend Air Door - 1st Design	MT18600		3.6L 6Cyl V (217) Temperature Blend Air Door	MT18600
DEVILLE				4.6L 8Cyl V (281) Mode Door	MT18572
05-00	4.6L 8Cyl V (281) Air Inlet Recirculating - (Blower Housing)	MT18526	STS		
	4.6L 8Cyl V (281) Temperature Blend Air Door	MT18526	11-05	3.6L 6Cyl V (217), Auxiliary Temperature Blend Air Door	MT18607
99-96	4.6L 8Cyl V (281) Temperature Blend Air Door	MT18513		3.6L 6Cyl V (217), Main Air Inlet Recirculating - (Blower Housing)	MT18605
96	4.6L 8Cyl V (279) Temperature Blend Air Door	MT18513		3.6L 6Cyl V (217), Main Mode Door	MT18598
			11-10	3.6L 6Cyl V (217), Right Main Temperature Blend Air Door	MT18604
			10-07	4.6L 8Cyl V (279), Auxiliary Temperature Blend Air Door	MT18607
				4.6L 8Cyl V (279), Main Air Inlet Recirculating - (Blower Housing)	MT18605
				4.6L 8Cyl V (279), Main Mode Door	MT18598
			10	4.6L 8Cyl V (279), Right Main Temperature Blend Air Door	MT18604
			10-05	4.6L 8Cyl V (281), Auxiliary Temperature Blend Air Door	MT18607
			(Cont'd)		

CADILLAC (Con't)			CHEVROLET (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
STS (Cont'd)			C/K1500, 2500 (Cont'd)		
10-05	4.6L 8Cyl V (281), Main Air Inlet Recirculating - (Blower Housing)	MT18605	90-88	4.3L 6Cyl V (262), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
	4.6L 8Cyl V (281), Main Mode Door	MT18598		5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
10	4.6L 8Cyl V (281), Right Main Temperature Blend Air Door	MT18604		5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
09-06	4.4L 8Cyl V (267), Auxiliary Temperature Blend Air Door	MT18607		6.2L 8Cyl V (379), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
	4.4L 8Cyl V (267), Main Air Inlet Recirculating - (Blower Housing)	MT18605	C/K1500, C/K2500		
	4.4L 8Cyl V (267), Main Mode Door	MT18598	99	5.0L 8Cyl V (305), Lower Temperature Blend Air Door	MT1800
	4.4L 8Cyl V (267), Right Main Temperature Blend Air Door	MT18604		5.0L 8Cyl V (305), Right Mode Door	MT18516
08-05	3.6L 6Cyl V (217), Right Main Temperature Blend Air Door	MT18604		5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18527
08-07	4.6L 8Cyl V (279), Right Main Temperature Blend Air Door	MT18604		5.7L 8Cyl V (350), Lower Temperature Blend Air Door	MT1800
08-05	4.6L 8Cyl V (281), Right Main Temperature Blend Air Door	MT18604		5.7L 8Cyl V (350), Right Mode Door	MT18516
CHEVROLET				5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18527
SWITCH HEATER BLEND DOOR ACTUATOR				6.5L 8Cyl V (395), Lower Temperature Blend Air Door	MT1800
Year	Application	Part No.		6.5L 8Cyl V (395), Right Mode Door	MT18516
AVANCE, 1500, 2500				6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18527
13-07	5.3L 8Cyl V (325), Lower Temperature Blend Air Door	MT1800		7.4L 8Cyl V (454), Lower Temperature Blend Air Door	MT1800
	5.3L 8Cyl V (325), Right Mode Door	MT18614		7.4L 8Cyl V (454), Right Mode Door	MT18516
	5.3L 8Cyl V (325), Upper Air Inlet Recirculating - (Blower Housing)	MT1800	97-95	7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18527
	5.3L 8Cyl V (325), Upper Temperature Blend Air Door	MT1800		5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
09-07	6.0L 8Cyl V (364), Lower Temperature Blend Air Door	MT1800		5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
	6.0L 8Cyl V (364), Right Mode Door	MT18614		6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
	6.0L 8Cyl V (364), Upper Air Inlet Recirculating - (Blower Housing)	MT1800		7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
	6.0L 8Cyl V (364), Upper Temperature Blend Air Door	MT1800	95	4.3L 6Cyl V (262), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
06-02	5.3L 8Cyl V (325), Lower Temperature Blend Air Door	MT18517	94-91	4.3L 6Cyl V (262), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
	5.3L 8Cyl V (325), Right Mode Door	MT18516		5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
	5.3L 8Cyl V (325), Upper Air Inlet Recirculating - (Blower Housing)	MT18527	94-92	6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
	8.1L 8Cyl V (496), Lower Temperature Blend Air Door	MT18517	94-91	7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
	8.1L 8Cyl V (496), Right Mode Door	MT18516	93-91	6.2L 8Cyl V (379), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
	8.1L 8Cyl V (496), Upper Air Inlet Recirculating - (Blower Housing)	MT18527	90-88	4.3L 6Cyl V (262), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
05-02	5.3L 8Cyl V (323), Lower Temperature Blend Air Door	MT18517		5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
	5.3L 8Cyl V (323), Right Mode Door	MT18516		5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
	5.3L 8Cyl V (323), Upper Air Inlet Recirculating - (Blower Housing)	MT18527		6.2L 8Cyl V (379), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
BLAZER			C/K1500, C/K2500, C/K3500		
05-95	4.3L 6Cyl V (262), Upper Temperature Blend Air Door - Electric Actuator - Electronic Controls	MT1800	99	5.0L 8Cyl V (305), Lower Temperature Blend Air Door	MT1800
	4.3L 6Cyl V (262), Upper Temperature Blend Air Door - Electric Actuator - Manual Controls	MT18503		5.0L 8Cyl V (305), Right Mode Door	MT18516
94-91	5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18507		5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18527
94	6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18507		5.7L 8Cyl V (350), Lower Temperature Blend Air Door	MT1800
91	6.2L 8Cyl V (379), Upper Air Inlet Recirculating - (Blower Housing)	MT18507		5.7L 8Cyl V (350), Right Mode Door	MT18516
C/K10,20 SUBURBAN, C/K1500-2500 SUBURBAN				5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18527
97-95	5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18519		6.5L 8Cyl V (395), Lower Temperature Blend Air Door	MT1800
	6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18519		6.5L 8Cyl V (395), Right Mode Door	MT18516
	7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18519		6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18527
94-92	5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18507		7.4L 8Cyl V (454), Lower Temperature Blend Air Door	MT1800
94	6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18507		7.4L 8Cyl V (454), Right Mode Door	MT18516
94-92	7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18507	97-95	7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18527
C/K1500, 2500				4.3L 6Cyl V (262), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
99	5.7L 8Cyl V (350), Lower Temperature Blend Air Door	MT1800		5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
	5.7L 8Cyl V (350), Right Mode Door	MT18516		5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
	5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18527		6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
	6.5L 8Cyl V (395), Lower Temperature Blend Air Door	MT1800	94-91	6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
	6.5L 8Cyl V (395), Right Mode Door	MT18516		7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
	6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18527	94-92	6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
	7.4L 8Cyl V (454), Lower Temperature Blend Air Door	MT1800	94-91	7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
	7.4L 8Cyl V (454), Right Mode Door	MT18516	93-91	6.2L 8Cyl V (379), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
	7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18527	90-88	4.3L 6Cyl V (262), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
97	5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18519		5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
97-95	5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18519		5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
	6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18519		6.2L 8Cyl V (379), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
	7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18519		7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
95	4.3L 6Cyl V (262), Upper Air Inlet Recirculating - (Blower Housing)	MT18519	CAPRICE		
	5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18519	15-14	3.6L 6Cyl V (217) Mode Door - (3 Required)	MT18610
94-91	4.3L 6Cyl V (262), Upper Air Inlet Recirculating - (Blower Housing)	MT18507		3.6L 6Cyl V (217) Temperature Blend Air Door	MT18542
	5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18507		6.0L 8Cyl V (364) Mode Door - (3 Required)	MT18610
	5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18507		6.0L 8Cyl V (364) Temperature Blend Air Door	MT18542
94-92	6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18507	13	3.6L 6Cyl V (217) Mode Door - No. 1	MT18610
94-91	7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18507		3.6L 6Cyl V (217) Mode Door - No. 2	MT18611
93-91	6.2L 8Cyl V (379), Upper Air Inlet Recirculating - (Blower Housing)	MT18507	(Cont'd)	3.6L 6Cyl V (217) Mode Door - No. 3	MT18542
(Cont'd)					

CHEVROLET (Con't)			CHEVROLET (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
CAPRICE (Cont'd)			IMPALA, IMPALA LIMITED		
13	6.0L 8Cyl V (364) Mode Door - No. 1	MT18610	03-00	3.4L 6Cyl V (207) Temperature Blend Air Door - Electric Actuator	MT18524
	6.0L 8Cyl V (364) Mode Door - No. 2	MT18611		3.8L 6Cyl V (231) Temperature Blend Air Door - Electric Actuator	MT18524
	6.0L 8Cyl V (364) Mode Door - No. 3	MT18542	MALIBU, MALIBU LIMITED		
12	3.6L 6Cyl V (217) Mode Door - No. 1	MT18611	12-08	2.4L 4Cyl L (145) Temperature Blend Air Door	MT18522
	3.6L 6Cyl V (217) Mode Door - No. 2	MT18542		3.6L 6Cyl V (217) Temperature Blend Air Door	MT18522
	3.6L 6Cyl V (217) Mode Door - No. 3	MT18610	10-08	3.5L 6Cyl V (213) Temperature Blend Air Door	MT18522
12-11	6.0L 8Cyl V (364) Mode Door - No. 1	MT18611		2.2L 4Cyl L (134) Temperature Blend Air Door	MT18522
	6.0L 8Cyl V (364) Mode Door - No. 2	MT18542	03-00	3.1L 6Cyl V (189) Temperature Blend Air Door - Electric Actuator	MT18524
	6.0L 8Cyl V (364) Mode Door - No. 3	MT18610		3.1L 6Cyl V (191) Temperature Blend Air Door - Electric Actuator	MT18524
COBALT			MONTE CARLO		
10-05	2.0L 4Cyl L (122) Temperature Blend Air Door	MT18614	03-00	3.4L 6Cyl V (207) Temperature Blend Air Door - Electric Actuator	MT18524
	2.2L 4Cyl L (134) Temperature Blend Air Door	MT18614		3.8L 6Cyl V (231) Temperature Blend Air Door - Electric Actuator	MT18524
08-06	2.4L 4Cyl L (145) Temperature Blend Air Door	MT18614	S10		
CORVETTE			04-94	4.3L 6Cyl V (262), Upper Temperature Blend Air Door - Electric Actuator - Electronic Controls	MT1800
04-97	5.7L 8Cyl V (350) Temperature Blend Air Door	MT1800	04-03	4.3L 6Cyl V (262), Upper Temperature Blend Air Door - Electric Actuator - Manual Controls	MT18503
EQUINOX			03-94	2.2L 4Cyl L (134), Upper Temperature Blend Air Door - Electric Actuator - Electronic Controls	MT1800
05	3.4L 6Cyl V (207), Upper Air Inlet Recirculating - (Blower Housing)	MT18526		2.2L 4Cyl L (134), Upper Temperature Blend Air Door - Electric Actuator - Manual Controls	MT18503
	3.4L 6Cyl V (209), Upper Air Inlet Recirculating - (Blower Housing)	MT18526	01-94	4.3L 6Cyl V (262), Upper Temperature Blend Air Door - Electric Actuator - Manual Controls	MT18503
EXPRESS 1500, 2500, 3500			00-97	-L -Cyl (-), Upper Temperature Blend Air Door - Electric Actuator - Electronic Controls	MT1800
15-03	4.8L 8Cyl V (294), Auxiliary Temperature Blend Air Door	MT18503		-L -Cyl (-), Upper Temperature Blend Air Door - Electric Actuator - Manual Controls	MT18503
	4.8L 8Cyl V (294), Left Auxiliary Mode Door	MT18523	S10 BLAZER		
	4.8L 8Cyl V (294), Left Main Temperature Blend Air Door - Electric Actuator - (Type 2)	MT18524	94	4.3L 6Cyl V (262), Upper Temperature Blend Air Door - Electric Actuator - Electronic Controls	MT1800
	6.0L 8Cyl V (364), Auxiliary Temperature Blend Air Door	MT18503		4.3L 6Cyl V (262), Upper Temperature Blend Air Door - Electric Actuator - Manual Controls	MT18503
	6.0L 8Cyl V (364), Left Auxiliary Mode Door	MT18523	SILVERADO 1500, SILVERADO 2500, SILVERADO 3500		
	6.0L 8Cyl V (364), Left Main Temperature Blend Air Door - Electric Actuator - (Type 2)	MT18524	13-07	4.3L 6Cyl V (262), Lower A.T.C. - Temperature Blend Air Door	MT1800
15-06	6.6L 8Cyl V (403), Auxiliary Temperature Blend Air Door	MT18503		4.3L 6Cyl V (262), Lower Manual A.C. - Temperature Blend Air Door	MT1800
	6.6L 8Cyl V (403), Left Auxiliary Mode Door	MT18523		4.3L 6Cyl V (262), Right A.T.C. - Mode Door	MT18614
	6.6L 8Cyl V (403), Left Main Temperature Blend Air Door - Electric Actuator - (Type 2)	MT18524		4.3L 6Cyl V (262), Upper A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800
14-03	5.3L 8Cyl V (325), Auxiliary Temperature Blend Air Door	MT18503		4.3L 6Cyl V (262), Upper A.T.C. - Temperature Blend Air Door	MT1800
	5.3L 8Cyl V (325), Left Auxiliary Mode Door	MT18523		4.3L 6Cyl V (262), Upper Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614
	5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - Electric Actuator - (Type 2)	MT18524		4.3L 6Cyl V (262), Upper Manual A.C. - Temperature Blend Air Door	MT18614
13-03	4.3L 6Cyl V (262), Auxiliary Temperature Blend Air Door	MT18503		4.8L 8Cyl V (294), Lower A.T.C. - Temperature Blend Air Door	MT1800
13-96	4.3L 6Cyl V (262), Left Auxiliary Mode Door	MT18523		4.8L 8Cyl V (294), Lower Manual A.C. - Temperature Blend Air Door	MT1800
13-03	4.3L 6Cyl V (262), Left Main Temperature Blend Air Door - Electric Actuator - (Type 2)	MT18524		4.8L 8Cyl V (294), Right A.T.C. - Mode Door	MT18614
05-03	5.3L 8Cyl V (323), Auxiliary Temperature Blend Air Door	MT18503		4.8L 8Cyl V (294), Upper A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800
	5.3L 8Cyl V (323), Left Auxiliary Mode Door	MT18523		4.8L 8Cyl V (294), Upper Manual A.C. - Temperature Blend Air Door	MT18614
	5.3L 8Cyl V (323), Left Main Temperature Blend Air Door - Electric Actuator - (Type 2)	MT18524		5.3L 8Cyl V (325), Lower A.T.C. - Temperature Blend Air Door	MT1800
02-96	4.3L 6Cyl V (262), Auxiliary Mode Door	MT18503		5.3L 8Cyl V (325), Lower Manual A.C. - Temperature Blend Air Door	MT1800
	4.3L 6Cyl V (262), Left Main Temperature Blend Air Door - Electric Actuator	MT18503		5.3L 8Cyl V (325), Right A.T.C. - Mode Door	MT18614
	5.0L 8Cyl V (305), Auxiliary Mode Door	MT18503		5.3L 8Cyl V (325), Upper A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800
	5.0L 8Cyl V (305), Left Auxiliary Mode Door	MT18523		5.3L 8Cyl V (325), Upper A.T.C. - Temperature Blend Air Door	MT1800
	5.0L 8Cyl V (305), Left Main Temperature Blend Air Door - Electric Actuator	MT18503		5.3L 8Cyl V (325), Upper Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614
	5.7L 8Cyl V (350), Auxiliary Mode Door	MT18503		4.8L 8Cyl V (294), Upper Manual A.C. - Temperature Blend Air Door	MT18614
	5.7L 8Cyl V (350), Left Auxiliary Mode Door	MT18523		5.3L 8Cyl V (325), Lower A.T.C. - Temperature Blend Air Door	MT1800
	5.7L 8Cyl V (350), Left Main Temperature Blend Air Door - Electric Actuator	MT18503		5.3L 8Cyl V (325), Lower Manual A.C. - Temperature Blend Air Door	MT1800
	6.5L 8Cyl V (395), Auxiliary Mode Door	MT18503		5.3L 8Cyl V (325), Right A.T.C. - Mode Door	MT18614
	6.5L 8Cyl V (395), Left Auxiliary Mode Door	MT18523		5.3L 8Cyl V (325), Upper A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800
	6.5L 8Cyl V (395), Left Main Temperature Blend Air Door - Electric Actuator	MT18503		5.3L 8Cyl V (325), Upper A.T.C. - Temperature Blend Air Door	MT1800
02-01	8.1L 8Cyl V (496), Auxiliary Mode Door	MT18503		5.3L 8Cyl V (325), Upper Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614
	8.1L 8Cyl V (496), Left Auxiliary Mode Door	MT18523		5.3L 8Cyl V (325), Upper Manual A.C. - Temperature Blend Air Door	MT18614
	8.1L 8Cyl V (496), Left Main Temperature Blend Air Door - Electric Actuator	MT18503		6.0L 8Cyl V (364), Lower A.T.C. - Temperature Blend Air Door	MT1800
00-96	7.4L 8Cyl V (454), Auxiliary Mode Door	MT18503		6.0L 8Cyl V (364), Lower Manual A.C. - Temperature Blend Air Door	MT1800
	7.4L 8Cyl V (454), Left Auxiliary Mode Door	MT18523		6.0L 8Cyl V (364), Right A.T.C. - Mode Door	MT18614
	7.4L 8Cyl V (454), Left Main Temperature Blend Air Door - Electric Actuator	MT18503	(Cont'd)		
HHR					
11-06	2.2L 4Cyl L (134), Right Temperature Blend Air Door	MT18614			
	2.4L 4Cyl L (145), Right Temperature Blend Air Door	MT18614			
10-08	2.0L 4Cyl L (122), Right Temperature Blend Air Door	MT18614			

CHEVROLET (Con't)			CHEVROLET (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
SILVERADO 1500, SILVERADO 2500, SILVERADO 3500 (Cont'd)			SUBURBAN 1500, SUBURBAN 2500 (Cont'd)		
13-07	6.0L 8Cyl V (364), Upper A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800	02-00	6.0L 8Cyl V (364), Right Mode Door	MT18516
	6.0L 8Cyl V (364), Upper A.T.C. - Temperature Blend Air Door	MT1800	02-01	8.1L 8Cyl V (496), Right Mode Door	MT18516
13-08	6.0L 8Cyl V (364), Upper Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614	TAHOE		
13-07	6.0L 8Cyl V (364), Upper Manual A.C. - Temperature Blend Air Door	MT18614	14-07	5.3L 8Cyl V (325), Left Air Inlet Recirculating - (Blower Housing)	MT1800
13-09	6.2L 8Cyl V (376), Lower A.T.C. - Temperature Blend Air Door	MT1800		5.3L 8Cyl V (325), Lower Temperature Blend Air Door	MT1800
	6.2L 8Cyl V (376), Lower Manual A.C. - Temperature Blend Air Door	MT1800	14-03	5.3L 8Cyl V (325), Right Mode Door	MT18614
	6.2L 8Cyl V (376), Right A.T.C. - Mode Door	MT18614	14-01	5.3L 8Cyl V (325), Upper Temperature Blend Air Door	MT1800
	6.2L 8Cyl V (376), Upper A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800	13-08	6.0L 8Cyl V (364), Left Air Inlet Recirculating - (Blower Housing)	MT1800
	6.2L 8Cyl V (376), Upper A.T.C. - Temperature Blend Air Door	MT1800		6.0L 8Cyl V (364), Lower Temperature Blend Air Door	MT1800
	6.2L 8Cyl V (376), Upper Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614		6.0L 8Cyl V (364), Right Mode Door	MT18614
	6.2L 8Cyl V (376), Upper Manual A.C. - Temperature Blend Air Door	MT18614	09-07	6.0L 8Cyl V (364), Upper Temperature Blend Air Door	MT1800
07	6.0L 8Cyl V (364), Upper Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18527		4.8L 8Cyl V (294), Left Air Inlet Recirculating - (Blower Housing)	MT1800
SILVERADO 1500 HD, SILVERADO 2500 HD, SILVERADO 3500 HD				4.8L 8Cyl V (294), Lower Temperature Blend Air Door	MT1800
07	6.0L 8Cyl V (364), Right Manual A.C. - Mode Door	MT18516	09-03	4.8L 8Cyl V (294), Right Mode Door	MT18614
	6.0L 8Cyl V (364), Upper Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614	09-01	4.8L 8Cyl V (294), Upper Temperature Blend Air Door	MT1800
	6.6L 8Cyl V (403), Right Manual A.C. - Mode Door	MT18516	09-08	6.2L 8Cyl V (376), Left Air Inlet Recirculating - (Blower Housing)	MT1800
	6.6L 8Cyl V (403), Upper Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18527		6.2L 8Cyl V (376), Lower Temperature Blend Air Door	MT1800
06-03	6.0L 8Cyl V (364), Lower Temperature Blend Air Door	MT1800		6.2L 8Cyl V (376), Right Mode Door	MT18614
06-01	6.0L 8Cyl V (364), Right Mode Door	MT18516	06-01	6.2L 8Cyl V (376), Upper Temperature Blend Air Door	MT1800
	6.0L 8Cyl V (364), Upper Air Inlet Recirculating - (Blower Housing)	MT18527		4.8L 8Cyl V (294), Left Air Inlet Recirculating - (Blower Housing)	MT18527
06-03	6.6L 8Cyl V (403), Lower Temperature Blend Air Door	MT1800		4.8L 8Cyl V (294), Lower Temperature Blend Air Door	MT18517
06-01	6.6L 8Cyl V (403), Right Mode Door	MT18516		5.3L 8Cyl V (325), Left Air Inlet Recirculating - (Blower Housing)	MT18527
	6.6L 8Cyl V (403), Upper Air Inlet Recirculating - (Blower Housing)	MT18527	02-01	5.3L 8Cyl V (325), Lower Temperature Blend Air Door	MT18517
	8.1L 8Cyl V (496), Lower Temperature Blend Air Door	MT1800		4.8L 8Cyl V (294), Right Mode Door	MT18516
	8.1L 8Cyl V (496), Right Mode Door	MT18516	97-95	5.3L 8Cyl V (325), Right Mode Door	MT18516
	8.1L 8Cyl V (496), Upper Air Inlet Recirculating - (Blower Housing)	MT18527		5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
02-01	6.0L 8Cyl V (364), Lower Temperature Blend Air Door	MT18517		6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
	6.6L 8Cyl V (403), Lower Temperature Blend Air Door	MT18517	TRAILBLAZER, TRAILBLAZER EXT		
	8.1L 8Cyl V (496), Lower Temperature Blend Air Door	MT18517	09-02	4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - without Rear A.C.	MT1809
SUBURBAN 1500, SUBURBAN 2500				4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521
14-07	5.3L 8Cyl V (325), Left Air Inlet Recirculating - (Blower Housing)	MT1800		4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612
	5.3L 8Cyl V (325), Lower Temperature Blend Air Door	MT1800		4.2L 6Cyl L (256), Main Mode Door - with Rear A.C.	MT18515
14-03	5.3L 8Cyl V (325), Right Mode Door	MT18614		4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - without Rear A.C.	MT1800
14-00	5.3L 8Cyl V (325), Upper Temperature Blend Air Door	MT1800		4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521
13-07	6.0L 8Cyl V (364), Left Air Inlet Recirculating - (Blower Housing)	MT1800	09-06	4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - with Rear A.C.	MT18527
	6.0L 8Cyl V (364), Lower Temperature Blend Air Door	MT1800		6.0L 8Cyl V (364), Left Main Temperature Blend Air Door - without Rear A.C.	MT1809
13-03	6.0L 8Cyl V (364), Right Mode Door	MT18614		6.0L 8Cyl V (364), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521
13-00	6.0L 8Cyl V (364), Upper Temperature Blend Air Door	MT1800		6.0L 8Cyl V (364), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612
12-09	6.0L 8Cyl V (366), Left Air Inlet Recirculating - (Blower Housing)	MT1800		6.0L 8Cyl V (364), Main Mode Door - with Rear A.C.	MT18515
	6.0L 8Cyl V (366), Lower Temperature Blend Air Door	MT1800		6.0L 8Cyl V (364), Right Main Temperature Blend Air Door - without Rear A.C.	MT1800
	6.0L 8Cyl V (366), Right Mode Door	MT18614		6.0L 8Cyl V (364), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521
	6.0L 8Cyl V (366), Upper Temperature Blend Air Door	MT1800	08-06	6.0L 8Cyl V (364), Right Main Temperature Blend Air Door - with Rear A.C.	MT18527
06-00	5.3L 8Cyl V (325), Left Air Inlet Recirculating - (Blower Housing)	MT18527		5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - without Rear A.C.	MT1809
	5.3L 8Cyl V (325), Lower Temperature Blend Air Door	MT18517		5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521
	6.0L 8Cyl V (364), Left Air Inlet Recirculating - (Blower Housing)	MT18527		5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612
	6.0L 8Cyl V (364), Lower Temperature Blend Air Door	MT18517		5.3L 8Cyl V (325), Main Mode Door - with Rear A.C.	MT18515
06-01	8.1L 8Cyl V (496), Left Air Inlet Recirculating - (Blower Housing)	MT18527		5.3L 8Cyl V (325), Right Main Temperature Blend Air Door - without Rear A.C.	MT1800
	8.1L 8Cyl V (496), Lower Temperature Blend Air Door	MT18517		5.3L 8Cyl V (325), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521
06-03	8.1L 8Cyl V (496), Right Mode Door	MT18614	02	4.2L 6Cyl L (256), Main Mode Door - without Rear A.C.	MT18515
06-01	8.1L 8Cyl V (496), Upper Temperature Blend Air Door	MT1800	TRAVERSE		
05-03	5.3L 8Cyl V (323), Left Air Inlet Recirculating - (Blower Housing)	MT18527	12-09	3.6L 6Cyl V (217), Main Air Inlet Recirculating - (Blower Housing)	MT18531
	5.3L 8Cyl V (323), Lower Temperature Blend Air Door	MT18517		3.6L 6Cyl V (217), Main Mode Door	MT18522
	5.3L 8Cyl V (323), Right Mode Door	MT18614		3.6L 6Cyl V (217), Main Temperature Blend Air Door	MT18522
	5.3L 8Cyl V (323), Upper Temperature Blend Air Door	MT1800	(Cont'd)		
02-00	5.3L 8Cyl V (325), Right Mode Door	MT18516			
	5.7L 8Cyl V (350), Left Air Inlet Recirculating - (Blower Housing)	MT18527			
	5.7L 8Cyl V (350), Lower Temperature Blend Air Door	MT18517			
	5.7L 8Cyl V (350), Right Mode Door	MT18516			
	5.7L 8Cyl V (350), Upper Temperature Blend Air Door	MT1800			
(Cont'd)					

CHEVROLET (Con't)			DODGE (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
TRAVERSE (Cont'd)			AVENGER (Cont'd)		
12-11	3.6L 6Cyl V (220), Main Air Inlet Recirculating - (Blower Housing)	MT18531	10-08	2.7L 6Cyl V (167) Actuator Motor	MT18595
	3.6L 6Cyl V (220), Main Mode Door	MT18522		3.5L 6Cyl V (215) Actuator Motor	MT18595
	3.6L 6Cyl V (220), Main Temperature Blend Air Door	MT18522	CALIBER		
UPLANDER			12-07	2.0L 4Cyl L (122) Actuator Motors - (2 Required)	MT18595
09-06	3.9L 6Cyl V (237), Auxiliary Temperature Blend Air Door	MT18595		2.4L 4Cyl L (144) Actuator Motors - (2 Required)	MT18595
	3.9L 6Cyl V (237), Right Main Air Inlet Recirculating - (Blower Housing)	MT18595	09-07	1.8L 4Cyl L (110) Actuator Motors - (2 Required)	MT18595
06-05	3.5L 6Cyl V (213), Auxiliary Temperature Blend Air Door	MT18595	CARAVAN, GRAND CARAVAN		
	3.5L 6Cyl V (213), Right Main Air Inlet Recirculating - (Blower Housing)	MT18595	15-11	3.6L 6Cyl V (220), Auxiliary Actuator Motors - (2 Required)	MT18595
	3.5L 6Cyl V (214), Auxiliary Temperature Blend Air Door	MT18595		3.6L 6Cyl V (220), Main Actuator Motors - (5 Required)	MT18595
	3.5L 6Cyl V (214), Right Main Air Inlet Recirculating - (Blower Housing)	MT18595	10-08	3.3L 6Cyl V (201), Auxiliary Actuator Motors - (2 Required)	MT18595
VENTURE				3.3L 6Cyl V (201), Main Actuator Motors - (5 Required)	MT18595
05-97	3.4L 6Cyl V (207), Auxiliary Temperature Blend Air Door	MT18525	10-09	3.8L 6Cyl V (231), Auxiliary Actuator Motors - (2 Required)	MT18595
	3.4L 6Cyl V (207), Left Auxiliary Temperature Blend Air Door	MT18527		3.8L 6Cyl V (231), Main Actuator Motors - (5 Required)	MT18595
	3.4L 6Cyl V (207), Main Mode Door	MT18529	10-08	4.0L 6Cyl V (241), Auxiliary Actuator Motors - (2 Required)	MT18595
	3.4L 6Cyl V (207), Main Temperature Blend Air Door	MT18524		4.0L 6Cyl V (241), Main Actuator Motors - (5 Required)	MT18595
01-97	3.4L 6Cyl V (204), Auxiliary Temperature Blend Air Door	MT18525	08	3.8L 6Cyl V (230), Auxiliary Actuator Motors - (2 Required)	MT18595
	3.4L 6Cyl V (204), Left Auxiliary Temperature Blend Air Door	MT18527		3.8L 6Cyl V (230), Main Actuator Motors - (5 Required)	MT18595
	3.4L 6Cyl V (204), Main Mode Door	MT18529	CHALLENGER		
	3.4L 6Cyl V (204), Main Temperature Blend Air Door	MT18524	15-11	3.6L 6Cyl V (220) Actuator Motors - (4 Required)	MT18595
CHRYSLER			15-09	5.7L 8Cyl V (345) Actuator Motors - (4 Required)	MT18595
SWITCH HEATER BLEND DOOR ACTUATOR			15	6.2L 8Cyl V (376) Actuator Motors - (4 Required)	MT18595
Year	Application	Part No.		6.2L 8Cyl V (378) Actuator Motors - (4 Required)	MT18595
200			15-11	6.4L 8Cyl V (392) Actuator Motors - (4 Required)	MT18595
14-11	2.4L 4Cyl L (144) Actuator Motor	MT18595	10-09	3.5L 6Cyl V (215) Actuator Motors - (4 Required)	MT18595
	3.6L 6Cyl V (220) Actuator Motor	MT18595		5.7L 8Cyl V (348) Actuator Motors - (4 Required)	MT18595
300			10-08	6.1L 8Cyl V (370) Actuator Motors - (4 Required)	MT18595
14-11	3.6L 6Cyl V (220) Actuator Motors - (4 Required)	MT18595	CHARGER		
	5.7L 8Cyl V (345) Actuator Motors - (4 Required)	MT18595	15-11	3.6L 6Cyl V (220) Actuator Motors - (4 Required)	MT18595
14-12	6.4L 8Cyl V (392) Actuator Motors - (4 Required)	MT18595		5.7L 8Cyl V (345) Actuator Motors - (4 Required)	MT18595
10-05	2.7L 6Cyl V (167) A.T.C. - Actuator - (4 Required)	MT18595	15	6.2L 8Cyl V (376) Actuator Motors - (4 Required)	MT18595
	2.7L 6Cyl V (167) Manual A.C. - Actuator Motor - (3 Required)	MT18595	15-12	6.4L 8Cyl V (392) Actuator Motors - (4 Required)	MT18595
	3.5L 6Cyl V (215) A.T.C. - Actuator - (4 Required)	MT18595	10-06	2.7L 6Cyl V (167) A.T.C. - Actuator - (4 Required)	MT18595
	3.5L 6Cyl V (215) Manual A.C. - Actuator Motor - (3 Required)	MT18595		2.7L 6Cyl V (167) Manual A.C. - Actuator Motor - (3 Required)	MT18595
	5.7L 8Cyl V (345) A.T.C. - Actuator - (4 Required)	MT18595		3.5L 6Cyl V (215) A.T.C. - Actuator - (4 Required)	MT18595
	5.7L 8Cyl V (345) Manual A.C. - Actuator Motor - (3 Required)	MT18595		3.5L 6Cyl V (215) Manual A.C. - Actuator Motor - (3 Required)	MT18595
	6.1L 8Cyl V (370) A.T.C. - Actuator - (4 Required)	MT18595		5.7L 8Cyl V (345) A.T.C. - Actuator - (4 Required)	MT18595
	6.1L 8Cyl V (370) Manual A.C. - Actuator Motor - (3 Required)	MT18595		5.7L 8Cyl V (345) Manual A.C. - Actuator Motor - (3 Required)	MT18595
ASPEN				6.1L 8Cyl V (370) A.T.C. - Actuator - (4 Required)	MT18595
09	4.7L 8Cyl V (285), Auxiliary Actuator Motors - (2 Required)	MT18595		6.1L 8Cyl V (370) Manual A.C. - Actuator Motor - (3 Required)	MT18595
	5.7L 8Cyl V (345), Auxiliary Actuator Motors - (2 Required)	MT18595	DAKOTA		
GRAND VOYAGER, VOYAGER, TOWN & COUNTRY			10-05	3.7L 6Cyl V (226) Actuator Motors - (2 Required)	MT18595
15-11	3.6L 6Cyl V (220), Auxiliary Actuator Motors - (2 Required)	MT18595		4.7L 8Cyl V (285) Actuator Motors - (2 Required)	MT18595
	3.6L 6Cyl V (220), Main Actuator Motors - (5 Required)	MT18595	DURANGO		
10-08	3.3L 6Cyl V (201), Auxiliary Actuator Motors - (2 Required)	MT18595	15-14	3.6L 6Cyl V (220), Main Actuator Motor - No. 2	MT18613
	3.3L 6Cyl V (201), Main Actuator Motors - (5 Required)	MT18595		5.7L 8Cyl V (345), Main Actuator Motor - No. 2	MT18613
10-09	3.8L 6Cyl V (231), Auxiliary Actuator Motors - (2 Required)	MT18595	13-11	3.6L 6Cyl V (220), Main Actuator Motors - (4 Required)	MT18595
	3.8L 6Cyl V (231), Main Actuator Motors - (5 Required)	MT18595		5.7L 8Cyl V (345), Main Actuator Motors - (4 Required)	MT18595
10-08	4.0L 6Cyl V (241), Auxiliary Actuator Motors - (2 Required)	MT18595	JOURNEY		
	4.0L 6Cyl V (241), Main Actuator Motors - (5 Required)	MT18595	15-09	2.4L 4Cyl L (144), Auxiliary Actuator Motors - (2 Required)	MT18616
08	3.8L 6Cyl V (230), Auxiliary Actuator Motors - (2 Required)	MT18595		2.4L 4Cyl L (144), Main Actuator Motors - (3 Required)	MT18595
	3.8L 6Cyl V (230), Main Actuator Motors - (5 Required)	MT18595	15-11	3.6L 6Cyl V (220), Auxiliary Actuator Motors - (2 Required)	MT18616
SEBRING				3.6L 6Cyl V (220), Main Actuator Motors - (3 Required)	MT18595
10-07	2.4L 4Cyl L (144) Actuator Motors - (3 Required)	MT18595	10-09	3.5L 6Cyl V (215), Auxiliary Actuator Motors - (2 Required)	MT18616
	2.7L 6Cyl V (167) Actuator Motors - (3 Required)	MT18595		3.5L 6Cyl V (215), Main Actuator Motors - (3 Required)	MT18595
	3.5L 6Cyl V (215) Actuator Motors - (3 Required)	MT18595	MAGNUM		
DODGE			08-05	2.7L 6Cyl V (167) A.T.C. - Actuator - (4 Required)	MT18595
SWITCH HEATER BLEND DOOR ACTUATOR				2.7L 6Cyl V (167) Manual A.C. - Actuator Motor - (3 Required)	MT18595
Year	Application	Part No.		3.5L 6Cyl V (215) A.T.C. - Actuator - (4 Required)	MT18595
AVENGER				3.5L 6Cyl V (215) Manual A.C. - Actuator Motor - (3 Required)	MT18595
14-08	2.4L 4Cyl L (144) Actuator Motor	MT18595		5.7L 8Cyl V (345) A.T.C. - Actuator - (4 Required)	MT18595
14-11	3.6L 6Cyl V (220) Actuator Motor	MT18595		5.7L 8Cyl V (345) Manual A.C. - Actuator Motor - (3 Required)	MT18595
(Cont'd)			08-06	6.1L 8Cyl V (370) A.T.C. - Actuator - (4 Required)	MT18595
				6.1L 8Cyl V (370) Manual A.C. - Actuator Motor - (3 Required)	MT18595
NITRO			11-07	3.7L 6Cyl V (226) Actuator Motors - (3 Required)	MT18617
				4.0L 6Cyl V (241) Actuator Motors - (3 Required)	MT18617

DODGE (Con't)			FORD (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
RAM 1500, RAM 2500, RAM 3500			EDGE (Cont'd)		
10-09	3.7L 6Cyl V (226) Actuator Motors - (4 Required)	MT18595	15-12	2.0L 4Cyl L (122) A.T.C. - Dual Zone - Defroster, Panel, Floor	MT18572
10-03	3.7L 6Cyl V (226), Main Replacement Door	MT18901		2.0L 4Cyl L (122) Manual A.C. - Air Inlet Recirculating - (Blower Housing) - without Humidity Sensor	MT18572
10-09	4.7L 8Cyl V (285) Actuator Motors - (4 Required)	MT18595		2.0L 4Cyl L (122) Manual A.C. - Mode Door - Defroster, Panel, Floor	MT18572
10-03	4.7L 8Cyl V (285), Main Replacement Door	MT18901		2.0L 4Cyl L (122) Manual A.C. - Temperature Blend Air Door	MT18573
10-09	5.7L 8Cyl V (345) Actuator Motors - (4 Required)	MT18595		2.0L 4Cyl L (122), Left A.T.C. - Dual Zone - Temperature Blend Door	MT18573
10-03	5.7L 8Cyl V (345), Main Replacement Door	MT18901		2.0L 4Cyl L (122), Right A.T.C. - Dual Zone - Temperature Blend Door	MT18573
10-09	5.9L 6Cyl L (359) Actuator Motors - (4 Required)	MT18595	15	2.7L 6Cyl V (164) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing) - without Humidity Sensor	MT18572
10-03	5.9L 6Cyl L (359), Main Replacement Door	MT18901		2.7L 6Cyl V (164) A.T.C. - Dual Zone - Defroster, Panel, Floor	MT18572
10-09	6.7L 6Cyl L (408) Actuator Motors - (4 Required)	MT18595		2.7L 6Cyl V (164) Manual A.C. - Air Inlet Recirculating - (Blower Housing) - without Humidity Sensor	MT18572
10-07	6.7L 6Cyl L (408), Main Replacement Door	MT18901		2.7L 6Cyl V (164) Manual A.C. - Mode Door - Defroster, Panel, Floor	MT18572
06-04	8.3L 10Cyl V (505), Main Replacement Door	MT18901		2.7L 6Cyl V (164) Manual A.C. - Temperature Blend Air Door	MT18573
04-03	4.7L 8Cyl V (287), Main Replacement Door	MT18901		2.7L 6Cyl V (164), Left A.T.C. - Dual Zone - Temperature Blend Door	MT18573
03	5.9L 8Cyl V (360), Main Replacement Door	MT18901		2.7L 6Cyl V (164), Right A.T.C. - Dual Zone - Temperature Blend Door	MT18573
	8.0L 10Cyl V (488), Main Replacement Door	MT18901	15-07	3.5L 6Cyl V (213) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing) - without Humidity Sensor	MT18572
RAM 1500 VAN				3.5L 6Cyl V (213) A.T.C. - Dual Zone - Defroster, Panel, Floor	MT18572
03	3.9L 6Cyl V (239), Main Replacement Door	MT18901		3.5L 6Cyl V (213) Manual A.C. - Air Inlet Recirculating - (Blower Housing) - without Humidity Sensor	MT18572
	5.2L 8Cyl V (318), Main Replacement Door	MT18901		3.5L 6Cyl V (213) Manual A.C. - Mode Door - Defroster, Panel, Floor	MT18572
	5.9L 8Cyl V (360), Main Replacement Door	MT18901		3.5L 6Cyl V (213) Manual A.C. - Temperature Blend Air Door	MT18573
RAM 2500 VAN				3.5L 6Cyl V (213), Left A.T.C. - Dual Zone - Temperature Blend Door	MT18573
03	5.2L 8Cyl V (318), Main Replacement Door	MT18901		3.5L 6Cyl V (213), Right A.T.C. - Dual Zone - Temperature Blend Door	MT18573
	5.9L 8Cyl V (360), Main Replacement Door	MT18901	11	3.7L 6Cyl V (227) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing) - without Humidity Sensor	MT18572
RAM 3500 VAN				3.7L 6Cyl V (227) A.T.C. - Dual Zone - Defroster, Panel, Floor	MT18572
03	5.2L 8Cyl V (318), Main Replacement Door	MT18901		3.7L 6Cyl V (227) Manual A.C. - Air Inlet Recirculating - (Blower Housing) - without Humidity Sensor	MT18572
	5.9L 8Cyl V (360), Main Replacement Door	MT18901		3.7L 6Cyl V (227) Manual A.C. - Mode Door - Defroster, Panel, Floor	MT18572
FORD				3.7L 6Cyl V (227) Manual A.C. - Temperature Blend Air Door	MT18573
SWITCH HEATER BLEND DOOR ACTUATOR				3.7L 6Cyl V (227), Left A.T.C. - Dual Zone - Temperature Blend Door	MT18573
Year	Application	Part No.		3.7L 6Cyl V (227), Right A.T.C. - Dual Zone - Temperature Blend Door	MT18573
CONTOUR				3.7L 6Cyl V (227) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing) - without Humidity Sensor	MT18572
00-95	2.0L 4Cyl L (121) Mode Door - (Electric Actuator)	MT18591		3.7L 6Cyl V (227) A.T.C. - Dual Zone - Defroster, Panel, Floor	MT18572
00-96	2.5L 6Cyl V (155) Mode Door - (Electric Actuator)	MT18591		3.7L 6Cyl V (227) Manual A.C. - Air Inlet Recirculating - (Blower Housing) - without Humidity Sensor	MT18572
96	2.0L 4Cyl L (122) Mode Door - (Electric Actuator)	MT18591		3.7L 6Cyl V (227) Manual A.C. - Mode Door - Defroster, Panel, Floor	MT18572
CROWN VICTORIA				3.7L 6Cyl V (227) Manual A.C. - Temperature Blend Air Door	MT18573
11-98	4.6L 8Cyl V (281) A.T.C. - Temperature Blend Air Door	MT18561		3.7L 6Cyl V (227), Left A.T.C. - Dual Zone - Temperature Blend Door	MT18573
11-92	4.6L 8Cyl V (281) Manual A.C. - Temperature Blend Air Door	MT18594		3.7L 6Cyl V (227), Right A.T.C. - Dual Zone - Temperature Blend Door	MT18573
97-95	4.6L 8Cyl V (281) A.T.C. - Temperature Blend Air Door	MT18555		3.7L 6Cyl V (227) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing) - without Humidity Sensor	MT18572
94-92	4.6L 8Cyl V (281) A.T.C. - Temperature Blend Air Door	MT18561		3.7L 6Cyl V (227) Manual A.C. - Mode Door - Defroster, Panel, Floor	MT18572
E-150, E-250				3.7L 6Cyl V (227) Manual A.C. - Temperature Blend Air Door	MT18573
14-03	4.6L 8Cyl V (281), Main Temperature Blend Air Door	MT18552		3.7L 6Cyl V (227), Left A.T.C. - Dual Zone - Temperature Blend Door	MT18573
	5.4L 8Cyl V (330), Main Temperature Blend Air Door	MT18552		3.7L 6Cyl V (227), Right A.T.C. - Dual Zone - Temperature Blend Door	MT18573
03	4.2L 6Cyl V (256), Main Temperature Blend Air Door	MT18552	ESCAPE		
E-150/E-250/E-350 CLUB WAGON, E-150/E-250/E-350 ECONOLINE, E-150/E-250/E-350 ECONOLINE CLUB WAGON			12-09	2.5L 4Cyl L (152) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18569
05-97	4.6L 8Cyl V (281), Main Temperature Blend Air Door	MT18552		2.5L 4Cyl L (152) A.T.C. - Dual Zone - Defroster, Panel, Floor	MT18569
	5.4L 8Cyl V (330), Main Temperature Blend Air Door	MT18552		2.5L 4Cyl L (152) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18595
05-04	6.0L 8Cyl V (363), Main Temperature Blend Air Door	MT18552		2.5L 4Cyl L (152) Manual A.C. - Defroster, Panel, Floor	MT18569
05	6.8L 10Cyl V (415), Main Temperature Blend Air Door	MT18552		2.5L 4Cyl L (152) Manual A.C. - Temperature Blend Air Door	MT18550
03-97	4.2L 6Cyl V (256), Main Temperature Blend Air Door	MT18552		2.5L 4Cyl L (152), Left A.T.C. - Dual Zone - Temperature Blend Door	MT18550
	6.8L 10Cyl V (415), Main Temperature Blend Air Door	MT18552		2.5L 4Cyl L (152), Right A.T.C. - Dual Zone - Temperature Blend Door	MT18550
	7.3L 8Cyl V (445), Main Temperature Blend Air Door	MT18552	12-08	3.0L 6Cyl V (181) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18569
96-93	4.9L 6Cyl L (300), Main Temperature Blend Air Door	MT18568		3.0L 6Cyl V (181) A.T.C. - Dual Zone - Defroster, Panel, Floor	MT18569
	5.0L 8Cyl V (302), Main Temperature Blend Air Door	MT18568		3.0L 6Cyl V (181) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18595
	5.8L 8Cyl V (351), Main Temperature Blend Air Door	MT18568		3.0L 6Cyl V (181) Manual A.C. - Defroster, Panel, Floor	MT18569
	7.3L 8Cyl V (445), Main Temperature Blend Air Door	MT18568		3.0L 6Cyl V (181) Manual A.C. - Temperature Blend Air Door	MT18550
	7.5L 8Cyl V (460), Main Temperature Blend Air Door	MT18568		3.0L 6Cyl V (181), Left A.T.C. - Dual Zone - Temperature Blend Door	MT18550
E-250 SUPER DUTY				3.0L 6Cyl V (181), Right A.T.C. - Dual Zone - Temperature Blend Door	MT18550
05-04	5.4L 8Cyl V (330), Main Temperature Blend Air Door	MT18552	10-08	3.0L 6Cyl V (183) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18569
E-350 SUPER DUTY				3.0L 6Cyl V (183) A.T.C. - Dual Zone - Defroster, Panel, Floor	MT18569
16-99	5.4L 8Cyl V (330), Main Temperature Blend Air Door	MT18552		3.0L 6Cyl V (183) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18595
	6.8L 10Cyl V (415), Main Temperature Blend Air Door	MT18552		3.0L 6Cyl V (183) Manual A.C. - Defroster, Panel, Floor	MT18569
10-04	6.0L 8Cyl V (363), Main Temperature Blend Air Door	MT18552			
03-99	7.3L 8Cyl V (445), Main Temperature Blend Air Door	MT18552			
EDGE					
15-12	2.0L 4Cyl L (122) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing) - without Humidity Sensor	MT18572			
(Cont'd)			(Cont'd)		

FORD (Con't)			FORD (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
ESCAPE (Cont'd)			EXPLORER (Cont'd)		
10-08	3.0L 6Cyl V (183) Manual A.C. - Temperature Blend Air Door . . .	MT18550	12-11	3.5L 6Cyl V (214), Right Main Mode Door . . .	MT18571
	3.0L 6Cyl V (183), Left A.T.C. - Dual Zone - Temperature Blend Door . . .	MT18550	10-02	4.0L 6Cyl V (245), Auxiliary Mode Door . . .	MT18508
	3.0L 6Cyl V (183), Right A.T.C. - Dual Zone - Temperature Blend Door . . .	MT18550		4.0L 6Cyl V (245), Auxiliary Temperature Blend Air Door . . .	MT18554
08	2.3L 4Cyl L (140) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing) . . .	MT18569		4.0L 6Cyl V (245), Left Main A.T.C. - Mode Door . . .	MT18558
	2.3L 4Cyl L (140) A.T.C. - Dual Zone - Defroster, Panel, Floor . . .	MT18569		4.0L 6Cyl V (245), Left Main Manual A.C. - Mode Door . . .	MT18509
	2.3L 4Cyl L (140) Manual A.C. - Air Inlet Recirculating - (Blower Housing) . . .	MT18595		4.0L 6Cyl V (245), Right Main A.T.C. - Mode Door . . .	MT18558
	2.3L 4Cyl L (140) Manual A.C. - Defroster, Panel, Floor . . .	MT18569		4.0L 6Cyl V (245), Right Main Manual A.C. - Mode Door . . .	MT18509
	2.3L 4Cyl L (140) Manual A.C. - Temperature Blend Air Door . . .	MT18550		4.6L 8Cyl V (281), Auxiliary Mode Door . . .	MT18508
	2.3L 4Cyl L (140), Left A.T.C. - Dual Zone - Temperature Blend Door . . .	MT18550		4.6L 8Cyl V (281), Auxiliary Temperature Blend Air Door . . .	MT18554
	2.3L 4Cyl L (140), Right A.T.C. - Dual Zone - Temperature Blend Door . . .	MT18550		4.6L 8Cyl V (281), Left Main A.T.C. - Mode Door . . .	MT18558
				4.6L 8Cyl V (281), Left Main Manual A.C. - Mode Door . . .	MT18509
				4.6L 8Cyl V (281), Right Main A.T.C. - Mode Door . . .	MT18558
				4.6L 8Cyl V (281), Right Main Manual A.C. - Mode Door . . .	MT18509
			01-98	4.0L 6Cyl V (245), Main A.T.C. - Blend Air Door . . .	MT18553
			01-97	4.0L 6Cyl V (245), Main Blend Door - with Auxiliary Console A.C. . .	MT18585
			01-98	5.0L 8Cyl V (302), Main A.T.C. - Blend Air Door . . .	MT18553
			01-97	5.0L 8Cyl V (302), Main Blend Door - with Auxiliary Console A.C. . .	MT18585
			97	4.0L 6Cyl V (245), Main A.T.C. - Blend Air Door . . .	MT18563
				5.0L 8Cyl V (302), Main A.T.C. - Blend Air Door . . .	MT18563
EXCURSION			EXPLORER SPORT TRAC		
05-01	5.4L 8Cyl V (330), Auxiliary Temperature Blend Air Door . . .	MT18579	10-07	4.0L 6Cyl V (245), Auxiliary Mode Door . . .	MT18508
	5.4L 8Cyl V (330), Main Temperature Blend Air Door - Manual A.C. . .	MT18511		4.0L 6Cyl V (245), Auxiliary Temperature Blend Air Door . . .	MT18554
05-03	6.0L 8Cyl V (363), Auxiliary Temperature Blend Air Door . . .	MT18579		4.0L 6Cyl V (245), Left Main A.T.C. - Mode Door . . .	MT18558
	6.0L 8Cyl V (363), Main Temperature Blend Air Door - Manual A.C. . .	MT18511		4.0L 6Cyl V (245), Left Main Manual A.C. - Mode Door . . .	MT18509
05-01	6.8L 10Cyl V (415), Auxiliary Temperature Blend Air Door . . .	MT18579		4.0L 6Cyl V (245), Right Main A.T.C. - Mode Door . . .	MT18558
	6.8L 10Cyl V (415), Main Temperature Blend Air Door - Manual A.C. . .	MT18511		4.0L 6Cyl V (245), Right Main Manual A.C. - Mode Door . . .	MT18509
03-01	7.3L 8Cyl V (445), Auxiliary Temperature Blend Air Door . . .	MT18579		4.6L 8Cyl V (281), Auxiliary Mode Door . . .	MT18508
	7.3L 8Cyl V (445), Main Temperature Blend Air Door - Manual A.C. . .	MT18511		4.6L 8Cyl V (281), Auxiliary Temperature Blend Air Door . . .	MT18554
				4.6L 8Cyl V (281), Left Main A.T.C. - Mode Door . . .	MT18558
				4.6L 8Cyl V (281), Left Main Manual A.C. - Mode Door . . .	MT18509
				4.6L 8Cyl V (281), Right Main A.T.C. - Mode Door . . .	MT18558
				4.6L 8Cyl V (281), Right Main Manual A.C. - Mode Door . . .	MT18509
			05-02	4.0L 6Cyl V (245), Auxiliary Mode Door . . .	MT18508
				4.0L 6Cyl V (245), Auxiliary Temperature Blend Air Door . . .	MT18554
				4.0L 6Cyl V (245), Left Main A.T.C. - Mode Door . . .	MT18558
				4.0L 6Cyl V (245), Left Main Manual A.C. - Mode Door . . .	MT18509
				4.0L 6Cyl V (245), Right Main A.T.C. - Mode Door . . .	MT18558
				4.0L 6Cyl V (245), Right Main Manual A.C. - Mode Door . . .	MT18509
			01	4.0L 6Cyl V (245), Main A.T.C. - Blend Air Door . . .	MT18553
				4.0L 6Cyl V (245), Main Blend Door - with Auxiliary Console A.C. . .	MT18585
EXPEDITION			F250/F-350 SUPERDUTY		
14-09	5.4L 8Cyl V (330), Auxiliary Temperature Blend Air Door - 114" Wheel Base . . .	MT18581	15-11	6.2L 8Cyl V (379), Lower A.T.C. - Actuator Motor . . .	MT18518
14-07	5.4L 8Cyl V (330), Auxiliary Temperature Blend Air Door - 131" Wheel Base . . .	MT18570		6.2L 8Cyl V (379), Right Actuator Motor . . .	MT18520
14-10	5.4L 8Cyl V (330), Main Air Inlet Recirculating - (Blower Housing) . . .	MT18595		6.2L 8Cyl V (379), Upper Actuator Motor . . .	MT18518
14-07	5.4L 8Cyl V (330), Main Mode Door - Defroster, Panel, Floor . . .	MT18569		6.7L 8Cyl V (406), Lower A.T.C. - Actuator Motor . . .	MT18518
14-09	5.4L 8Cyl V (330), Main Temperature Blend Air Door . . .	MT18551		6.7L 8Cyl V (406), Right Actuator Motor . . .	MT18520
09	5.4L 8Cyl V (330), Main Air Inlet Recirculating - (Blower Housing) - Before 03/30/2009 . . .	MT18595		6.7L 8Cyl V (406), Upper Actuator Motor . . .	MT18518
	5.4L 8Cyl V (330), Main Air Inlet Recirculating - (Blower Housing) - From 03/30/2009 . . .	MT18595		6.7L 8Cyl V (409), Lower A.T.C. - Actuator Motor . . .	MT18518
08-07	5.4L 8Cyl V (330), Auxiliary Temperature Blend Air Door - 114" Wheel Base . . .	MT18508		6.7L 8Cyl V (409), Right Actuator Motor . . .	MT18520
	5.4L 8Cyl V (330), Main Air Inlet Recirculating - (Blower Housing) . . .	MT18595		6.7L 8Cyl V (409), Upper Actuator Motor . . .	MT18518
	5.4L 8Cyl V (330), Main Temperature Blend Air Door . . .	MT18580	10-08	5.4L 8Cyl V (330) Temperature Blend Air Door . . .	MT18569
05-03	5.4L 8Cyl V (330), Auxiliary Mode Door . . .	MT18508		6.8L 10Cyl V (391) Temperature Blend Air Door . . .	MT18569
	5.4L 8Cyl V (330), Auxiliary Temperature Blend Air Door . . .	MT18554		6.8L 10Cyl V (415) Temperature Blend Air Door . . .	MT18569
	5.4L 8Cyl V (330), Main Mode Door - Defroster, Panel, Floor . . .	MT18509		5.4L 8Cyl V (330) A.T.C. - Blend Air Door . . .	MT18578
	5.4L 8Cyl V (330), Main Temperature Blend Air Door . . .	MT18581		5.4L 8Cyl V (330) Manual A.C. - Blend Air Door . . .	MT18511
04-03	4.6L 8Cyl V (281), Auxiliary Mode Door . . .	MT18508		6.0L 8Cyl V (363) A.T.C. - Blend Air Door . . .	MT18578
	4.6L 8Cyl V (281), Auxiliary Temperature Blend Air Door . . .	MT18554		6.0L 8Cyl V (363) Manual A.C. - Blend Air Door . . .	MT18511
	4.6L 8Cyl V (281), Main Mode Door - Defroster, Panel, Floor . . .	MT18509		6.8L 10Cyl V (415) A.T.C. - Blend Air Door . . .	MT18578
	4.6L 8Cyl V (281), Main Temperature Blend Air Door . . .	MT18581		6.8L 10Cyl V (415) Manual A.C. - Blend Air Door . . .	MT18511
02-00	4.6L 8Cyl V (281), Auxiliary Temperature Blend Air Door . . .	MT18579	04-99	5.4L 8Cyl V (330) Blend Door . . .	MT18511
02-98	4.6L 8Cyl V (281), Main Mode Door - Defroster, Panel, Floor . . .	MT18562	04-03	6.0L 8Cyl V (363) Blend Door . . .	MT18511
02-00	5.4L 8Cyl V (330), Auxiliary Temperature Blend Air Door . . .	MT18579	04-99	6.8L 10Cyl V (415) Blend Door . . .	MT18511
02-98	5.4L 8Cyl V (330), Main Mode Door - Defroster, Panel, Floor . . .	MT18562	03-99	7.3L 8Cyl V (445) Blend Door . . .	MT18511
EXPLORER			F-150, F250, F-350		
15-12	2.0L 4Cyl L (122), Auxiliary Mode Door . . .	MT18559	14-11	3.5L 6Cyl V (213) Air Inlet Recirculating - (Blower Housing) . . .	MT18550
	2.0L 4Cyl L (122), Auxiliary Temperature Blend Air Door . . .	MT18559		3.5L 6Cyl V (213) Manual A.C. - Temperature Blend Air Door . . .	MT18551
	2.0L 4Cyl L (122), Left Main Mode Door . . .	MT18571		3.5L 6Cyl V (213) Mode Door - Defroster, Panel, Floor . . .	MT18569
	2.0L 4Cyl L (122), Main Air Inlet Recirculating - (Blower Housing) . . .	MT18571		3.5L 6Cyl V (213), Left A.T.C. - Temperature Blend Air Door . . .	MT18551
	2.0L 4Cyl L (122), Right Main Mode Door . . .	MT18571		3.5L 6Cyl V (213), Right A.T.C. - Temperature Blend Air Door . . .	MT18551
15-11	3.5L 6Cyl V (213), Auxiliary Mode Door . . .	MT18559			
	3.5L 6Cyl V (213), Auxiliary Temperature Blend Air Door . . .	MT18559			
	3.5L 6Cyl V (213), Left Main Mode Door . . .	MT18571			
	3.5L 6Cyl V (213), Main Air Inlet Recirculating - (Blower Housing) . . .	MT18571			
	3.5L 6Cyl V (213), Right Main Mode Door . . .	MT18571			
12-11	3.5L 6Cyl V (214), Auxiliary Mode Door . . .	MT18559			
	3.5L 6Cyl V (214), Auxiliary Temperature Blend Air Door . . .	MT18559			
	3.5L 6Cyl V (214), Left Main Mode Door . . .	MT18571			
	3.5L 6Cyl V (214), Main Air Inlet Recirculating - (Blower Housing) . . .	MT18571			
(Cont'd)			(Cont'd)		

FORD (Con't)			FORD (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
F-150, F250, F-350 (Cont'd)			F-150, F250, F-350 (Cont'd)		
14-11	3.7L 6Cyl V (227) Air Inlet Recirculating - (Blower Housing)	MT18550	97	7.5L 8Cyl V (460) Blend Door	MT18556
	3.7L 6Cyl V (227) Manual A.C. - Temperature Blend Air Door	MT18551	F-150 HERITAGE		
	3.7L 6Cyl V (227) Mode Door - Defroster, Panel, Floor	MT18569	04	4.2L 6Cyl V (256) Air Inlet Recirculating - (Blower Housing)	MT18595
	3.7L 6Cyl V (227), Left A.T.C. - Temperature Blend Air Door	MT18551		4.2L 6Cyl V (256) Mode Door - Defroster, Panel, Floor	MT18562
	3.7L 6Cyl V (227), Right A.T.C. - Temperature Blend Air Door	MT18551		4.2L 6Cyl V (256), Left Temperature Blend Air Door	MT18510
	5.0L 8Cyl V (302) Air Inlet Recirculating - (Blower Housing)	MT18550		4.2L 6Cyl V (256), Right Temperature Blend Air Door	MT18510
	5.0L 8Cyl V (302) Manual A.C. - Temperature Blend Air Door	MT18551		4.6L 8Cyl V (281) Air Inlet Recirculating - (Blower Housing)	MT18595
	5.0L 8Cyl V (302) Mode Door - Defroster, Panel, Floor	MT18569		4.6L 8Cyl V (281) Mode Door - Defroster, Panel, Floor	MT18562
	5.0L 8Cyl V (302), Left A.T.C. - Temperature Blend Air Door	MT18551		4.6L 8Cyl V (281), Left Temperature Blend Air Door	MT18510
	5.0L 8Cyl V (302), Right A.T.C. - Temperature Blend Air Door	MT18551		4.6L 8Cyl V (281), Right Temperature Blend Air Door	MT18510
14-10	6.2L 8Cyl V (379) Air Inlet Recirculating - (Blower Housing)	MT18550		5.4L 8Cyl V (330) Air Inlet Recirculating - (Blower Housing)	MT18595
	6.2L 8Cyl V (379) Manual A.C. - Temperature Blend Air Door	MT18551		5.4L 8Cyl V (330) Mode Door - Defroster, Panel, Floor	MT18562
	6.2L 8Cyl V (379) Mode Door - Defroster, Panel, Floor	MT18569		5.4L 8Cyl V (330), Left Temperature Blend Air Door	MT18510
	6.2L 8Cyl V (379), Left A.T.C. - Temperature Blend Air Door	MT18551		5.4L 8Cyl V (330), Right Temperature Blend Air Door	MT18510
	6.2L 8Cyl V (379), Right A.T.C. - Temperature Blend Air Door	MT18551	FIESTA		
12-11	3.7L 6Cyl V (226) Air Inlet Recirculating - (Blower Housing)	MT18550	13-11	1.6L 4Cyl L (97) Air Inlet Recirculating - (Blower Housing)	MT18595
	3.7L 6Cyl V (226) Manual A.C. - Temperature Blend Air Door	MT18551		1.6L 4Cyl L (97) Mode Door	MT18595
	3.7L 6Cyl V (226) Mode Door - Defroster, Panel, Floor	MT18569		1.6L 4Cyl L (97) Temperature Blend Air Door	MT18595
	3.7L 6Cyl V (226), Left A.T.C. - Temperature Blend Air Door	MT18551		1.6L 4Cyl L (98) Air Inlet Recirculating - (Blower Housing)	MT18595
	3.7L 6Cyl V (226), Right A.T.C. - Temperature Blend Air Door	MT18551		1.6L 4Cyl L (98) Mode Door	MT18595
	5.0L 8Cyl V (305) Air Inlet Recirculating - (Blower Housing)	MT18550		1.6L 4Cyl L (98) Temperature Blend Air Door	MT18595
	5.0L 8Cyl V (305) Manual A.C. - Temperature Blend Air Door	MT18551	FIVE HUNDRED		
	5.0L 8Cyl V (305) Mode Door - Defroster, Panel, Floor	MT18569	07-05	3.0L 6Cyl V (181), Upper Temperature Blend Air Door	MT18570
	5.0L 8Cyl V (305), Left A.T.C. - Temperature Blend Air Door	MT18551		3.0L 6Cyl V (183), Upper Temperature Blend Air Door	MT18570
	5.0L 8Cyl V (305), Right A.T.C. - Temperature Blend Air Door	MT18551	FLEX		
10-09	4.2L 6Cyl V (256) Air Inlet Recirculating - (Blower Housing)	MT18550	15-09	3.5L 6Cyl V (213), Auxiliary Temperature Blend Air Door	MT18551
	4.2L 6Cyl V (256) Manual A.C. - Temperature Blend Air Door	MT18551		3.5L 6Cyl V (213), Left Main A.T.C. - Dual Zone - Blend Door	MT18571
	4.2L 6Cyl V (256) Mode Door - Defroster, Panel, Floor	MT18569		3.5L 6Cyl V (213), Main A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18571
	4.2L 6Cyl V (256), Left A.T.C. - Temperature Blend Air Door	MT18551		3.5L 6Cyl V (213), Main A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18571
	4.2L 6Cyl V (256), Right A.T.C. - Temperature Blend Air Door	MT18551		3.5L 6Cyl V (213), Right Main A.T.C. - Blend Air Door	MT18571
	4.6L 8Cyl V (281) Air Inlet Recirculating - (Blower Housing)	MT18550		3.5L 6Cyl V (213), Right Main A.T.C. - Dual Zone - Blend Door	MT18571
	4.6L 8Cyl V (281) Manual A.C. - Temperature Blend Air Door	MT18551	FOCUS		
	4.6L 8Cyl V (281) Mode Door - Defroster, Panel, Floor	MT18569	13-12	2.0L 4Cyl L (122) Actuator Motors - (5 Required)	MT18571
	4.6L 8Cyl V (281), Left A.T.C. - Temperature Blend Air Door	MT18551		-L -Cyl - (-) Actuator Motors - (5 Required)	MT18571
	4.6L 8Cyl V (281), Right A.T.C. - Temperature Blend Air Door	MT18551	12	2.0L 4Cyl L (121) Actuator Motors - (5 Required)	MT18571
	4.6L 8Cyl V (281) Air Inlet Recirculating - (Blower Housing)	MT18550	11-08	2.0L 4Cyl L (121) Air Inlet Recirculating - (Blower Housing)	MT18589
	4.6L 8Cyl V (281) Manual A.C. - Temperature Blend Air Door	MT18551		2.0L 4Cyl L (121), Left Mode Door - Defroster, Panel, Floor	MT18541
	4.6L 8Cyl V (281) Mode Door - Defroster, Panel, Floor	MT18569		2.0L 4Cyl L (121), Right Mode Door - Defroster, Panel, Floor	MT18541
	4.6L 8Cyl V (281), Left A.T.C. - Temperature Blend Air Door	MT18551	10	2.5L 5Cyl L (153) Air Inlet Recirculating - (Blower Housing)	MT18589
	4.6L 8Cyl V (281), Right A.T.C. - Temperature Blend Air Door	MT18551		2.5L 5Cyl L (153), Left Mode Door - Defroster, Panel, Floor	MT18541
	5.4L 8Cyl V (330) Air Inlet Recirculating - (Blower Housing)	MT18550		2.5L 5Cyl L (153), Right Mode Door - Defroster, Panel, Floor	MT18541
	5.4L 8Cyl V (330) Manual A.C. - Temperature Blend Air Door	MT18551		2.5L 5Cyl L (154) Air Inlet Recirculating - (Blower Housing)	MT18589
	5.4L 8Cyl V (330) Mode Door - Defroster, Panel, Floor	MT18569		2.5L 5Cyl L (154), Left Mode Door - Defroster, Panel, Floor	MT18541
	5.4L 8Cyl V (330), Left A.T.C. - Temperature Blend Air Door	MT18551		2.5L 5Cyl L (154), Right Mode Door - Defroster, Panel, Floor	MT18541
	5.4L 8Cyl V (330), Right A.T.C. - Temperature Blend Air Door	MT18551	03-00	2.0L 4Cyl L (121) Mode Door - A.C. Door	MT18574
08-02	4.2L 6Cyl V (256) Air Inlet Recirculating - (Blower Housing)	MT18550	03	2.3L 4Cyl L (140) Mode Door - A.C. Door	MT18574
	4.2L 6Cyl V (256), Left Temperature Blend Air Door	MT18510	FREESTAR		
	4.2L 6Cyl V (256), Right Temperature Blend Air Door	MT18510	07-04	3.9L 6Cyl V (238), Auxiliary Air Inlet Recirculating - (Blower Housing)	MT18510
	4.6L 8Cyl V (281) Air Inlet Recirculating - (Blower Housing)	MT18595		3.9L 6Cyl V (238), Auxiliary Mode Door	MT18550
	4.6L 8Cyl V (281), Left Temperature Blend Air Door	MT18510		3.9L 6Cyl V (238), Left Main Mode Door - A.T.C.	MT18583
	4.6L 8Cyl V (281), Right Temperature Blend Air Door	MT18510		3.9L 6Cyl V (238), Main Air Inlet Recirculating - (Blower Housing)	MT18595
	5.4L 8Cyl V (330) Air Inlet Recirculating - (Blower Housing)	MT18595		3.9L 6Cyl V (238), Main Mode Door - Manual A.C.	MT18583
	5.4L 8Cyl V (330), Left Temperature Blend Air Door	MT18510		3.9L 6Cyl V (238), Right Main Mode Door - A.T.C.	MT18583
	5.4L 8Cyl V (330), Right Temperature Blend Air Door	MT18510		4.2L 6Cyl V (256), Auxiliary Air Inlet Recirculating - (Blower Housing)	MT18510
05	4.2L 6Cyl V (256) Mode Door - Defroster, Panel, Floor - Before 11/13/2004	MT18550		4.2L 6Cyl V (256), Auxiliary Mode Door	MT18550
	4.6L 8Cyl V (281) Mode Door - Defroster, Panel, Floor - Before 11/13/2004	MT18550		4.2L 6Cyl V (256), Left Main Mode Door - A.T.C.	MT18583
	5.4L 8Cyl V (330) Mode Door - Defroster, Panel, Floor - Before 11/13/2004	MT18550		4.2L 6Cyl V (256), Main Air Inlet Recirculating - (Blower Housing)	MT18595
04-02	4.2L 6Cyl V (256) Mode Door - Defroster, Panel, Floor	MT18562		4.2L 6Cyl V (256), Main Mode Door - Manual A.C.	MT18583
	4.6L 8Cyl V (281) Mode Door - Defroster, Panel, Floor	MT18562		4.2L 6Cyl V (256), Right Main Mode Door - A.T.C.	MT18583
	5.4L 8Cyl V (330) Mode Door - Defroster, Panel, Floor	MT18562		4.2L 6Cyl V (256), Auxiliary Air Inlet Recirculating - (Blower Housing)	MT18510
01-97	4.2L 6Cyl V (256) A.C. Mode Door	MT18556		4.2L 6Cyl V (256), Auxiliary Mode Door	MT18550
	4.6L 8Cyl V (281) A.C. Mode Door	MT18556		4.2L 6Cyl V (256), Left Main Mode Door - A.T.C.	MT18583
	5.4L 8Cyl V (330) A.C. Mode Door	MT18556		4.2L 6Cyl V (256), Main Air Inlet Recirculating - (Blower Housing)	MT18595
99-97	4.6L 8Cyl V (281) Blend Door	MT18556		4.2L 6Cyl V (256), Main Mode Door - Manual A.C.	MT18583
	5.4L 8Cyl V (330) Blend Door	MT18556		4.2L 6Cyl V (256), Right Main Mode Door - A.T.C.	MT18583
97	4.9L 6Cyl L (300) A.C. Mode Door	MT18556	FREESTYLE		
	5.0L 8Cyl V (302) A.C. Mode Door	MT18556	07-05	3.0L 6Cyl V (181), Auxiliary Air Inlet Recirculating - (Blower Housing)	MT18577
	5.0L 8Cyl V (302) Blend Door	MT18556		3.0L 6Cyl V (181), Main Temperature Blend Air Door	MT18570
	5.8L 8Cyl V (351) A.C. Mode Door	MT18556			
	5.8L 8Cyl V (351) Blend Door	MT18556			
	7.3L 8Cyl V (445) A.C. Mode Door	MT18556			
	7.3L 8Cyl V (445) Blend Door	MT18556			
	7.5L 8Cyl V (460) A.C. Mode Door	MT18556			
(Cont'd)					

FORD (Con't)			FORD (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
FUSION			MUSTANG		
12-10	2.5L 4Cyl L (152) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18522	14-13	3.7L 6Cyl V (227) A.T.C. - Defroster Door	MT18595
	2.5L 4Cyl L (152) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18526		3.7L 6Cyl V (227) A.T.C. - Mode Door	MT18595
	2.5L 4Cyl L (152) A.T.C. - Dual Zone - Temperature Blend Door	MT18522		3.7L 6Cyl V (227) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18575
	2.5L 4Cyl L (152) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18526		3.7L 6Cyl V (227) Manual A.C. - Defroster Door	MT18595
	2.5L 4Cyl L (152) Manual A.C. - Temperature Blend Air Door	MT18522		3.7L 6Cyl V (227) Manual A.C. - Mode Door	MT18595
	2.5L 4Cyl L (153) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18522		3.7L 6Cyl V (227), Left Air Inlet Recirculating - (Blower Housing)	MT18575
	2.5L 4Cyl L (153) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18522		3.7L 6Cyl V (227), Right Air Inlet Recirculating - (Blower Housing)	MT18575
	2.5L 4Cyl L (153) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18526		3.7L 6Cyl V (228) A.T.C. - Defroster Door	MT18595
	2.5L 4Cyl L (153) A.T.C. - Dual Zone - Temperature Blend Door	MT18522		3.7L 6Cyl V (228) A.T.C. - Mode Door	MT18595
	2.5L 4Cyl L (153) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18526		3.7L 6Cyl V (228) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18575
	2.5L 4Cyl L (153) Manual A.C. - Temperature Blend Air Door	MT18522		3.7L 6Cyl V (228) Manual A.C. - Defroster Door	MT18595
	3.0L 6Cyl V (181) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18522		3.7L 6Cyl V (228) Manual A.C. - Mode Door	MT18595
	3.0L 6Cyl V (181) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18526		3.7L 6Cyl V (228), Left Air Inlet Recirculating - (Blower Housing)	MT18575
	3.0L 6Cyl V (181) A.T.C. - Dual Zone - Temperature Blend Door	MT18522		3.7L 6Cyl V (228), Right Air Inlet Recirculating - (Blower Housing)	MT18575
12-06	3.0L 6Cyl V (181) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18526		5.0L 8Cyl V (302) A.T.C. - Defroster Door	MT18595
12-10	3.0L 6Cyl V (181) Manual A.C. - Temperature Blend Air Door	MT18522		5.0L 8Cyl V (302) A.T.C. - Mode Door	MT18595
	3.5L 6Cyl V (213) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18522		5.0L 8Cyl V (302) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18575
	3.5L 6Cyl V (213) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18526		5.0L 8Cyl V (302) Manual A.C. - Defroster Door	MT18595
12	3.5L 6Cyl V (213) A.T.C. - Dual Zone - Temperature Blend Door	MT18522		5.0L 8Cyl V (302) Manual A.C. - Mode Door	MT18595
12-10	3.5L 6Cyl V (213) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18526		5.0L 8Cyl V (302), Left Air Inlet Recirculating - (Blower Housing)	MT18575
	3.5L 6Cyl V (213) Manual A.C. - Temperature Blend Air Door	MT18522		5.0L 8Cyl V (302), Right Air Inlet Recirculating - (Blower Housing)	MT18575
12-11	3.5L 6Cyl V (214) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18522		5.8L 8Cyl V (354) A.T.C. - Defroster Door	MT18595
	3.5L 6Cyl V (214) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18526		5.8L 8Cyl V (354) A.T.C. - Mode Door	MT18595
12	3.5L 6Cyl V (214) A.T.C. - Dual Zone - Temperature Blend Door	MT18522		5.8L 8Cyl V (354) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18575
12-10	3.5L 6Cyl V (214) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18526		5.8L 8Cyl V (354) Manual A.C. - Defroster Door	MT18595
	3.5L 6Cyl V (214) Manual A.C. - Temperature Blend Air Door	MT18522		5.8L 8Cyl V (354) Manual A.C. - Mode Door	MT18595
12-11	3.5L 6Cyl V (214) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18522		5.8L 8Cyl V (354), Left Air Inlet Recirculating - (Blower Housing)	MT18575
	3.5L 6Cyl V (214) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18526		5.8L 8Cyl V (354), Right Air Inlet Recirculating - (Blower Housing)	MT18575
12	3.5L 6Cyl V (214) A.T.C. - Dual Zone - Temperature Blend Door	MT18522		5.8L 8Cyl V (355) A.T.C. - Defroster Door	MT18595
12-11	3.5L 6Cyl V (214) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18526		5.8L 8Cyl V (355) A.T.C. - Mode Door	MT18595
	3.5L 6Cyl V (214) Manual A.C. - Temperature Blend Air Door	MT18522		5.8L 8Cyl V (355) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18575
10	2.3L 4Cyl L (140) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18522		5.8L 8Cyl V (355) Manual A.C. - Defroster Door	MT18595
	2.3L 4Cyl L (140) A.T.C. - Dual Zone - Temperature Blend Door	MT18522		5.8L 8Cyl V (355) Manual A.C. - Mode Door	MT18595
10-06	2.3L 4Cyl L (140) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18526		5.8L 8Cyl V (355), Left Air Inlet Recirculating - (Blower Housing)	MT18575
	2.3L 4Cyl L (140) Manual A.C. - Temperature Blend Air Door	MT18522		5.8L 8Cyl V (355), Right Air Inlet Recirculating - (Blower Housing)	MT18575
10	3.0L 6Cyl V (183) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18522		3.7L 6Cyl V (227) Mode Door - Defroster, Panel, Floor	MT18569
	3.0L 6Cyl V (183) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18526		3.7L 6Cyl V (227) Temperature Blend Air Door	MT18575
	3.0L 6Cyl V (183) A.T.C. - Dual Zone - Temperature Blend Door	MT18522		3.7L 6Cyl V (227), Left Air Inlet Recirculating - (Blower Housing)	MT18595
10-06	3.0L 6Cyl V (183) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18526		3.7L 6Cyl V (227), Right Air Inlet Recirculating - (Blower Housing)	MT18595
	3.0L 6Cyl V (183) Manual A.C. - Temperature Blend Air Door	MT18522		3.7L 6Cyl V (228) Mode Door - Defroster, Panel, Floor	MT18569
10	3.5L 6Cyl V (213) A.T.C. - Dual Zone - Temperature Blend Door	MT18522		3.7L 6Cyl V (228) Temperature Blend Air Door	MT18575
09-06	2.3L 4Cyl L (140) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18526		3.7L 6Cyl V (228), Left Air Inlet Recirculating - (Blower Housing)	MT18595
	2.3L 4Cyl L (140) A.T.C. - Temperature Blend Air Door	MT18614		3.7L 6Cyl V (228), Right Air Inlet Recirculating - (Blower Housing)	MT18595
	2.3L 4Cyl L (140) Manual A.C. - Temperature Blend Air Door	MT18614		5.0L 8Cyl V (302) Mode Door - Defroster, Panel, Floor	MT18569
	3.0L 6Cyl V (181) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18526		5.0L 8Cyl V (302) Temperature Blend Air Door	MT18575
	3.0L 6Cyl V (181) A.T.C. - Temperature Blend Air Door	MT18614		5.0L 8Cyl V (302), Left Air Inlet Recirculating - (Blower Housing)	MT18595
	3.0L 6Cyl V (181) Manual A.C. - Temperature Blend Air Door	MT18614		5.0L 8Cyl V (302), Right Air Inlet Recirculating - (Blower Housing)	MT18595
	3.0L 6Cyl V (183) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18526		5.4L 8Cyl V (330) Mode Door - Defroster, Panel, Floor	MT18569
	3.0L 6Cyl V (183) A.T.C. - Temperature Blend Air Door	MT18614		5.4L 8Cyl V (330) Temperature Blend Air Door	MT18575
	3.0L 6Cyl V (183) Manual A.C. - Temperature Blend Air Door	MT18614		5.4L 8Cyl V (330), Left Air Inlet Recirculating - (Blower Housing)	MT18595
				5.4L 8Cyl V (330), Right Air Inlet Recirculating - (Blower Housing)	MT18595
GT				4.0L 6Cyl V (245) Mode Door - Defroster, Panel, Floor	MT18569
06-05	5.4L 8Cyl V (330) Air Inlet Recirculating - (Blower Housing)	MT18595		4.0L 6Cyl V (245) Temperature Blend Air Door	MT18575
	5.4L 8Cyl V (330) Mode Door - Defroster, Panel, Floor	MT18550		4.0L 6Cyl V (245), Left Air Inlet Recirculating - (Blower Housing)	MT18595
	5.4L 8Cyl V (330) Temperature Blend Air Door	MT18570		4.0L 6Cyl V (245), Right Air Inlet Recirculating - (Blower Housing)	MT18595
				4.6L 8Cyl V (281) Mode Door - Defroster, Panel, Floor	MT18569
				4.6L 8Cyl V (281) Temperature Blend Air Door	MT18575
				4.6L 8Cyl V (281), Left Air Inlet Recirculating - (Blower Housing)	MT18595
				4.6L 8Cyl V (281), Right Air Inlet Recirculating - (Blower Housing)	MT18595
				4.0L 6Cyl V (245) Air Inlet Recirculating - (Blower Housing)	MT18595
				4.0L 6Cyl V (245) Mode Door - Defroster, Panel, Floor	MT18550
				4.0L 6Cyl V (245) Temperature Blend Air Door	MT18570
				4.6L 8Cyl V (281) Air Inlet Recirculating - (Blower Housing)	MT18595
				4.6L 8Cyl V (281) Mode Door - Defroster, Panel, Floor	MT18550
				4.6L 8Cyl V (281) Temperature Blend Air Door	MT18570
			09-07	5.4L 8Cyl V (330) Air Inlet Recirculating - (Blower Housing)	MT18595
			(Cont'd)		

FORD (Con't)			GMC (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
MUSTANG (Cont'd)			C/K15 SUBURBAN, C/K25 SUBURBAN, C/K1500 SUBURBAN, C/K 2500 SUBURBAN		
09-07	5.4L 8Cyl V (330) Mode Door - Defroster, Panel, Floor	MT18550	97-95	5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
	5.4L 8Cyl V (330) Temperature Blend Air Door	MT18570		6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
RANGER				7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
11-01	2.3L 4Cyl L (140) Blend Door - with Integral AC	MT18554	94-92	5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
11-97	4.0L 6Cyl V (245) Blend Door - with Integral AC	MT18554	94	6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
10	2.3L 4Cyl L (138) Blend Door - with Integral AC	MT18554	94-92	7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
08-97	3.0L 6Cyl V (182) Blend Door - with Integral AC	MT18554	C/K1500, C/K2500, C/K3500		
02	2.3L 4Cyl L (138) Blend Door - with Integral AC	MT18554	00-99	5.7L 8Cyl V (350), Lower Temperature Blend Air Door	MT1800
02-98	-L -Cyl - (-) Blend Door	MT18553		5.7L 8Cyl V (350), Right Mode Door	MT18516
97	2.3L 4Cyl L (140) Blend Door - with Integral AC	MT18554		5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18527
TAURUS				6.5L 8Cyl V (395), Lower Temperature Blend Air Door	MT1800
15-13	2.0L 4Cyl L (122) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18571		6.5L 8Cyl V (395), Right Mode Door	MT18516
	2.0L 4Cyl L (122) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18571		6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18527
	2.0L 4Cyl L (122), Left Temperature Blend Air Door	MT18571		7.4L 8Cyl V (454), Lower Temperature Blend Air Door	MT1800
	2.0L 4Cyl L (122), Right Temperature Blend Air Door	MT18571		7.4L 8Cyl V (454), Right Mode Door	MT18516
15-10	3.5L 6Cyl V (213) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18571	99	7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18527
	3.5L 6Cyl V (213) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18571		5.0L 8Cyl V (305), Lower Temperature Blend Air Door	MT1800
	3.5L 6Cyl V (213), Left Temperature Blend Air Door	MT18571		5.0L 8Cyl V (305), Right Mode Door	MT18516
15-08	3.5L 6Cyl V (213), Right Temperature Blend Air Door	MT18571	97	5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18527
	3.5L 6Cyl V (213) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18570		4.3L 6Cyl V (262), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
09-08	3.5L 6Cyl V (213) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18570	97-96	5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
	3.5L 6Cyl V (213) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18570		5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
07-05	3.0L 6Cyl V (182) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18570		6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
07-97	3.0L 6Cyl V (182) A.T.C. - Mode Door	MT18558		7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18519
07-05	3.0L 6Cyl V (182) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18570	94-91	4.3L 6Cyl V (262), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
07-97	3.0L 6Cyl V (182) Manual A.C. - Mode Door	MT18557		5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
05	3.0L 6Cyl V (181) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18570		5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
05-97	3.0L 6Cyl V (181) A.T.C. - Mode Door	MT18558	94-92	6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
05	3.0L 6Cyl V (181) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18570	94-91	7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
05-97	3.0L 6Cyl V (181) Manual A.C. - Mode Door	MT18557	93-91	6.2L 8Cyl V (379), Upper Air Inlet Recirculating - (Blower Housing)	MT18507
95-91	3.0L 6Cyl V (182) Mode Door - A.T.C.	MT18588	90-88	4.3L 6Cyl V (262), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
	3.0L 6Cyl V (182) Mode Door - Manual A.C.	MT18586		5.0L 8Cyl V (305), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
TAURUS X				5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
09-08	3.5L 6Cyl V (213), Auxiliary Temperature Blend Air Door	MT18577		6.2L 8Cyl V (379), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
	3.5L 6Cyl V (213), Left Main Temperature Blend Air Door	MT18571		7.4L 8Cyl V (454), Upper Air Inlet Recirculating - (Blower Housing)	MT18505
	3.5L 6Cyl V (213), Main Air Inlet Recirculating - (Blower Housing) - A.T.C.	MT18571	ENVOY, ENVOY XL, ENVOY XUV		
	3.5L 6Cyl V (213), Main Air Inlet Recirculating - (Blower Housing) - Manual A.C.	MT18571	09-02	4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1809
	3.5L 6Cyl V (213), Right Main Temperature Blend Air Door	MT18571		4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521
THUNDERBIRD				4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612
05-02	3.9L 8Cyl V (242) Air Inlet Recirculating - (Blower Housing)	MT18576		4.2L 6Cyl L (256), Main Mode Door - with Rear A.C.	MT18515
	3.9L 8Cyl V (242) Cold Air By-Pass	MT18587		4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1800
	3.9L 8Cyl V (242) Floor Air Flow	MT18592		4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521
	3.9L 8Cyl V (242) Panel Control Door	MT18567		4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - with Rear A.C.	MT18527
97-96	3.8L 6Cyl V (232) Temperature Blend Air Door - Manual A.C.	MT18579	08-06	5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1809
	4.6L 8Cyl V (281) Temperature Blend Air Door - Manual A.C.	MT18579		5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521
WINDSTAR				5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612
03-99	3.8L 6Cyl V (232), Auxiliary Blend Door	MT18584		5.3L 8Cyl V (325), Main Mode Door - with Rear A.C.	MT18515
	3.8L 6Cyl V (232), Main Blend Door	MT18507		5.3L 8Cyl V (325), Right Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1800
00-99	3.0L 6Cyl V (182), Auxiliary Blend Door	MT18584		5.3L 8Cyl V (325), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521
	3.0L 6Cyl V (182), Main Blend Door	MT18507		5.3L 8Cyl V (325), Right Main Temperature Blend Air Door - with Rear A.C.	MT18527
GMC			02	4.2L 6Cyl L (256), Main Mode Door - without Rear A.C.	MT18515
SWITCH HEATER BLEND DOOR ACTUATOR			JIMMY		
Year	Application	Part No.	Year	Application	Part No.
ACADIA			05	4.3L 6Cyl V (4294), Upper Temperature Blend Air Door - Electric Actuator - Electronic Controls	MT1800
12-07	3.6L 6Cyl V (217), Main Air Inlet Recirculating - (Blower Housing)	MT18531		4.3L 6Cyl V (4294), Upper Temperature Blend Air Door - Electric Actuator - Manual Controls	MT18503
	3.6L 6Cyl V (217), Main Mode Door	MT18522	04-94	4.3L 6Cyl V (262), Upper Temperature Blend Air Door - Electric Actuator - Electronic Controls	MT1800
	3.6L 6Cyl V (217), Main Temperature Blend Air Door	MT18522	(Cont'd)		

GMC (Con't)			GMC (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
JIMMY (Cont'd)			SIERRA 1500, SIERRA 2500, SIERRA 3500 (Cont'd)		
04-94	4.3L 6Cyl V (262), Upper Temperature Blend Air Door - Electric Actuator - Manual Controls	MT18503	13-07	5.3L 8Cyl V (325), Lower A.T.C. - Temperature Blend Air Door	MT1800
91	5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18507		5.3L 8Cyl V (325), Lower Manual A.C. - Temperature Blend Air Door	MT1800
	6.2L 8Cyl V (379), Upper Air Inlet Recirculating - (Blower Housing)	MT18507		5.3L 8Cyl V (325), Right A.T.C. - Mode Door	MT18614
SAVAVN 1500, 2500, 3500				5.3L 8Cyl V (325), Upper A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800
15-03	4.8L 8Cyl V (294), Auxiliary Temperature Blend Air Door	MT18503		5.3L 8Cyl V (325), Upper A.T.C. - Temperature Blend Air Door	MT1800
	4.8L 8Cyl V (294), Left Auxiliary Mode Door	MT18523		5.3L 8Cyl V (325), Upper Manual A.C. - Temperature Blend Air Door	MT18614
	4.8L 8Cyl V (294), Left Main Temperature Blend Air Door - Electric Actuator - (Type 2)	MT18524		6.0L 8Cyl V (364) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614
	6.0L 8Cyl V (364), Auxiliary Temperature Blend Air Door	MT18503		6.0L 8Cyl V (364), Lower A.T.C. - Temperature Blend Air Door	MT1800
	6.0L 8Cyl V (364), Left Auxiliary Mode Door	MT18523		6.0L 8Cyl V (364), Lower Manual A.C. - Temperature Blend Air Door	MT1800
	6.0L 8Cyl V (364), Left Main Temperature Blend Air Door - Electric Actuator - (Type 2)	MT18524		6.0L 8Cyl V (364), Right A.T.C. - Mode Door	MT18614
15-06	6.6L 8Cyl V (403), Auxiliary Temperature Blend Air Door	MT18503		6.0L 8Cyl V (364), Upper A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800
	6.6L 8Cyl V (403), Left Auxiliary Mode Door	MT18523		6.0L 8Cyl V (364), Upper A.T.C. - Temperature Blend Air Door	MT1800
	6.6L 8Cyl V (403), Left Main Temperature Blend Air Door - Electric Actuator - (Type 2)	MT18524		6.0L 8Cyl V (364), Upper Manual A.C. - Temperature Blend Air Door	MT18614
14-03	5.3L 8Cyl V (325), Auxiliary Temperature Blend Air Door	MT18503	13-11	6.2L 8Cyl V (376) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614
	5.3L 8Cyl V (325), Left Auxiliary Mode Door	MT18523		6.2L 8Cyl V (376), Lower A.T.C. - Temperature Blend Air Door	MT1800
	5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - Electric Actuator - (Type 2)	MT18524		6.2L 8Cyl V (376), Lower Manual A.C. - Temperature Blend Air Door	MT1800
13-03	4.3L 6Cyl V (262), Auxiliary Temperature Blend Air Door	MT18503	13-09	6.2L 8Cyl V (376), Right A.T.C. - Mode Door	MT18614
13-96	4.3L 6Cyl V (262), Left Auxiliary Mode Door	MT18523		6.2L 8Cyl V (376), Upper A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800
13-03	4.3L 6Cyl V (262), Left Main Temperature Blend Air Door - Electric Actuator - (Type 2)	MT18524		6.2L 8Cyl V (376), Upper A.T.C. - Temperature Blend Air Door	MT1800
02-96	4.3L 6Cyl V (262), Auxiliary Mode Door	MT18503		6.2L 8Cyl V (376), Upper Manual A.C. - Temperature Blend Air Door	MT18614
	4.3L 6Cyl V (262), Left Main Temperature Blend Air Door - Electric Actuator	MT18503		6.2L 8Cyl V (376), Air Inlet Recirculating - (Blower Housing)	MT18614
	5.0L 8Cyl V (305), Auxiliary Mode Door	MT18503	10	6.2L 8Cyl V (376) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614
	5.0L 8Cyl V (305), Left Auxiliary Mode Door	MT18523	09		
	5.0L 8Cyl V (305), Left Main Temperature Blend Air Door - Electric Actuator	MT18503	SIERRA 1500 HD, SIERRA 2500 HD, SIERRA 3500 HD		
	5.7L 8Cyl V (350), Auxiliary Mode Door	MT18503	13-07	6.0L 8Cyl V (364) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614
	5.7L 8Cyl V (350), Left Auxiliary Mode Door	MT18523		6.0L 8Cyl V (364), Lower A.T.C. - Temperature Blend Air Door	MT1800
	5.7L 8Cyl V (350), Left Main Temperature Blend Air Door - Electric Actuator	MT18503		6.0L 8Cyl V (364), Lower Manual A.C. - Temperature Blend Air Door	MT1800
	6.5L 8Cyl V (395), Auxiliary Mode Door	MT18503		6.0L 8Cyl V (364), Right A.T.C. - Mode Door	MT18614
	6.5L 8Cyl V (395), Left Auxiliary Mode Door	MT18523		6.0L 8Cyl V (364), Upper A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800
	6.5L 8Cyl V (395), Left Main Temperature Blend Air Door - Electric Actuator	MT18503		6.0L 8Cyl V (364), Upper A.T.C. - Temperature Blend Air Door	MT1800
02-01	8.1L 8Cyl V (496), Auxiliary Mode Door	MT18503		6.0L 8Cyl V (364), Upper Manual A.C. - Temperature Blend Air Door	MT18614
	8.1L 8Cyl V (496), Left Auxiliary Mode Door	MT18523		6.6L 8Cyl V (403) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614
	8.1L 8Cyl V (496), Left Main Temperature Blend Air Door - Electric Actuator	MT18503		6.6L 8Cyl V (403), Lower A.T.C. - Temperature Blend Air Door	MT1800
00-96	7.4L 8Cyl V (454), Auxiliary Mode Door	MT18503		6.6L 8Cyl V (403), Lower Manual A.C. - Temperature Blend Air Door	MT1800
	7.4L 8Cyl V (454), Left Auxiliary Mode Door	MT18523		6.6L 8Cyl V (403), Right A.T.C. - Mode Door	MT18614
	7.4L 8Cyl V (454), Left Main Temperature Blend Air Door - Electric Actuator	MT18503		6.6L 8Cyl V (403), Upper A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800
SIERRA 1500, SIERRA 2500, SIERRA 3500				6.6L 8Cyl V (403), Upper A.T.C. - Temperature Blend Air Door	MT1800
13-07	4.3L 6Cyl V (262) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614	TERRAIN		
	4.3L 6Cyl V (262), Lower A.T.C. - Temperature Blend Air Door	MT1800	13	3.6L 6Cyl V (217), Lower Air Inlet Recirculating - (Blower Housing) - 1st Design	MT18541
	4.3L 6Cyl V (262), Lower Manual A.C. - Temperature Blend Air Door	MT1800		3.6L 6Cyl V (220), Lower Air Inlet Recirculating - (Blower Housing) - 1st Design	MT18541
	4.3L 6Cyl V (262), Right A.T.C. - Mode Door	MT18614	12-11	3.0L 6Cyl V (182), Lower Air Inlet Recirculating - (Blower Housing)	MT18541
	4.3L 6Cyl V (262), Upper A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800		3.0L 6Cyl V (182), Upper Air Inlet Recirculating - (Blower Housing)	MT18541
	4.3L 6Cyl V (262), Upper A.T.C. - Temperature Blend Air Door	MT1800		3.0L 6Cyl V (183), Lower Air Inlet Recirculating - (Blower Housing)	MT18541
	4.3L 6Cyl V (262), Upper Manual A.C. - Temperature Blend Air Door	MT18614		3.0L 6Cyl V (183), Upper Air Inlet Recirculating - (Blower Housing)	MT18541
	4.8L 8Cyl V (294) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614	YUKON, YUKON XL, YUKON XL 1500, YUKON XL 2500		
	4.8L 8Cyl V (294), Lower A.T.C. - Temperature Blend Air Door	MT1800	14-07	5.3L 8Cyl V (325), Left Air Inlet Recirculating - (Blower Housing)	MT1800
	4.8L 8Cyl V (294), Lower Manual A.C. - Temperature Blend Air Door	MT1800		5.3L 8Cyl V (325), Lower Temperature Blend Air Door	MT1800
	4.8L 8Cyl V (294), Right A.T.C. - Mode Door	MT18614	14-03	5.3L 8Cyl V (325), Right Mode Door	MT18614
	4.8L 8Cyl V (294), Upper A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800	14-01	5.3L 8Cyl V (325), Upper Temperature Blend Air Door	MT1800
	4.8L 8Cyl V (294), Upper A.T.C. - Temperature Blend Air Door	MT1800	(Cont'd)		
	4.8L 8Cyl V (294), Upper Manual A.C. - Temperature Blend Air Door	MT18614			
	5.3L 8Cyl V (325) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT18614			
(Cont'd)					

GMC (Con't)			HYUNDAI (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
YUKON, YUKON XL, YUKON XL 1500, YUKON XL 2500 (Cont'd)			TIBURON		
13-08	6.0L 8Cyl V (364), Left Air Inlet Recirculating - (Blower Housing)	MT1800	08-03	2.0L 4Cyl L (1975) Mode Control	MT18546
	6.0L 8Cyl V (364), Lower Temperature Blend Air Door	MT1800		2.0L 4Cyl L (1975) Temperature Blend Air Door	MT18548
	6.0L 8Cyl V (364), Right Mode Door	MT18614		2.7L 6Cyl V (2656) Mode Control	MT18546
	6.0L 8Cyl V (364), Upper Temperature Blend Air Door	MT1800		2.7L 6Cyl V (2656) Temperature Blend Air Door	MT18548
09-07	4.8L 8Cyl V (294), Left Air Inlet Recirculating - (Blower Housing)	MT1800	VERACRUZ		
	4.8L 8Cyl V (294), Lower Temperature Blend Air Door	MT1800	12-07	3.8L 6Cyl V (3778), Main Air Inlet Recirculating - (Blower Housing)	MT18544
09-03	4.8L 8Cyl V (294), Right Mode Door	MT18614	ISUZU		
09-01	4.8L 8Cyl V (294), Upper Temperature Blend Air Door	MT1800	SWITCH HEATER BLEND DOOR ACTUATOR		
09-08	6.2L 8Cyl V (376), Left Air Inlet Recirculating - (Blower Housing)	MT1800	Year	Application	Part No.
	6.2L 8Cyl V (376), Lower Temperature Blend Air Door	MT1800	ASCENDER		
	6.2L 8Cyl V (376), Right Mode Door	MT18614	08-03	4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1809
	6.2L 8Cyl V (376), Upper Temperature Blend Air Door	MT1800		4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521
	6.2L 8Cyl V (378), Left Air Inlet Recirculating - (Blower Housing)	MT1800		4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612
	6.2L 8Cyl V (378), Lower Temperature Blend Air Door	MT1800		4.2L 6Cyl L (256), Main Mode Door - with Rear A.C.	MT18515
	6.2L 8Cyl V (378), Right Mode Door	MT18614		4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1800
06-01	6.2L 8Cyl V (378), Upper Temperature Blend Air Door	MT1800		4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521
	4.8L 8Cyl V (294), Left Air Inlet Recirculating - (Blower Housing)	MT18527		4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - with Rear A.C.	MT18527
	4.8L 8Cyl V (294), Lower Temperature Blend Air Door	MT18517	06-03	5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1809
	5.3L 8Cyl V (325), Left Air Inlet Recirculating - (Blower Housing)	MT18527		5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521
	5.3L 8Cyl V (325), Lower Temperature Blend Air Door	MT18517		5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612
02-01	4.8L 8Cyl V (294), Right Mode Door	MT18516		5.3L 8Cyl V (325), Main Mode Door - with Rear A.C.	MT18515
	5.3L 8Cyl V (325), Right Mode Door	MT18516		5.3L 8Cyl V (325), Right Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1800
97-95	5.7L 8Cyl V (350), Upper Air Inlet Recirculating - (Blower Housing)	MT18519		5.3L 8Cyl V (325), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521
	6.5L 8Cyl V (395), Upper Air Inlet Recirculating - (Blower Housing)	MT18519		5.3L 8Cyl V (325), Right Main Temperature Blend Air Door - with Rear A.C.	MT18527
HYUNDAI			JEEP		
SWITCH HEATER BLEND DOOR ACTUATOR			SWITCH HEATER BLEND DOOR ACTUATOR		
Year	Application	Part No.	Year	Application	Part No.
ACCENT			COMMANDER		
11-06	1.6L 4Cyl L (1599) Mode Control	MT18544	10-06	3.7L 6Cyl V (226) Actuator Motors - (4 Required)	MT18618
09-08	1.6L 4Cyl L (1599) Air Inlet Recirculating - (Blower Housing)	MT18545		4.7L 8Cyl V (285) Actuator Motors - (4 Required)	MT18618
07-06	1.6L 4Cyl L (1599) Air Inlet Recirculating - (Blower Housing)	MT18544		5.7L 8Cyl V (345) Actuator Motors - (4 Required)	MT18618
06	1.6L 4Cyl L (1600) Air Inlet Recirculating - (Blower Housing)	MT18544	COMPASS		
	1.6L 4Cyl L (1600) Mode Control	MT18544	15-07	2.0L 4Cyl L (122) Actuator Motors - (6 Required)	MT18595
				2.4L 4Cyl L (144) Actuator Motors - (6 Required)	MT18595
AZERA			GRAND CHEROKEE		
10	3.3L 6Cyl V (3342) Mode Control - Before 10/24/2009	MT18547	15-14	3.0L 6Cyl V (182) Defroster Door	MT18613
10-07	3.3L 6Cyl V (3342) Temperature Blend Air Door	MT18547		3.6L 6Cyl V (220) Defroster Door	MT18613
10	3.8L 6Cyl V (3778) Mode Control - Before 10/24/2009	MT18547		5.7L 8Cyl V (345) Defroster Door	MT18613
10-06	3.8L 6Cyl V (3778) Temperature Blend Air Door	MT18547		6.4L 8Cyl V (392) Defroster Door	MT18613
08-07	3.3L 6Cyl V (3342) Mode Control	MT18547	13-11	3.6L 6Cyl V (220) Actuator Motors - (4 Required)	MT18595
08-06	3.8L 6Cyl V (3778) Mode Control	MT18547		5.7L 8Cyl V (345) Actuator Motors - (4 Required)	MT18595
ELANTRA, ELANTRA COUPE, ELANTRA GT			13-12	6.4L 8Cyl V (392) Actuator Motors - (4 Required)	MT18595
13	1.8L 4Cyl L (1797) Air Inlet Recirculating - (Blower Housing) - GT Model	MT18549	10-07	3.0L 6Cyl V (182) Actuator Motors - (5 Required)	MT18618
12-11	1.8L 4Cyl L (1797) Air Inlet Recirculating - (Blower Housing)	MT18549	10-05	3.7L 6Cyl V (226) Actuator Motors - (5 Required)	MT18618
	2.0L 4Cyl L (1975) Air Inlet Recirculating - (Blower Housing)	MT18549		4.7L 8Cyl V (285) Actuator Motors - (5 Required)	MT18618
	2.0L 4Cyl L (1975) Air Inlet Recirculating - (Blower Housing)	MT18545		5.7L 8Cyl V (345) Actuator Motors - (5 Required)	MT18618
	2.0L 4Cyl L (1975), Left Mode Control	MT18544	10-06	6.1L 8Cyl V (370) Actuator Motors - (5 Required)	MT18618
	2.0L 4Cyl L (1975), Right Temperature Blend Air Door	MT18544	07	4.7L 8Cyl V (287) Actuator Motors - (5 Required)	MT18618
06-01	2.0L 4Cyl L (1975), Left Mode Control	MT18546	06-05	5.7L 8Cyl V (348) Actuator Motors - (5 Required)	MT18618
	2.0L 4Cyl L (1975), Right Temperature Blend Air Door	MT18548	04	4.0L 6Cyl L (241) Air Inlet Recirculating - (Blower Housing)	MT18502
GENESIS, GENESIS COUPE				4.0L 6Cyl L (241) Heater Door	MT18524
15	3.8L 6Cyl V (3778) Air Inlet Recirculating - (Blower Housing)	MT18549		4.0L 6Cyl L (241) Temperature Blend Air Door	MT18502
	5.0L 8Cyl V (5038) Air Inlet Recirculating - (Blower Housing)	MT18549	04-99	4.0L 6Cyl L (242) Air Inlet Recirculating - (Blower Housing)	MT18502
SANTA FE, SANTA FE XL				4.0L 6Cyl L (242) Heater Door	MT18524
12-10	2.4L 4Cyl L (2359), Main Air Inlet Recirculating - (Blower Housing)	MT18549		4.0L 6Cyl L (242) Temperature Blend Air Door	MT18502
	2.4L 4Cyl L (2359), Main Temperature Blend Air Door	MT18547	(Cont'd)		
	3.5L 6Cyl V (3470), Main Air Inlet Recirculating - (Blower Housing)	MT18549			
	3.5L 6Cyl V (3470), Main Temperature Blend Air Door	MT18547			
09-07	2.7L 6Cyl V (2656), Main Air Inlet Recirculating - (Blower Housing)	MT18544			
	2.7L 6Cyl V (2656), Main Temperature Blend Air Door	MT18547			
	3.3L 6Cyl V (3342), Main Air Inlet Recirculating - (Blower Housing)	MT18544			
	3.3L 6Cyl V (3342), Main Temperature Blend Air Door	MT18547			
SONATA					
10-06	2.4L 4Cyl L (2359), Left Temperature Blend Air Door	MT18547			
	3.3L 6Cyl V (3342), Left Temperature Blend Air Door	MT18547			

JEEP (Con't)			LINCOLN		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR		
Year	Application	Part No.	Year	Application	Part No.
GRAND CHEROKEE (Cont'd)			AVIATOR		
04-02	4.7L 8Cyl V (285) Air Inlet Recirculating - (Blower Housing)	MT18502	05-03	4.6L 8Cyl V (281), Auxiliary Mode Control	MT18508
	4.7L 8Cyl V (285) Heater Door	MT18524		4.6L 8Cyl V (281), Auxiliary Temperature Blend Air Door	MT18554
	4.7L 8Cyl V (285) Temperature Blend Air Door	MT18502		4.6L 8Cyl V (281), Left Main A.T.C. - Mode Door	MT18558
02-99	4.7L 8Cyl V (287) Air Inlet Recirculating - (Blower Housing)	MT18502		4.6L 8Cyl V (281), Left Main Manual A.C. - Mode Door	MT18509
	4.7L 8Cyl V (287) Heater Door	MT18524		4.6L 8Cyl V (281), Right Main A.T.C. - Mode Door	MT18558
	4.7L 8Cyl V (287) Temperature Blend Air Door	MT18502		4.6L 8Cyl V (281), Right Main Manual A.C. - Mode Door	MT18509
98-96	4.0L 6Cyl L (241) Temperature Blend Air Door - Manual A.C.	MT18528	BLACKWOOD		
98-94	4.0L 6Cyl L (242) Temperature Blend Air Door - Manual A.C.	MT18528	02	5.4L 8Cyl V (330) Mode Door - Defroster, Panel, Floor	MT18562
	5.2L 8Cyl V (318) Temperature Blend Air Door - Manual A.C.	MT18528	CONTINENTAL		
98	5.9L 8Cyl V (360) Temperature Blend Air Door - Manual A.C.	MT18528	97-95	4.6L 8Cyl V (281) A.T.C. - Temperature Blend Air Door	MT18593
95	5.2L 8Cyl V (317) Temperature Blend Air Door - Manual A.C.	MT18528	LS		
LIBERTY			06-03	3.9L 8Cyl V (241) Air Inlet Recirculating - (Blower Housing)	MT18576
12-08	3.7L 6Cyl V (226) Actuator Motors - (3 Required)	MT18617		3.9L 8Cyl V (241) Cold Air By-Pass	MT18587
07-02	3.7L 6Cyl V (226) Temperature Blend Air Door	MT18524		3.9L 8Cyl V (241) Floor Air Flow	MT18592
06-05	2.8L 4Cyl L (171) Temperature Blend Air Door	MT18524		3.9L 8Cyl V (241) Panel Control Door	MT18567
05-02	2.4L 4Cyl L (148) Temperature Blend Air Door	MT18524	06-00	3.9L 8Cyl V (242) Air Inlet Recirculating - (Blower Housing)	MT18576
PATRIOT				3.9L 8Cyl V (242) Cold Air By-Pass	MT18587
15-07	2.0L 4Cyl L (122) Actuator Motors - (6 Required)	MT18595		3.9L 8Cyl V (242) Floor Air Flow	MT18592
	2.4L 4Cyl L (144) Actuator Motors - (6 Required)	MT18595		3.9L 8Cyl V (242) Panel Control Door	MT18567
WRANGLER			01-00	3.9L 8Cyl V (241) Air Inlet Recirculating - (Blower Housing)	MT18576
15-12	3.6L 6Cyl V (220) Actuator Motors - (3 Required)	MT18595		3.9L 8Cyl V (241) Cold Air By-Pass	MT18587
11-07	3.8L 6Cyl V (231) Actuator Motors - (3 Required)	MT18595		3.9L 8Cyl V (241) Floor Air Flow	MT18592
KIA				3.9L 8Cyl V (241) Panel Control Door	MT18567
SWITCH HEATER BLEND DOOR ACTUATOR			MARK LT		
Year	Application	Part No.	08-06	5.4L 8Cyl V (330) Air Inlet Recirculating - (Blower Housing)	MT18595
OPTIMA				5.4L 8Cyl V (330), Left Temperature Blend Air Door	MT18510
10-06	2.4L 4Cyl L (2359) Mode Control	MT18547		5.4L 8Cyl V (330), Right Temperature Blend Air Door	MT18510
	2.7L 6Cyl V (2656) Mode Control	MT18547	MARK VII		
06	2.4L 4Cyl L (2351) Mode Control	MT18547	98-97	4.6L 8Cyl V (281) Temperature Blend Air Door	MT18590
SORENTO			MKS		
09-08	3.3L 6Cyl V (3342) Temperature Blend Air Door	MT18547	15-10	3.5L 6Cyl V (213) Air Inlet Recirculating - (Blower Housing)	MT18571
	3.3L 6Cyl V (3342) Vent Control	MT18547		3.5L 6Cyl V (213), Left Temperature Blend Air Door	MT18571
09-07	3.8L 6Cyl V (3778) Temperature Blend Air Door	MT18547		3.5L 6Cyl V (213), Right Temperature Blend Air Door	MT18571
	3.8L 6Cyl V (3778) Vent Control	MT18547	15-09	3.7L 6Cyl V (227) Air Inlet Recirculating - (Blower Housing)	MT18571
06-03	3.5L 6Cyl V (3497) Temperature Blend Air Door	MT18547		3.7L 6Cyl V (227), Left Temperature Blend Air Door	MT18571
	3.5L 6Cyl V (3497) Vent Control	MT18547		3.7L 6Cyl V (227), Right Temperature Blend Air Door	MT18571
LEXUS			MKT		
SWITCH HEATER BLEND DOOR ACTUATOR			15-13	2.0L 4Cyl L (122) Air Inlet Recirculating - (Blower Housing)	MT18571
Year	Application	Part No.		2.0L 4Cyl L (122), Left Temperature Blend Air Door	MT18571
GS300, GS350				2.0L 4Cyl L (122), Right Temperature Blend Air Door	MT18571
05-99	3.0L 6Cyl L (2997) Mode Door	MT18615	15-10	3.5L 6Cyl V (213) Air Inlet Recirculating - (Blower Housing)	MT18571
98	3.0L 6Cyl L (2997) Mode Door - From 07/99	MT18615		3.5L 6Cyl V (213), Left Temperature Blend Air Door	MT18571
GS400, GS430, GS450H				3.5L 6Cyl V (213), Right Temperature Blend Air Door	MT18571
05-01	4.3L 8Cyl V (4293) Mode Door	MT18615		3.7L 6Cyl V (227) Air Inlet Recirculating - (Blower Housing)	MT18571
00-99	4.0L 8Cyl V (3969) Mode Door	MT18615		3.7L 6Cyl V (227), Left Temperature Blend Air Door	MT18571
98	4.0L 8Cyl V (3969) Mode Door - From 07/99	MT18615		3.7L 6Cyl V (227), Right Temperature Blend Air Door	MT18571
GX470			MKZ		
09-03	4.7L 8Cyl V (285), Main Air Inlet Recirculating - (Blower Housing)	MT18605	12-11	2.5L 4Cyl L (152) Air Inlet Recirculating - (Blower Housing)	MT18522
	4.7L 8Cyl V (285), Right Main Damper Blend Door	MT18605	NAVIGATOR		
IS300			14-09	5.4L 8Cyl V (330), Auxiliary Temperature Blend Air Door - 114" Wheel Base	MT18581
05-01	3.0L 6Cyl L (2997) Mode Door	MT18615	14-07	5.4L 8Cyl V (330), Auxiliary Temperature Blend Air Door - 131" Wheel Base	MT18570
RX300, RX330, RX350			14-10	5.4L 8Cyl V (330), Main Air Inlet Recirculating - (Blower Housing)	MT18595
09-07	3.5L 6Cyl V (3456), Right Air Mix - Damper Door - Japan Built	MT18543	14-07	5.4L 8Cyl V (330), Main Mode Door - Defroster, Panel, Floor	MT18569
06-04	3.3L 6Cyl V (202), Left Air Mix - Temperature Door	MT18543	14-09	5.4L 8Cyl V (330), Main Temperature Blend Air Door	MT18551
03-99	3.0L 6Cyl V (2995) Mode Door	MT18615	09	5.4L 8Cyl V (330), Main Air Inlet Recirculating - (Blower Housing) - Before 03/30/2009	MT18595
SC430				5.4L 8Cyl V (330), Main Air Inlet Recirculating - (Blower Housing) - From 03/30/2009	MT18595
10-02	4.3L 8Cyl V (4293), Right Mode Door	MT18615	08-07	5.4L 8Cyl V (330), Auxiliary Temperature Blend Air Door - 114" Wheel Base	MT18508
				5.4L 8Cyl V (330), Main Air Inlet Recirculating - (Blower Housing)	MT18595
				5.4L 8Cyl V (330), Main Temperature Blend Air Door	MT18580
			06-03	5.4L 8Cyl V (330), Auxiliary Mode Door	MT18508
				5.4L 8Cyl V (330), Auxiliary Temperature Blend Air Door	MT18554
				5.4L 8Cyl V (330), Main Mode Door - Defroster, Panel, Floor	MT18509
				5.4L 8Cyl V (330), Main Temperature Blend Air Door	MT18581
			02-00	5.4L 8Cyl V (330), Auxiliary Temperature Blend Air Door	MT18579
			(Cont'd)		

LINCOLN (Con't)			MERCURY (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
NAVIGATOR (Cont'd)			MARINER (Cont'd)		
02-00	5.4L 8Cyl V (330), Main Mode Door - Defroster, Panel, Floor	MT18562	09-08	3.0L 6Cyl V (183), Left A.T.C. - Dual Zone - Temperature Blend Door	MT18550
TOWN CAR			08	3.0L 6Cyl V (183), Right A.T.C. - Dual Zone - Temperature Blend Door	MT18550
11-03	4.6L 8Cyl V (281) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18560	2.3L 4Cyl L (140) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18569	MT18569
	4.6L 8Cyl V (281) A.T.C. - Defroster, Panel, Floor	MT18564	2.3L 4Cyl L (140) A.T.C. - Dual Zone - Defroster, Panel, Floor	MT18569	MT18569
	4.6L 8Cyl V (281) A.T.C. - Defroster Door	MT18567	2.3L 4Cyl L (140) Air Inlet Recirculating - (Blower Housing) - Manual A.C.	MT18595	MT18595
	4.6L 8Cyl V (281) A.T.C. - Temperature Blend Air Door	MT18560	2.3L 4Cyl L (140) Mode Door - Defroster, Panel, Floor - Manual A.C.	MT18569	MT18569
02-98	4.6L 8Cyl V (281) A.T.C. - Blend Air Door - No. 1	MT18565	2.3L 4Cyl L (140) Temperature Blend Air Door - Manual A.C.	MT18550	MT18550
97-95	4.6L 8Cyl V (281) A.T.C. - Blend Air Door	MT18555	2.3L 4Cyl L (140), Left A.T.C. - Dual Zone - Temperature Blend Door	MT18550	MT18550
97-91	4.6L 8Cyl V (281) Manual A.C. - Blend Air Door	MT18594	2.3L 4Cyl L (140), Right A.T.C. - Dual Zone - Temperature Blend Door	MT18550	MT18550
94-91	4.6L 8Cyl V (281) A.T.C. - Blend Air Door	MT18561	MILAN		
ZEPHYR			11-10	2.5L 4Cyl L (152) Air Inlet Recirculating - (Blower Housing) - A.T.C.	MT18522
06	3.0L 6Cyl V (181) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18526	09-06	2.3L 4Cyl L (140) Temperature Blend Air Door - A.T.C.	MT18614
	3.0L 6Cyl V (181) A.T.C. - Temperature Blend Air Door	MT18526	2.3L 4Cyl L (140) Temperature Blend Air Door - Manual A.C.	MT18614	MT18614
	3.0L 6Cyl V (181) Manual A.C. - Temperature Blend Air Door	MT18614	3.0L 6Cyl V (181) Temperature Blend Air Door - A.T.C.	MT18614	MT18614
	3.0L 6Cyl V (183) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18526	3.0L 6Cyl V (181) Temperature Blend Air Door - Manual A.C.	MT18614	MT18614
	3.0L 6Cyl V (183) A.T.C. - Temperature Blend Air Door	MT18526	08	3.0L 6Cyl V (183) Temperature Blend Air Door - A.T.C.	MT18614
	3.0L 6Cyl V (183) Manual A.C. - Temperature Blend Air Door	MT18614	3.0L 6Cyl V (183) Temperature Blend Air Door - Manual A.C.	MT18614	MT18614
MERCURY			MONTEGO		
SWITCH HEATER BLEND DOOR ACTUATOR			07-06	3.0L 6Cyl V (181) Actuator Motor - Manual A.C. - No. 1	MT18570
Year	Application	Part No.	05	3.0L 6Cyl V (183) Actuator Motor - Manual A.C. - No. 1	MT18570
COUGAR			3.0L 6Cyl V (181) Actuator Motor - Manual A.C. - No. 2	MT18570	MT18570
02-99	2.0L 4Cyl L (121) Temperature Blend Air Door	MT18591	3.0L 6Cyl V (183) Actuator Motor - Manual A.C. - No. 2	MT18570	MT18570
	2.5L 6Cyl V (155) Temperature Blend Air Door	MT18591	MONTEREY		
97-96	3.8L 6Cyl V (232) Temperature Blend Air Door - Manual A.C.	MT18579	07-04	4.2L 6Cyl V (256), Auxiliary Air Inlet Recirculating - (Blower Housing)	MT18510
	4.6L 8Cyl V (281) Temperature Blend Air Door - Manual A.C.	MT18579	4.2L 6Cyl V (256), Main Air Inlet Recirculating - (Blower Housing)	MT18595	MT18595
GRAND MARQUIS			4.2L 6Cyl V (256), Main Mode Door	MT18583	MT18583
11-98	4.6L 8Cyl V (281) Blend Door - A.T.C.	MT18561	MOUNTAINEER		
11-92	4.6L 8Cyl V (281) Blend Door - Manual A.C.	MT18594	10-02	4.0L 6Cyl V (245), Auxiliary Mode Door	MT18508
97-95	4.6L 8Cyl V (281) Blend Door - A.T.C.	MT18555	4.0L 6Cyl V (245), Auxiliary Temperature Blend Air Door	MT18554	MT18554
94-92	4.6L 8Cyl V (281) Blend Door - A.T.C.	MT18561	4.0L 6Cyl V (245), Left Main Mode Door - A.T.C.	MT18558	MT18558
MARAUDER			4.0L 6Cyl V (245), Left Main Mode Door - Manual A.C.	MT18509	MT18509
04-03	4.6L 8Cyl V (281) Blend Door - A.T.C.	MT18561	4.0L 6Cyl V (245), Right Main Mode Door - A.T.C.	MT18558	MT18558
	4.6L 8Cyl V (281) Blend Door - Manual A.C.	MT18594	4.0L 6Cyl V (245), Right Main Mode Door - Manual A.C.	MT18509	MT18509
MARINER			4.6L 8Cyl V (281), Auxiliary Mode Door	MT18508	MT18508
11-09	2.5L 4Cyl L (152) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18569	4.6L 8Cyl V (281), Auxiliary Temperature Blend Air Door	MT18554	MT18554
	2.5L 4Cyl L (152) A.T.C. - Dual Zone - Defroster, Panel, Floor	MT18569	4.6L 8Cyl V (281), Left Main Mode Door - A.T.C.	MT18558	MT18558
	2.5L 4Cyl L (152) Air Inlet Recirculating - (Blower Housing) - Manual A.C.	MT18595	4.6L 8Cyl V (281), Left Main Mode Door - Manual A.C.	MT18509	MT18509
	2.5L 4Cyl L (152) Mode Door - Defroster, Panel, Floor - Manual A.C.	MT18569	4.6L 8Cyl V (281), Right Main Mode Door - A.T.C.	MT18558	MT18558
	2.5L 4Cyl L (152) Temperature Blend Air Door - Manual A.C.	MT18550	4.6L 8Cyl V (281), Right Main Mode Door - Manual A.C.	MT18509	MT18509
	2.5L 4Cyl L (152), Left A.T.C. - Dual Zone - Temperature Blend Door	MT18550	02	4.6L 8Cyl V (281), Auxiliary Temperature Blend Air Door	MT18554
	2.5L 4Cyl L (152), Right A.T.C. - Dual Zone - Temperature Blend Door	MT18550	01-98	4.0L 6Cyl V (245), Main Blend Door - A.T.C.	MT18553
	3.0L 6Cyl V (181) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18569	4.0L 6Cyl V (245), Main Blend Door - with Auxiliary Console A.C.	MT18585	MT18585
	3.0L 6Cyl V (181) A.T.C. - Dual Zone - Defroster, Panel, Floor	MT18569	5.0L 8Cyl V (302), Main Blend Door - A.T.C.	MT18553	MT18553
	3.0L 6Cyl V (181) Air Inlet Recirculating - (Blower Housing) - Manual A.C.	MT18595	01-97	5.0L 8Cyl V (302), Main Blend Door - with Auxiliary Console A.C.	MT18585
	3.0L 6Cyl V (181) Mode Door - Defroster, Panel, Floor - Manual A.C.	MT18569	97	5.0L 8Cyl V (302), Main Blend Door - A.T.C.	MT18563
	3.0L 6Cyl V (181) Temperature Blend Air Door - Manual A.C.	MT18550	MYSTIQUE		
	3.0L 6Cyl V (181), Left A.T.C. - Dual Zone - Temperature Blend Door	MT18550	00-95	2.0L 4Cyl L (121) Mode Door	MT18591
	3.0L 6Cyl V (181), Right A.T.C. - Dual Zone - Temperature Blend Door	MT18550	2.5L 6Cyl V (155) Mode Door	MT18591	MT18591
09-08	3.0L 6Cyl V (183) A.T.C. - Dual Zone - Air Inlet Recirculating - (Blower Housing)	MT18569	SABLE		
	3.0L 6Cyl V (183) A.T.C. - Dual Zone - Defroster, Panel, Floor	MT18569	09-08	3.5L 6Cyl V (213) Air Inlet Recirculating - (Blower Housing) - A.T.C.	MT18570
	3.0L 6Cyl V (183) Air Inlet Recirculating - (Blower Housing) - Manual A.C.	MT18595	3.5L 6Cyl V (213) Air Inlet Recirculating - (Blower Housing) - Manual A.C.	MT18570	MT18570
	3.0L 6Cyl V (183) Mode Door - Defroster, Panel, Floor - Manual A.C.	MT18569	3.5L 6Cyl V (213), Left Temperature Blend Air Door	MT18571	MT18571
	3.0L 6Cyl V (183) Temperature Blend Air Door - Manual A.C.	MT18550	3.5L 6Cyl V (213), Right Temperature Blend Air Door	MT18571	MT18571
(Cont'd)			05	3.0L 6Cyl V (181) Air Inlet Recirculating - (Blower Housing) - A.T.C.	MT18570
			3.0L 6Cyl V (181) Air Inlet Recirculating - (Blower Housing) - Manual A.C.	MT18570	MT18570
			05-97	3.0L 6Cyl V (181) Mode Door - A.T.C.	MT18558
			3.0L 6Cyl V (181) Mode Door - Manual A.C.	MT18557	MT18557
			(Cont'd)		

MERCURY (Con't)			OLDSMOBILE (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
SABLE (Cont'd)			INTRIGUE (Cont'd)		
05	3.0L 6Cyl V (182) Air Inlet Recirculating - (Blower Housing) - A.T.C.	MT18570	99-98	3.8L 6Cyl V (231) A.T.C. - Temperature Blend Air Door - Electric	MT1800
	3.0L 6Cyl V (182) Air Inlet Recirculating - (Blower Housing) - Manual A.C.	MT18570		3.8L 6Cyl V (231) Manual A.C. - Temperature Blend Air Door - Electric Actuator	MT18524
05-97	3.0L 6Cyl V (182) Mode Door - A.T.C.	MT18558	LSS		
	3.0L 6Cyl V (182) Mode Door - Manual A.C.	MT18557	99-96	3.8L 6Cyl V (231) Temperature Blend Air Door - Electric Actuator - (with Lever)	MT18514
95-91	3.0L 6Cyl V (182) Mode Door - A.T.C.	MT18588	REGENCY		
	3.0L 6Cyl V (182) Mode Door - Manual A.C.	MT18586	98-97	3.8L 6Cyl V (231) Temperature Blend Air Door - Electric Actuator - (with Lever)	MT18514
OLDSMOBILE			SILHOUETTE		
SWITCH HEATER BLEND DOOR ACTUATOR			04-01	3.4L 6Cyl V (207), Auxiliary Temperature Blend Air Door	MT18525
Year	Application	Part No.		3.4L 6Cyl V (207), Left Auxiliary Temperature Blend Air Door	MT18527
88				3.4L 6Cyl V (207), Main Mode Door	MT18529
99-92	3.8L 6Cyl V (231) Temperature Blend Air Door - Electric Actuator - (with Lever)	MT18514		3.4L 6Cyl V (207), Main Temperature Blend Air Door	MT18524
98			96	3.4L 6Cyl V (207) Temperature Blend Air Door - Electric Actuator	MT18503
96-94	3.8L 6Cyl V (231) Temperature Blend Air Door - Electric Actuator - (with Lever)	MT18514	95-93	3.8L 6Cyl V (231) Temperature Blend Air Door - Electric Actuator	MT18503
ALERO			94-93	3.1L 6Cyl V (189) Temperature Blend Air Door - Electric Actuator	MT18503
04-02	2.2L 4Cyl L (134) Temperature Blend Air Door - Electric Actuator	MT18524	PONTIAC		
04-99	3.4L 6Cyl V (207) Temperature Blend Air Door - Electric Actuator	MT18524	SWITCH HEATER BLEND DOOR ACTUATOR		
01-99	2.4L 4Cyl L (146) Temperature Blend Air Door - Electric Actuator	MT18524	Year	Application	Part No.
AURORA			AZTEK		
03-01	4.0L 8Cyl V (244) Air Inlet Recirculating - (Blower Housing)	MT1800	05-01	3.4L 6Cyl V (204), Auxiliary Temperature Blend Air Door	MT18525
	4.0L 8Cyl V (244), Left Temperature Blend Air Door	MT1809		3.4L 6Cyl V (204), Left Auxiliary Temperature Blend Air Door	MT18527
	4.0L 8Cyl V (244), Right Temperature Blend Air Door	MT1800		3.4L 6Cyl V (204), Main Mode Door	MT18529
02-01	3.5L 6Cyl V (214) Air Inlet Recirculating - (Blower Housing)	MT1800		3.4L 6Cyl V (204), Main Temperature Blend Air Door	MT18524
	3.5L 6Cyl V (214), Left Temperature Blend Air Door	MT1809		3.4L 6Cyl V (207), Auxiliary Temperature Blend Air Door	MT18525
	3.5L 6Cyl V (214), Right Temperature Blend Air Door	MT1800		3.4L 6Cyl V (207), Left Auxiliary Temperature Blend Air Door	MT18527
99-95	4.0L 8Cyl V (244) Air Inlet Recirculating - (Blower Housing)	MT1800		3.4L 6Cyl V (207), Main Mode Door	MT18529
	4.0L 8Cyl V (244), Left Temperature Blend Air Door	MT1809		3.4L 6Cyl V (207), Main Temperature Blend Air Door	MT18524
	4.0L 8Cyl V (244), Right Temperature Blend Air Door	MT1800	BONNEVILLE		
BRAVADA			05-00	3.8L 6Cyl V (231) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800
04-02	4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1809		3.8L 6Cyl V (231) A.T.C. - Mode Door	MT18614
	4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521		3.8L 6Cyl V (231) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT1800
	4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612		3.8L 6Cyl V (231) Manual A.C. - Mode Door	MT18530
	4.2L 6Cyl L (256), Main Mode Door - with Rear A.C.	MT18515		3.8L 6Cyl V (231) Manual A.C. - Temperature Blend Air Door	MT18530
	4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1800		3.8L 6Cyl V (231), Left A.T.C. - Temperature Blend Air Door	MT1809
	4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521		3.8L 6Cyl V (231), Right A.T.C. - Temperature Blend Air Door - (2 Required)	MT1800
	4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - with Rear A.C.	MT18527	05-04	4.6L 8Cyl V (281) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT1800
02	4.2L 6Cyl L (256), Main Mode Door - without Rear A.C.	MT18515		4.6L 8Cyl V (281) A.T.C. - Mode Door	MT18614
01-96	4.3L 6Cyl V (262), Upper Temperature Blend Air Door - Electric Actuator - Electronic Controls	MT1800		4.6L 8Cyl V (281) Manual A.C. - Air Inlet Recirculating - (Blower Housing)	MT1800
	4.3L 6Cyl V (262), Upper Temperature Blend Air Door - Electric Actuator - Manual Controls	MT18503		4.6L 8Cyl V (281) Manual A.C. - Mode Door	MT18530
94	4.3L 6Cyl V (262), Upper Temperature Blend Air Door - Electric Actuator - Electronic Controls	MT1800		4.6L 8Cyl V (281) Manual A.C. - Temperature Blend Air Door	MT18530
	4.3L 6Cyl V (262), Upper Temperature Blend Air Door - Electric Actuator - Manual Controls	MT18503		4.6L 8Cyl V (281), Left A.T.C. - Temperature Blend Air Door	MT1809
				4.6L 8Cyl V (281), Right A.T.C. - Temperature Blend Air Door - (2 Required)	MT1800
CUTLASS			99-94	3.8L 6Cyl V (231) Temperature Blend Air Door - Electric Actuator - (with Lever)	MT18514
99-97	3.1L 6Cyl V (189) Temperature Blend Air Door - Electric Actuator	MT18524	G5		
CUTLASS SUPREME			10-07	2.2L 4Cyl L (134) Temperature Blend Air Door	MT18614
97-94	3.1L 6Cyl V (189) Temperature Blend Air Door - Electric Actuator - (Code 3982) - A.T.C.	MT1800	08-07	2.4L 4Cyl L (145) Temperature Blend Air Door	MT18614
	3.1L 6Cyl V (189) Temperature Blend Air Door - Electric Actuator - (Code 4932) - Manual A.C.	MT18512		2.4L 4Cyl L (146) Temperature Blend Air Door	MT18614
96-94	3.4L 6Cyl V (207) Temperature Blend Air Door - Electric Actuator - (Code 3982) - A.T.C.	MT1800	G6		
	3.4L 6Cyl V (207) Temperature Blend Air Door - Electric Actuator - (Code 4932) - Manual A.C.	MT18512	10-06	2.4L 4Cyl L (145) A.T.C. - Temperature Blend Air Door	MT18522
				2.4L 4Cyl L (145) Manual A.C. - Temperature Blend Air Door	MT18522
			10-05	3.5L 6Cyl V (213) A.T.C. - Temperature Blend Air Door	MT18522
				3.5L 6Cyl V (213) Manual A.C. - Temperature Blend Air Door	MT18522
			09-07	3.6L 6Cyl V (217) A.T.C. - Temperature Blend Air Door	MT18522
				3.6L 6Cyl V (217) Manual A.C. - Temperature Blend Air Door	MT18522
			09-06	3.9L 6Cyl V (237) A.T.C. - Temperature Blend Air Door	MT18522
				3.9L 6Cyl V (237) Manual A.C. - Temperature Blend Air Door	MT18522
			06	3.5L 6Cyl V (214) A.T.C. - Temperature Blend Air Door	MT18522
				3.5L 6Cyl V (214) Manual A.C. - Temperature Blend Air Door	MT18522
			05	3.5L 6Cyl V (211) A.T.C. - Temperature Blend Air Door	MT18522
INTRIGUE			(Cont'd)		
02-99	3.5L 6Cyl V (214) A.T.C. - Temperature Blend Air Door - Electric	MT1800			
	3.5L 6Cyl V (214) Manual A.C. - Temperature Blend Air Door - Electric Actuator	MT18524			
(Cont'd)					

PONTIAC (Con't)			SAAB (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
G6 (Cont'd)			9-7X (Cont'd)		
05	3.5L 6Cyl V (211) Manual A.C. - Temperature Blend Air Door	MT18522	09-05	4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521
G8				4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - with Rear A.C.	MT18527
09-08	3.6L 6Cyl V (217) A.T.C. - Mode Door	MT18542		5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1809
	3.6L 6Cyl V (217) Manual A.C. - Mode Door	MT18611		5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521
	3.6L 6Cyl V (217) Mode Door - Fresh Air-Recirculation	MT18610		5.3L 8Cyl V (325), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612
	6.0L 8Cyl V (364) A.T.C. - Mode Door	MT18542		5.3L 8Cyl V (325), Main Mode Door - with Rear A.C.	MT18515
	6.0L 8Cyl V (364) Manual A.C. - Mode Door	MT18611		5.3L 8Cyl V (325), Right Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1800
	6.0L 8Cyl V (364) Mode Door - Fresh Air-Recirculation	MT18610		5.3L 8Cyl V (325), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521
09	6.2L 8Cyl V (376) A.T.C. - Mode Door	MT18542	09-08	6.0L 8Cyl V (364), Left Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1809
	6.2L 8Cyl V (376) Manual A.C. - Mode Door	MT18611		6.0L 8Cyl V (364), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521
	6.2L 8Cyl V (376) Mode Door - Fresh Air-Recirculation	MT18610		6.0L 8Cyl V (364), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612
MONTANA				6.0L 8Cyl V (364), Main Mode Door - with Rear A.C.	MT18515
09-06	3.9L 6Cyl V (237), Main Air Inlet Recirculating - (Blower Housing)	MT18595		6.0L 8Cyl V (364), Right Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1800
	3.9L 6Cyl V (237), Main Defroster Door	MT18595		6.0L 8Cyl V (364), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521
	3.9L 6Cyl V (237), Main Mode Door	MT18595		6.0L 8Cyl V (364), Right Main Temperature Blend Air Door - with Rear A.C.	MT18527
06	3.9L 6Cyl V (237), Main Temperature Blend Air Door	MT18595		6.0L 8Cyl V (364), Left Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1809
	3.5L 6Cyl V (213), Main Air Inlet Recirculating - (Blower Housing)	MT18595		6.0L 8Cyl V (364), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521
	3.5L 6Cyl V (213), Main Defroster Door	MT18595		6.0L 8Cyl V (364), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612
	3.5L 6Cyl V (213), Main Mode Door	MT18595		6.0L 8Cyl V (364), Main Mode Door - with Rear A.C.	MT18515
	3.5L 6Cyl V (213), Main Temperature Blend Air Door	MT18595		6.0L 8Cyl V (364), Right Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1800
05-01	3.4L 6Cyl V (207), Auxiliary Temperature Blend Air Door	MT18525		6.0L 8Cyl V (364), Right Main Temperature Blend Air Door - with Rear A.C.	MT18521
	3.4L 6Cyl V (207), Main Mode Door	MT18529		6.0L 8Cyl V (364), Right Main Temperature Blend Air Door - with Rear A.C.	MT18527
	3.4L 6Cyl V (207), Main Temperature Blend Air Door	MT18524			
05	3.5L 6Cyl V (213), Auxiliary Temperature Blend Air Door	MT18525	SATURN		
	3.5L 6Cyl V (213), Main Mode Door	MT18529	SWITCH HEATER BLEND DOOR ACTUATOR		
	3.5L 6Cyl V (213), Main Temperature Blend Air Door	MT18524	Year Application Part No.		
PURSUIT			OUTLOOK		
06-05	2.2L 4Cyl L (134) Temperature Blend Air Door	MT18614	10-07	3.6L 6Cyl V (217), Main Air Inlet Recirculating - (Blower Housing)	MT18531
06	2.4L 4Cyl L (145) Temperature Blend Air Door	MT18614		3.6L 6Cyl V (217), Main Mode Door	MT18522
TRANS SPORT				3.6L 6Cyl V (217), Main Temperature Blend Air Door	MT18522
96	3.4L 6Cyl V (207) Temperature Blend Air Door - Electric Actuator	MT18503	VUE		
95-94	3.1L 6Cyl V (189) Temperature Blend Air Door - Electric Actuator	MT18503	07-02	2.2L 4Cyl L (134) Air Inlet Recirculating - (Blower Housing)	MT18526
	3.8L 6Cyl V (231) Temperature Blend Air Door - Electric Actuator	MT18503	07	2.4L 4Cyl L (145) Air Inlet Recirculating - (Blower Housing)	MT18526
VIBE			07-06	3.5L 6Cyl V (3471) Air Inlet Recirculating - (Blower Housing)	MT18526
10-09	1.8L 4Cyl L (1798) Air Inlet Recirculating - (Blower Housing)	MT18609	05-04	3.5L 6Cyl V (3474) Air Inlet Recirculating - (Blower Housing)	MT18526
	2.4L 4Cyl L (2362) Air Inlet Recirculating - (Blower Housing)	MT18609	04	3.5L 6Cyl V (3475) Air Inlet Recirculating - (Blower Housing)	MT18526
RAM			TOYOTA		
SWITCH HEATER BLEND DOOR ACTUATOR			SWITCH HEATER BLEND DOOR ACTUATOR		
Year	Application	Part No.	Year	Application	Part No.
1500, 2500, 3500			4RUNNER		
15-14	3.0L 6Cyl V (182) Actuator Motors - (4 Required)	MT18595	09-03	4.0L 6Cyl V (241) Air Inlet Recirculating - (Blower Housing)	MT18605
15-13	3.6L 6Cyl V (220) Actuator Motors - (4 Required)	MT18595	09-05	4.0L 6Cyl V (241), Left Servo Damper - Mode Door - Sport, SR5 Model	MT18605
15-11	5.7L 8Cyl V (345) Actuator Motors - (4 Required)	MT18595	09-03	4.0L 6Cyl V (241), Right Servo Damper - Mode Door	MT18605
15-14	6.4L 8Cyl V (392) Actuator Motors - (4 Required)	MT18595		4.7L 8Cyl V (285) Air Inlet Recirculating - (Blower Housing)	MT18605
15-11	6.7L 6Cyl L (408) Actuator Motors - (4 Required)	MT18595	09-05	4.7L 8Cyl V (285), Left Servo Damper - Mode Door - Sport, SR5 Model	MT18605
13-11	3.7L 6Cyl V (226) Actuator Motors - (4 Required)	MT18595		4.7L 8Cyl V (285), Right Servo Damper - Mode Door	MT18605
	4.7L 8Cyl V (285) Actuator Motors - (4 Required)	MT18595	09-03	4.7L 8Cyl V (285), Right Servo Damper - Mode Door	MT18605
	4.7L 8Cyl V (287) Actuator Motors - (4 Required)	MT18595	05-03	4.7L 8Cyl V (284) Air Inlet Recirculating - (Blower Housing)	MT18605
12-11	6.7L 6Cyl L (409) Actuator Motors - (4 Required)	MT18595	05	4.7L 8Cyl V (284), Left Servo Damper - Mode Door - Sport, SR5 Model	MT18605
DAKOTA			05-03	4.7L 8Cyl V (284), Right Servo Damper - Mode Door	MT18605
11	3.7L 6Cyl V (226) Actuator Motors - (2 Required)	MT18595	04-03	4.0L 6Cyl V (241), Left Servo Damper - Mode Door - Base, Sport, SR5 Model	MT18605
	4.7L 8Cyl V (285) Actuator Motors - (2 Required)	MT18595		4.7L 8Cyl V (284), Left Servo Damper - Mode Door - Base, Sport, SR5 Model	MT18605
SAAB				4.7L 8Cyl V (285), Left Servo Damper - Mode Door - Base, Sport, SR5 Model	MT18605
SWITCH HEATER BLEND DOOR ACTUATOR			CAMRY		
Year	Application	Part No.	Year	Application	Part No.
9-7X			06-02	2.4L 4Cyl L (144) Air Inlet Recirculating - (Blower Housing) - LE, SE Model	MT18596
09-05	4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1809		2.4L 4Cyl L (2362) Air Inlet Recirculating - (Blower Housing) - LE, SE Model	MT18596
	4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - with Rear A.C.	MT18521			
	4.2L 6Cyl L (256), Left Main Temperature Blend Air Door - with Rear A.C.	MT18612			
	4.2L 6Cyl L (256), Main Mode Door - with Rear A.C.	MT18515			
	4.2L 6Cyl L (256), Right Main Temperature Blend Air Door - without Rear A.C. - (2 Required)	MT1800			
(Cont'd)			(Cont'd)		































TOYOTA (Con't)			TOYOTA (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)			SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.	Year	Application	Part No.
CAMRY (Cont'd)			SIENNA		
06-05	3.0L 6Cyl V (183) Air Inlet Recirculating - (Blower Housing) - LE, SE Model	MT18596	10-07	3.5L 6Cyl V (214), Main Air Inlet Recirculating - (Blower Housing) - Manual A.C.	MT18609
06-02	3.0L 6Cyl V (2995) Air Inlet Recirculating - (Blower Housing) - LE, SE Model	MT18596		3.5L 6Cyl V (3456), Main Air Inlet Recirculating - (Blower Housing) - Manual A.C.	MT18609
06-05	3.3L 6Cyl V (202) Air Inlet Recirculating - (Blower Housing) - LE, SE Model	MT18596	06-04	3.3L 6Cyl V (202), Main Air Inlet Recirculating - (Blower Housing) - CE, LE Model	MT18609
04	3.3L 6Cyl V (3300) Air Inlet Recirculating - (Blower Housing) - LE, SE Model	MT18596	SOLARA		
02	3.0L 6Cyl V (183) Air Inlet Recirculating - (Blower Housing) - LE, SE Model	MT18596	08-04	2.4L 4Cyl L (2362) Air Inlet Recirculating - (Blower Housing) - Exc. SLE Model	MT18596
COROLLA			08-05	3.3L 6Cyl V (202) Air Inlet Recirculating - (Blower Housing) - Exc. SLE Model	MT18596
13-10	1.8L 4Cyl L (109) Air Inlet Recirculating - (Blower Housing) - Manual A.C. - Japan Built	MT18609	04	3.3L 6Cyl V (3300) Air Inlet Recirculating - (Blower Housing) - Exc. SLE Model	MT18596
	1.8L 4Cyl L (109) Air Inlet Recirculating - (Blower Housing) - Manual A.C. - USA Built	MT18609	VOLKSWAGEN		
	1.8L 4Cyl L (110) Air Inlet Recirculating - (Blower Housing) - Manual A.C. - Japan Built	MT18609	SWITCH HEATER BLEND DOOR ACTUATOR		
	1.8L 4Cyl L (110) Air Inlet Recirculating - (Blower Housing) - Manual A.C. - USA Built	MT18609	Year	Application	Part No.
13-09	1.8L 4Cyl L (1798) Air Inlet Recirculating - (Blower Housing) - Manual A.C. - Japan Built	MT18609	BEETLE, BEETLE CABRIO		
	1.8L 4Cyl L (1798) Air Inlet Recirculating - (Blower Housing) - Manual A.C. - USA Built	MT18609	10-98	2.0L 4Cyl L (121) Adjuster Motor - Manual A.C.	MT18535
13-10	2.4L 4Cyl L (146) Air Inlet Recirculating - (Blower Housing) - Manual A.C. - Japan Built	MT18609	10-06	2.5L 5Cyl L (151) Adjuster Motor - Manual A.C.	MT18535
	2.4L 4Cyl L (146) Air Inlet Recirculating - (Blower Housing) - Manual A.C. - USA Built	MT18609	06-98	1.9L 4Cyl L (116) Adjuster Motor - Manual A.C.	MT18535
12-09	2.4L 4Cyl L (2362) Air Inlet Recirculating - (Blower Housing) - Manual A.C. - Japan Built	MT18609	05-99	1.8L 4Cyl L (1781) Adjuster Motor - Manual A.C.	MT18535
	2.4L 4Cyl L (2362) Air Inlet Recirculating - (Blower Housing) - Manual A.C. - USA Built	MT18609	GOLF, GOLF CITY, GOLF SPORTWAGEN, JETTA, JETTA CITY		
09	1.8L 4Cyl L (1794) Air Inlet Recirculating - (Blower Housing) - Manual A.C. - Japan Built	MT18609	06-00	1.8L 4Cyl L (1781) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18532
	1.8L 4Cyl L (1794) Air Inlet Recirculating - (Blower Housing) - Manual A.C. - USA Built	MT18609		1.8L 4Cyl L (1781) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18540
02-98	1.8L 4Cyl L (1794) Air Inlet Recirculating - (Blower Housing)	MT18596	06-99	1.8L 4Cyl L (1781) A.T.C. - Defroster Door	MT18539
FJ CRUISER				1.8L 4Cyl L (1781) A.T.C. - Temperature Blend Air Door	MT18538
14-07	4.0L 6Cyl V (241) Air Inlet Recirculating - (Blower Housing)	MT18596		1.8L 4Cyl L (1781) Manual A.C. - Adjuster Motor	MT18535
	4.0L 6Cyl V (241) Servo Damper - Mode Door	MT18605		1.9L 4Cyl L (116) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18532
11-08	4.0L 6Cyl V (244) Air Inlet Recirculating - (Blower Housing)	MT18596		1.9L 4Cyl L (116) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18540
	4.0L 6Cyl V (244) Servo Damper - Mode Door	MT18605		1.9L 4Cyl L (116) A.T.C. - Defroster Door	MT18539
HIGHLANDER				1.9L 4Cyl L (116) A.T.C. - Temperature Blend Air Door	MT18538
07-04	2.4L 4Cyl L (2362), Main Servo Damper - Temperature Blend Door	MT18543		1.9L 4Cyl L (116) Manual A.C. - Adjuster Motor	MT18535
07-05	3.3L 6Cyl V (202), Main Servo Damper - Temperature Blend Door	MT18543		2.0L 4Cyl L (121) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18532
04	3.3L 6Cyl V (3300), Main Servo Damper - Temperature Blend Door	MT18543		2.0L 4Cyl L (121) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18540
MATRIX				2.0L 4Cyl L (121) A.T.C. - Defroster Door	MT18539
14-09	1.8L 4Cyl L (1798) Air Inlet Recirculating - (Blower Housing)	MT18609		2.0L 4Cyl L (121) A.T.C. - Temperature Blend Air Door	MT18538
13-09	2.4L 4Cyl L (2362) Air Inlet Recirculating - (Blower Housing)	MT18609		2.0L 4Cyl L (121) Manual A.C. - Adjuster Motor	MT18535
10	1.8L 4Cyl L (110) Air Inlet Recirculating - (Blower Housing)	MT18609	05	1.8L 4Cyl L (1781) A.T.C. - Defroster Door	MT18536
	2.4L 4Cyl L (144) Air Inlet Recirculating - (Blower Housing)	MT18609		1.8L 4Cyl L (1781) A.T.C. - Temperature Blend Air Door - No. 1	MT18540
RAV5				1.8L 4Cyl L (1781) A.T.C. - Temperature Blend Air Door - No. 2	MT18537
15-09	2.5L 4Cyl L (152) Air Inlet Recirculating - (Blower Housing) - Base or Sport Model	MT18609		1.9L 4Cyl L (116) A.T.C. - Defroster Door	MT18536
15-10	2.5L 4Cyl L (153) Air Inlet Recirculating - (Blower Housing) - Base or Sport Model	MT18609		1.9L 4Cyl L (116) A.T.C. - Temperature Blend Air Door - No. 1	MT18540
14-12	-L -Cyl - (-) Air Inlet Recirculating - (Blower Housing) - Base or Sport Model	MT18609		1.9L 4Cyl L (116) A.T.C. - Temperature Blend Air Door - No. 2	MT18537
12-10	3.5L 6Cyl V (214) Air Inlet Recirculating - (Blower Housing) - Base or Sport Model	MT18609		2.0L 4Cyl L (121) A.T.C. - Defroster Door	MT18536
12-06	3.5L 6Cyl V (3456) Air Inlet Recirculating - (Blower Housing) - Base or Sport Model	MT18609		2.0L 4Cyl L (121) A.T.C. - Temperature Blend Air Door - No. 1	MT18540
08-06	2.4L 4Cyl L (146) Air Inlet Recirculating - (Blower Housing) - Base or Sport Model	MT18609		2.0L 4Cyl L (121) A.T.C. - Temperature Blend Air Door - No. 2	MT18537
	2.4L 4Cyl L (2362) Air Inlet Recirculating - (Blower Housing) - Base or Sport Model	MT18609		2.5L 5Cyl L (151) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18532
05-04	2.4L 4Cyl L (146) Air Inlet Recirculating - (Blower Housing)	MT18596		2.5L 5Cyl L (151) A.T.C. - Defroster Door	MT18536
	2.4L 4Cyl L (2362) Air Inlet Recirculating - (Blower Housing)	MT18596		2.5L 5Cyl L (151) A.T.C. - Temperature Blend Air Door - No. 1	MT18537
03-01	2.0L 4Cyl L (122) Air Inlet Recirculating - (Blower Housing)	MT18596		2.5L 5Cyl L (151) A.T.C. - Temperature Blend Air Door - No. 2	MT18540
	-L -Cyl - (-) Air Inlet Recirculating - (Blower Housing)	MT18596		2.5L 5Cyl L (151) Manual A.C. - Adjuster Motor	MT18535
(Cont'd)			05-99	2.8L 6Cyl V (2792) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18532
				2.8L 6Cyl V (2792) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18540
				2.8L 6Cyl V (2792) A.T.C. - Defroster Door	MT18539
				2.8L 6Cyl V (2792) A.T.C. - Temperature Blend Air Door	MT18538
				2.8L 6Cyl V (2792) Manual A.C. - Adjuster Motor	MT18535
			04-99	1.8L 4Cyl L (1781) A.T.C. - Adjuster Motor	MT18532
				1.8L 4Cyl L (1781) A.T.C. - Air Inlet Recirculating - (Blower Housing) - (Vent Control)	MT18540
				1.9L 4Cyl L (116) A.T.C. - Adjuster Motor	MT18532

VOLKSWAGEN (Con't)		
SWITCH HEATER BLEND DOOR ACTUATOR (Cont'd)		
Year	Application	Part No.
GOLF, GOLF CITY, GOLF SPORTWAGEN, JETTA, JETTA CITY (Cont'd)		
04-99	1.9L 4Cyl L (116) A.T.C. - Air Inlet Recirculating - (Blower Housing) - (Vent Control)	MT18540
	2.0L 4Cyl L (121) A.T.C. - Adjuster Motor	MT18532
	2.0L 4Cyl L (121) A.T.C. - Air Inlet Recirculating - (Blower Housing) - (Vent Control)	MT18540
	2.8L 6Cyl V (2792) A.T.C. - Adjuster Motor	MT18532
	2.8L 6Cyl V (2792) A.T.C. - Air Inlet Recirculating - (Blower Housing) - (Vent Control)	MT18540
04	3.2L 6Cyl V (3189) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18532
	3.2L 6Cyl V (3189) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18540
	3.2L 6Cyl V (3189) A.T.C. - Defroster Door	MT18539
	3.2L 6Cyl V (3189) A.T.C. - Temperature Blend Air Door	MT18538
	3.2L 6Cyl V (3189) Manual A.C. - Adjuster Motor	MT18535
03	3.2L 6Cyl V (195) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18532
	3.2L 6Cyl V (195) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18540
	3.2L 6Cyl V (195) A.T.C. - Defroster Door	MT18539
	3.2L 6Cyl V (195) A.T.C. - Temperature Blend Air Door	MT18538
	3.2L 6Cyl V (195) Manual A.C. - Adjuster Motor	MT18535
99	1.8L 4Cyl L (109) A.T.C. - Adjuster Motor	MT18532
	1.8L 4Cyl L (109) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18532
	1.8L 4Cyl L (109) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18540
	1.8L 4Cyl L (109) A.T.C. - Air Inlet Recirculating - (Blower Housing) - (Vent Control)	MT18540
	1.8L 4Cyl L (109) A.T.C. - Defroster Door	MT18539
	1.8L 4Cyl L (109) A.T.C. - Temperature Blend Air Door	MT18538
	1.8L 4Cyl L (109) Manual A.C. - Adjuster Motor	MT18535
	2.8L 6Cyl V (2792) A.T.C. - Adjuster Motor	MT18535
GTI		
06	2.0L 4Cyl L (121) Manual A.C. - Adjuster Motor	MT18535
PASSAT, PASSAT CC		
05-01	1.8L 4Cyl L (1781) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18534
	1.8L 4Cyl L (1781) A.T.C. - Defroster Door	MT18533
	1.8L 4Cyl L (1781) Manual A.C. - Adjuster Motor	MT18535
05-04	2.0L 4Cyl L (120) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18534
	2.0L 4Cyl L (120) A.T.C. - Defroster Door	MT18533
	2.0L 4Cyl L (120) Manual A.C. - Adjuster Motor	MT18535
05-01	2.8L 6Cyl V (169) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18534
	2.8L 6Cyl V (169) A.T.C. - Defroster Door	MT18533
	2.8L 6Cyl V (169) Manual A.C. - Adjuster Motor	MT18535
	2.8L 6Cyl V (2771) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18534
	2.8L 6Cyl V (2771) A.T.C. - Defroster Door	MT18533
	2.8L 6Cyl V (2771) Manual A.C. - Adjuster Motor	MT18535
04-02	4.0L 8Cyl W (244) A.T.C. - Air Inlet Recirculating - (Blower Housing)	MT18534
	4.0L 8Cyl W (244) A.T.C. - Defroster Door	MT18533
	4.0L 8Cyl W (244) Manual A.C. - Adjuster Motor	MT18535
RABBIT		
06	2.5L 5Cyl L (151) Manual A.C. - Adjuster Motor	MT18535

ELECTRICAL ACTUATORS

<p>Height: GMP Width: 5 Depth: GM</p> <p>Buick 94-07 Cadillac 94-96 Cadillac 98-13 Chevrolet 94-14 GMC 94-14 Isuzu 03-08 Oldsmobile 94-04 Pontiac 00-05 Saab 05-09</p>  <p>MT1800</p>	<p>Height: GMP Width: 5 Depth: GM</p> <p>Buick 95-07 Cadillac 98-04 Chevrolet 02-09 GMC 02-09 Isuzu 03-08 Oldsmobile 95-99 Oldsmobile 01-04 Pontiac 00-05 Saab 05-09</p>  <p>MT1809</p>	<p>Height: CHR Width: 2 Depth: Chrysler</p> <p>Jeep 99-04</p>  <p>MT18502</p>
<p>Height: GMP Width: 4 Depth: GM</p> <p>Chevrolet 94-15 GMC 94-15 Oldsmobile 93-01 Pontiac 94-96</p>  <p>MT18503</p>	<p>Height: GMP Width: 5 Depth: GM</p> <p>Chevrolet 88-90 GMC 88-90</p>  <p>MT18505</p>	<p>Height: GMP Width: 2 Depth: GM</p> <p>Chevrolet 91-94 Ford 99-03 GMC 91-94</p>  <p>MT18507</p>
<p>Height: FD1B Width: 8 Depth: Ford</p> <p>Ford 02-10 Lincoln 03-08 Mercury 02-10</p>  <p>MT18508</p>	<p>Height: FD1B Width: 8 Depth: Ford</p> <p>Ford 02-10 Lincoln 03-06 Mercury 02-10</p>  <p>MT18509</p>	<p>Height: CH3 Width: 5 Depth: Ford</p> <p>Ford 02-08 Lincoln 06-08 Mercury 04-07</p>  <p>MT18510</p>
<p>Height: FD1B Width: 8 Depth: Ford</p> <p>Ford 97 Ford 99-07</p>  <p>MT18511</p>	<p>Height: GMP Width: 4 Depth: GMHD</p> <p>Buick 94-96 Oldsmobile 94-97</p>  <p>MT18512</p>	<p>Height: GMP Width: 5 Depth: GM</p> <p>Cadillac 96-02</p>  <p>MT18513</p>
<p>Height: GMP Width: 5 Depth: GM</p> <p>Buick 94-99 Oldsmobile 92-99 Pontiac 94-99</p>  <p>MT18514</p>	<p>Height: GMP Width: 5 Depth: GM</p> <p>Chevrolet 02-09 GMC 02-09 Isuzu 03-08 Oldsmobile 02-04 Saab 05-09</p>  <p>MT18515</p>	<p>Height: GMP Width: 5 Depth: GM</p> <p>Cadillac 02 Chevrolet 99-07 GMC 99-02</p>  <p>MT18516</p>

ELECTRICAL ACTUATORS

Height: GMP Width: 5 Depth: GM Cadillac 02-06 Chevrolet 00-06 GMC 01-06   MT18517	Height: CH4 Width: 5 Depth: FORD Ford 11-15   MT18518	Height: GMP Width: 3 Depth: GM Chevrolet 95-97 GMC 95-97   MT18519
Height: CH4 Width: 5 Depth: FORD Ford 11-15   MT18520	Height: GMP Width: 5 Depth: GM Buick 04-07 Chevrolet 02-09 GMC 02-09 Isuzu 03-08 Oldsmobile 02-04 Saab 05-09   MT18521	Height: GMP Width: 5 Depth: GM Buick 08-12 Chevrolet 08-12 Ford 10-12 GMC 07-12 Lincoln 11-12 Mercury 10-11 Pontiac 05-10 Saturn 07-10   MT18522
Height: GMP Width: 4 Depth: GM Chevrolet 96-15 GMC 96-15   MT18523	Height: GMP Width: 4 Depth: GM, Chrysler Buick 02-07 Chevrolet 97-15 GMC 03-15 Jeep 99-07 Oldsmobile 97-04 Pontiac 01-05   MT18524	Height: GMP Width: 4 Depth: GM Chevrolet 97-05 Oldsmobile 01-04 Pontiac 01-05   MT18525
Height: GMP Width: 2 Depth: GM/Ford Cadillac 00-05 Chevrolet 05 Ford 06-12 Lincoln 06 Saturn 02-07   MT18526	Height: GMP Width: 3 Depth: GM Buick 04-07 Cadillac 02-06 Chevrolet 97-09 GMC 99-09 Isuzu 03-08 Oldsmobile 01-04 Pontiac 01-05 Saab 05-09   MT18527	Height: GMP Width: 4 Depth: Chrysler Jeep 94-98   MT18528
Height: GMP Width: 4 Depth: GM Buick 02-07 Chevrolet 97-05 Oldsmobile 01-04 Pontiac 01-05   MT18529	Height: GMP Width: 4 Depth: GM Buick 00-05 Pontiac 00-05   MT18530	Height: GMP Width: 5 Depth: GM Buick 08-12 Chevrolet 09-12 GMC 07-12 Saturn 07-10   MT18531

ELECTRICAL ACTUATORS

<p>Height: VW1 Width: 5 Depth: VW</p> <p>Audi 03-08 Volkswagen 99-07</p>  <p>MT18532</p>	<p>Height: VW2 Width: 5 Depth: VW</p> <p>Audi 96-02 Volkswagen 01-05</p>  <p>MT18533</p>	<p>Height: VW2 Width: 5 Depth: VW</p> <p>Audi 97-02 Volkswagen 01-05</p>  <p>MT18534</p>
<p>Height: VW1 Width: 3 Depth: VW</p> <p>Volkswagen 98-10</p>  <p>MT18535</p>	<p>Height: VW3 Width: 5 Depth: VW</p> <p>Volkswagen 05</p>  <p>MT18536</p>	<p>Height: VW3 Width: 5 Depth: VW</p> <p>Volkswagen 05</p>  <p>MT18537</p>
<p>Height: VW2 Width: 5 Depth: VW</p> <p>Audi 01-08 Volkswagen 99-07</p>  <p>MT18538</p>	<p>Height: VW2 Width: 5 Depth: VW</p> <p>Audi 01-08 Volkswagen 99-07</p>  <p>MT18539</p>	<p>Height: VW2 Width: 5 Depth: VW</p> <p>Audi 01-08 Volkswagen 99-07</p>  <p>MT18540</p>
<p>Height: CH4 Width: 5 Depth: FORD</p> <p>Ford 08-11 GMC 11-13</p>  <p>MT18541</p>	<p>Height: DEN1L Width: 5 Depth: GM</p> <p>Chevrolet 11-15 Pontiac 08-09</p>  <p>MT18542</p>	<p>Height: DEN1S Width: 5 Depth: Toyota</p> <p>Lexus 04-09 Toyota 04-07</p>  <p>MT18543</p>
<p>Height: HY2A Width: 5 Depth: Hyundai</p> <p>Dodge 06-11 Hyundai 06-12</p>  <p>MT18544</p>	<p>Height: HY2B Width: 5 Depth: Hyundai</p> <p>Dodge 08-09 Hyundai 07-10</p>  <p>MT18545</p>	<p>Height: HY4 Width: 5 Depth: Hyundai</p> <p>Hyundai 01-08</p>  <p>MT18546</p>














ELECTRICAL ACTUATORS

Height: HY2A Width: 5 Depth: Hyundai Hyundai 06-12 Kia 03-10  MT18547	Height: HY4 Width: 5 Depth: Hyundai Hyundai 01-08  MT18548	Height: HY3 Width: 5 Depth: Hyundai Hyundai 10-13 Hyundai 15  MT18549
Height: CH3 Width: 5 Depth: Ford Ford 04-14 Lincoln 14 Mercury 08-11  MT18550	Height: FD3 Width: 5 Depth: Ford Ford 09-15 Lincoln 09-14  MT18551	Height: FD1A Width: 8 Depth: Ford Ford 97-16  MT18552
Height: FD1B Width: 8 Depth: Ford Ford 98-02 Mercury 98-01  MT18553	Height: FD1B Width: 8 Depth: Ford Ford 97-11 Lincoln 03-06 Mercury 02-10  MT18554	Height: FD1A Width: 8 Depth: Ford Ford 95-97 Lincoln 95-97 Mercury 95-97  MT18555
Height: FD1B Width: 8 Depth: Ford Ford 97-04  MT18556	Height: FD1A Width: 8 Depth: Ford Ford 97-07 Mercury 97-05  MT18557	Height: FD1A Width: 8 Depth: Ford Ford 97-10 Lincoln 03-05 Mercury 97-10  MT18558
Height: CH4 Width: 5 Depth: FORD Ford 11-15  MT18559	Height: FD2 Width: 6 Depth: Ford Lincoln 03-11  MT18560	Height: FD1A Width: 8 Depth: Ford Ford 91-94 Ford 98-11 Lincoln 91-94 Mercury 92-94 Mercury 98-11  MT18561

ELECTRICAL ACTUATORS

<p>Height: FD1B Width: 8 Depth: Ford</p> <p>Ford 98-04 Lincoln 00-03</p>  <p>MT18562</p>	<p>Height: FD1B Width: 8 Depth: Ford</p> <p>Ford 97 Mercury 97</p>  <p>MT18563</p>	<p>Height: FD2 Width: 6 Depth: Ford</p> <p>Lincoln 03-11</p>  <p>MT18564</p>
<p>Height: FD2 Width: 6 Depth: Ford</p> <p>Lincoln 98-02</p>  <p>MT18565</p>	<p>Height: FD2 Width: 6 Depth: Ford</p> <p>Ford 02-05 Lincoln 00-11</p>  <p>MT18567</p>	<p>Height: FD1A Width: 8 Depth: Ford</p> <p>Ford 93-96</p>  <p>MT18568</p>
<p>Height: CH3 Width: 5 Depth: Ford</p> <p>Ford 07-14 Lincoln 07-14 Mercury 08-11</p>  <p>MT18569</p>	<p>Height: CH3 Width: 5 Depth: Ford</p> <p>Ford 05-14 Lincoln 07-14 Mercury 05-09</p>  <p>MT18570</p>	<p>Height: FD3 Width: 5 Depth: Ford</p> <p>Ford 08-15 Lincoln 09-15 Mercury 08-09</p>  <p>MT18571</p>
<p>Height: DEN1L Width: 7 Depth: Ford</p> <p>Cadillac 03-05 Ford 07-15</p>  <p>MT18572</p>	<p>Height: DEN1L Width: 7 Depth: Ford</p> <p>Ford 07-15</p>  <p>MT18573</p>	<p>Height: FD2 Width: 6 Depth: Ford</p> <p>Ford 00-03</p>  <p>MT18574</p>
<p>Height: CH3 Width: 5 Depth: Ford</p> <p>Ford 10-14</p>  <p>MT18575</p>	<p>Height: FD2 Width: 6 Depth: Ford</p> <p>Ford 02-05 Lincoln 00-06</p>  <p>MT18576</p>	<p>Height: CH3 Width: 5 Depth: Ford</p> <p>Ford 05-09</p>  <p>MT18577</p>

ELECTRICAL ACTUATORS

Height: FD1B Width: 8 Depth: Ford Ford 05-07  MT18578	Height: FD1B Width: 8 Depth: Ford Ford 96-97 Ford 00-05 Lincoln 00-02 Mercury 96-97  MT18579	Height: CH3 Width: 5 Depth: Ford Ford 07-08 Lincoln 07-08  MT18580
Height: FD1B Width: 8 Depth: Ford Ford 03-05 Ford 09-14 Lincoln 03-06 Lincoln 09-14  MT18581	Height: CH3 Width: 5 Depth: Ford Ford 04-07 Mercury 04-07  MT18583	Height: FD1B Width: 8 Depth: Ford Ford 99-03  MT18584
Height: FD1B Width: 8 Depth: Ford Ford 97-01 Mercury 97-01  MT18585	Height: FD1B Width: 8 Depth: Ford Ford 91-95 Mercury 91-95  MT18586	Height: FD2 Width: 6 Depth: Ford Ford 02-05 Lincoln 00-06  MT18587
Height: FD1B Width: 8 Depth: Ford Ford 91-95 Mercury 91-95  MT18588	Height: CH4 Width: 2 Depth: FORD Ford 08-11  MT18589	Height: FD1B Width: 8 Depth: Ford Lincoln 97-98  MT18590
Height: FD1A Width: 8 Depth: Ford Ford 95-00 Mercury 95-02  MT18591	Height: FD2 Width: 6 Depth: Ford Ford 02-05 Lincoln 00-06  MT18592	Height: FD1A Width: 8 Depth: Ford Lincoln 95-97  MT18593

ELECTRICAL ACTUATORS

<p>Height: FD1A Width: 8 Depth: Ford</p> <p>Ford 91-11 Lincoln 91-97 Mercury 92-11</p>  <p>MT18594</p>	<p>Height: CH3 Width: 2 Depth: Chrysler, Ford, GM</p> <p>Buick 05-07 Chevrolet 05-09 Chrysler 05-15 Dodge 05-15 Ford 02-14 Jeep 07-15 Lincoln 06-14 Mercury 04-11 Pontiac 06-09 Ram 10-15</p>  <p>MT18595</p>	<p>Height: DEN1S Width: 3 Depth: GM</p> <p>Buick 06-11 Toyota 98-14</p>  <p>MT18596</p>
<p>Height: DEN1S Width: 5 Depth: GM</p> <p>Buick 06-11 Cadillac 06-11</p>  <p>MT18597</p>	<p>Height: DEN1S Width: 5 Depth: GM</p> <p>Buick 06-11 Cadillac 05-11</p>  <p>MT18598</p>	<p>Height: DEN1S Width: 5 Depth: GM</p> <p>Buick 06-11 Cadillac 06-11</p>  <p>MT18599</p>
<p>Height: DEN1L Width: 7 Depth: GM</p> <p>Cadillac 03-07</p>  <p>MT18600</p>	<p>Height: DEN1L Width: 7 Depth: GM</p> <p>Cadillac 03-09</p>  <p>MT18601</p>	<p>Height: DEN1L Width: 5 Depth: GM</p> <p>Cadillac 08-09</p>  <p>MT18602</p>
<p>Height: DEN1S Width: 5 Depth: GM</p> <p>Cadillac 08-14</p>  <p>MT18603</p>	<p>Height: DEN1S Width: 5 Depth: GM</p> <p>Cadillac 05-11</p>  <p>MT18604</p>	<p>Height: DEN1S Width: 5 Depth: GM</p> <p>Buick 06-11 Cadillac 05-14 Lexus 03-09 Toyota 03-14</p>  <p>MT18605</p>
<p>Height: DEN1S Width: 5 Depth: GM</p> <p>Cadillac 05-09</p>  <p>MT18606</p>	<p>Height: DEN1S Width: 5 Depth: GM</p> <p>Cadillac 05-11</p>  <p>MT18607</p>	<p>Height: DEN1S Width: 3 Depth: GM</p> <p>Pontiac 09-10 Toyota 04-15</p>  <p>MT18609</p>

ELECTRICAL ACTUATORS

Height: DEN1L Width: 5 Depth: GM Chevrolet 11-15 Pontiac 08-09  MT18610	Height: DEN1L Width: 5 Depth: GM Chevrolet 11-13 Pontiac 08-09  MT18611	Height: GMP Width: 5 Depth: GM Buick 04-07 Chevrolet 02-09 GMC 02-09 Isuzu 03-08 Oldsmobile 02-04 Saab 05-09  MT18612
Height: CH3 Width: 5 Depth: Chrysler Dodge 14-15 Jeep 14-15  MT18613	Height: GMP Width: 5 Depth: GM, Ford Buick 00-05 Cadillac 03-13 Chevrolet 03-14 Ford 06-09 GMC 03-14 Lincoln 06 Mercury 06-09 Pontiac 00-10  MT18614	Height: CH4 Width: 2 Depth: CHRYSLER Dodge 09-15  MT18616
Height: CH4 Width: 2 Depth: CHRYSLER Dodge 07-12 Jeep 08-13  MT18617	Height: CH4 Width: 2 Depth: CHRYSLER Jeep 05-10  MT18618	 MT18900
Dodge 03-10 Ram 10  MT18901		

CROSS REFERENCE

CROSS	OUR #	CROSS	OUR #	CROSS	OUR #	CROSS	OUR #
AC DELCO		CHRYSLER		DORMAN		DORMAN	
15-71845	MT18503	5012710AA	MT18502	604-200	MT18552	604-190	MT18542
15-72139	MT18505	5012728AA	MT18502	604-201	MT18553	604-902	MT18543
15-73020	MT18507	50127728AB	MT18502	604-202	MT18554	604-300	MT18544
15-71846	MT18512	5012750AA	MT18524	604-211	MT18554	604-304	MT18544
15-71923	MT18514	5013741AA	MT18524	604-222	MT18554	604-305	MT18544
15-73044	MT18515	5137781AA	MT18524	604-206	MT18557	604-306	MT18544
15-72505	MT18516	5170954AA	MT18524	604-207	MT18558	604-307	MT18544
15-72507	MT18517	5174382AA	MT18524	604-214	MT18561	604-311	MT18544
15-72106	MT18519	5061099AA	MT18595	604-216	MT18562	604-301	MT18545
15-73598	MT18521	680000494AA	MT18595	604-234	MT18571	604-302	MT18546
15-73822	MT18521	68000470AA	MT18595	604-253	MT18571	604-308	MT18547
15-71937	MT18522	68000495AA	MT18595	604-163	MT18572	604-310	MT18547
15-73514	MT18522	68013367AA	MT18595	604-237	MT18572	604-313	MT18547
15-73607	MT18522	68018095AA	MT18595	604-238	MT18572	604-303	MT18548
15-73666	MT18522	68018109AA	MT18595	604-272	MT18578	604-309	MT18549
15-72634	MT18524	6803337AA	MT18595	604-208	MT18594	604-224	MT18550
15-72649	MT18524	68037360AA	MT18595	604-004	MT18595	604-233	MT18550
15-73586	MT18524	68037360AB	MT18595	604-005	MT18595	604-909	MT18550
15-73627	MT18524	68048902AA	MT18595	604-021	MT18595	604-252	MT18551
15-72792	MT18525	68048902AB	MT18595	604-024	MT18595	604-212	MT18560
15-72506	MT18527	68079488AA	MT18595	604-029	MT18595	604-226	MT18560
15-72786	MT18527	68079488AB	MT18595	604-035	MT18595	604-217	MT18563
15-73599	MT18527	68089742AA	MT18595	604-038	MT18595	604-220	MT18564
15-72648	MT18529	68238243AA	MT18595	604-045	MT18595	604-221	MT18565
15-72646	MT18530	MT18595	MT18595	604-154	MT18595	604-223	MT18567
15-72792	MT18530	4720015	MT18528	604-232	MT18595	604-263	MT18567
15-72973	MT18530	68224192AA	MT18613	604-250	MT18595	604-264	MT18567
15-73043	MT18572	CROSS	OUR #	604-251	MT18595	604-225	MT18568
15-73062	MT18595	DODGE		604-262	MT18595	604-227	MT18569
15-73664	MT18596	97124-1E000	MT18544	604-276	MT18595	604-228	MT18569
15-80645	MT18597	CROSS	OUR #	604-282	MT18595	604-241	MT18569
15-73022	MT18598	DORMAN		604-148	MT18596	604-261	MT18569
15-73179	MT18598	604-001	MT18502	604-149	MT18597	604-270	MT18569
15-73816	MT18598	604-016	MT18502	601-168	MT18598	604-231	MT18570
15-73823	MT18598	604-044	MT18502	604-150	MT18598	604-274	MT18570
15-73826	MT18598	604-100	MT18503	604-155	MT18598	604-239	MT18573
15-80646	MT18598	604-102	MT18505	604-156	MT18598	604-240	MT18573
15-73180	MT18599	604-103	MT18507	604-17	MT18598	604-259	MT18574
15-72803	MT18600	604-213	MT18508	604-171	MT18598	604-260	MT18575
15-72790	MT18601	604-209	MT18509	604-151	MT18599	604-266	MT18576
15-73818	MT18602	604-218	MT18510	604-157	MT18600	604-267	MT18577
15-73848	MT18603	604-228	MT18510	604-158	MT18601	604-273	MT18579
15-73026	MT18605	604-203	MT18511	15-73818	MT18602	604-914	MT18579
15-73027	MT18605	604-5103	MT18512	604-160	MT18603	604-275	MT18580
15-73665	MT18605	604-123	MT18514	604-152	MT18605	604-277	MT18581
15-73209	MT18606	604-115	MT18515	604-162	MT18605	604-283	MT18583
15-73025	MT18607	604-113	MT18516	604-176	MT18605	604-287	MT18584
15-73181	MT18607	604-101	MT18517	604-164	MT18606	604-278	MT18585
15-73892	MT18609	604-116	MT18519	604-169	MT18607	604-908	MT18585
15-73596	MT18612	604-119	MT18521	604-175	MT18607	604-913	MT18586
15-72631	MT18614	604-186	MT18521	604-192	MT18609	604-912	MT18587
15-72645	MT18614	604-124	MT18522	604-110	MT18612	604-911	MT18588
15-73108	MT18614	604-135	MT18522	604-112	MT18614	604-915	MT18590
15-73435	MT18614	604-141	MT18522	604-121	MT18614	604-0918	MT18591
15-73597	MT18614	604-195	MT18522	604-126	MT18614	604-919	MT18592
15-73620	MT18614	604-229	MT18522	604-127	MT18614	604-916	MT18593
15-73643	MT18614	604-910	MT18522	604-133	MT18614	604-161	MT18604
15-73644	MT18614	604-020	MT18524	604-146	MT18614	604-189	MT18610
15-73952	MT18614	604-043	MT18524	604-170	MT18614	604-191	MT18611
15-72215	MT18513	604-046	MT18524	604-184	MT18614	CROSS	OUR #
15-72262	MT18523	604-107	MT18524	604-244	MT18614	FORD	
15-72654	MT18526	604-136	MT18524	604-128	MT18513	1L2Z-19E616-BA	MT18508
15-72971	MT1800	604-131	MT18525	604-125	MT18523	1L2Z-19E616-C	MT18509
15-72972	MT1809	604-120	MT18527	604-165	MT18526	9L3Z-19E616-E	MT18510
15-72974	MT18526	604-199	MT18527	604-166	MT18526	3C3Z-19E616-BA	MT18511
15-73606	MT18526	604-117	MT18529	604-196	MT18526	XF2Z-19E616-FB	MT18511
15-73989	MT18531	604-118	MT18530	604-230	MT18526	AE5Z-19E616-A	MT18522
15-73024	MT18604	604-147	MT18530	604-245	MT18526	AE5Z-19E616-C	MT18522
		604-850	MT18535	604-009	MT18528	8S4Z-19E616-B	MT18541
		604-258	MT18541	604-140	MT18531	6C2Z-19E616-A	MT18552

CROSS REFERENCE

CROSS	OUR #	CROSS	OUR #	CROSS	OUR #	CROSS	OUR #
FORD		FORD		GM		MOTORCRAFT	
F68Z-19E616-AA	MT18552	5F9Z-19E616-CA	MT18577	25815468	MT18602	YH-1743	MT18508
XC2Z-19E616-AA	MT18552	F4SZ-19E616-A	MT18579	25865637	MT18603	YH-1744	MT18509
F87Z-19E616-AA	MT18553	F6S-19E616-AA	MT18579	25770696	MT18605	YH-1752	MT18510
2L2Z-19E616-BA	MT18554	XL3Z-19E616-CA	MT18579	89023395	MT18605	YH-1748	MT18511
3L1Z-19E616-AB	MT18554	7L1Z-19E616-C	MT18580	89023397	MT18605	YH-1764	MT18511
F87Z-19E616-BA	MT18554	1L2Z-19E616-AA	MT18581	89024960	MT18606	YH-1855	MT18522
YL5Z-19E616-AA	MT18554	4F2Z-19E616-HA	MT18583	25770693	MT18607	YH-1887	MT18522
F6VZ-19E616-AA	MT18555	XF2Z-19E616-A	MT18584	89023391	MT18607	YH-1883	MT18541
2L3Z-19E616-BA	MT18556	2L1Z-19E616-BA	MT18585	19184663	MT18609	YH-1762	MT18552
XL3Z-19E616-BA	MT18556	F77Z-19E616-AB	MT18585	52402610	MT18612	YH-1761	MT18553
XF1Z-19E616-CA	MT18557	F2DZ-19E616-A	MT18586	89018675	MT18612	YH-1746	MT18554
F7DZ-19E616-BA	MT18558	F2DZ-19E616-B	MT18586	10393075	MT18614	YH-1749	MT18554
XW7Z-19E616-BA	MT18561	XW4Z-19E616-EA	MT18587	15798229	MT18614	YH-1767	MT18554
4L3Z-19E616-EA	MT18562	F3DZ-19E616-A	MT18588	15887320	MT18614	YH-1757	MT18555
XL3Z-19E616-AB	MT18562	F7LZ-19E616-AD	MT18590	15887322	MT18614	YH-1747	MT18556
8G1Z-19E616-C	MT18571	F8RZ-19E616-BA	MT18591	52492938	MT18614	YH-1763	MT18557
AA5Z-19E616-B	MT18571	XW4Z-19E616-DA	MT18592	52495593	MT18614	YH-1759	MT18558
AA5Z-19E616-C	MT18571	F7OZ-19E616-AA	MT18593	89018374	MT18614	YH-1766	MT18561
AL3Z-19E616-A	MT18571	CROSS	OUR #	89018376	MT18614	YH-1765	MT18562
DL3Z-19E616-A	MT18571	GM		89018677	MT18614	YH-1777	MT18571
EG1Z-19E616-C	MT18571	89018365	MT1800	89022572	MT18614	YH-1778	MT18571
7T4Z-19E616-A	MT18572	89018375	MT1809	89023358	MT18614	YH-1779	MT18571
7T4Z-19E616-D	MT18572	16124922	MT18503	16180230	MT18513	YH-1897	MT18571
3C7Z-19E616-AA	MT18578	89018356	MT18503	89018372	MT18523	YH-1933	MT18571
1W7Z-19E616-A	MT18594	16141802	MT18505	15788038	MT18526	YH-1875	MT18572
AW2Z-19E616-AA	MT18594	89018369	MT18505	52492937	MT18526	YH-1878	MT18572
AW7Z-19E616-A	MT18594	F16141802	MT18505	89018380	MT18526	YH-1860	MT18578
4F2Z-19E616-EA	MT18595	16149192	MT18507	89018381	MT18526	YH-1745	MT18594
6R3Z-19E616-A	MT18595	89018370	MT18507	20826182	MT18531	YH-1801	MT18595
7L1Z-19E616-E	MT18595	16124932	MT18512	92192013	MT18542	YH-1862	MT18595
8L8Z-19E616-A	MT18595	16141822	MT18514	89023390	MT18604	YH-1869	MT18595
8L8Z-19E616-D	MT18595	52408412	MT18515	92192011	MT18610	YH-1874	MT18595
9L3Z-19E616-C	MT18595	89018525	MT18515	92192012	MT18611	YH-1884	MT18595
9L3Z-19E616-F	MT18595	89018539	MT18515	CROSS	OUR #	YH-1893	MT18595
AR3Z-19E616-D	MT18595	52473356	MT18516	HYUNDAI		YH-1895	MT18595
AR3Z-19E616-E	MT18595	52474810	MT18517	97124-1E000	MT18544	YH-1868	MT18614
BE8Z-19E616-A	MT18595	16167292	MT18519	97125-2G000	MT18544	YH-1900	MT18614
CAR3Z-19E616-D	MT18595	89018367	MT18519	97154-1E000	MT18544	YH-1886	MT18526
6E5Z-19E616-B	MT18614	19130388	MT18521	97154-2H000	MT18544	YH-1899	MT18526
6E5Z-19E616-BA	MT18614	89018676	MT18521	97159-1H000	MT18544	YH-1750	MT18550
6E5Z-19E616-A	MT18526	15788055	MT18522	97159-2H000	MT18544	YH-1770	MT18550
6E5Z-19E616-AA	MT18526	15844209	MT18522	97159-2L000	MT18544	YH-1861	MT18550
AE5Z-19E616-B	MT18526	15920864	MT18522	97124-2H000	MT18545	YH-1870	MT18550
4L3Z-19E616-E	MT18550	16124952	MT18522	97154-2D000	MT18546	YH-1879	MT18551
4L3Z-19E616-EA	MT18550	89018368	MT18522	97154-2G000	MT18547	YH-1753	MT18560
6R3Z-19E616-B	MT18550	16177412	MT18524	97159-3K000	MT18547	YH-1756	MT18560
8L8Z-19E616-E	MT18550	89018395	MT18524	97160-3K000	MT18547	YH-1758	MT18563
AL8Z-19E616-F	MT18550	89018681	MT18524	97159-2D000	MT18548	YH-1755	MT18564
8A8Z-19E616-A	MT18551	89018960	MT18524	97162-1UAA0	MT18549	YH-1768	MT18565
3W1Z-19E616-AA	MT18560	10310747	MT18525	CROSS	OUR #	YH-1754	MT18567
9W1Z-19E616-A	MT18560	10317842	MT18527	HYUNDAI		YH-1849	MT18567
9W1Z-19E616-D	MT18560	52747495	MT18527	97124-1E000	MT18544	YH-1850	MT18567
F7Z-19E616-BA	MT18563	89018373	MT18527	97125-2G000	MT18544	YH-1760	MT18568
9W1Z-19E616-C	MT18564	89018678	MT18527	97154-1E000	MT18544	YH-1751	MT18569
YW1Z-19E616-BA	MT18565	10424940	MT18529	97154-2H000	MT18544	YH-1769	MT18569
9W1Z-19E616-B	MT18567	89018377	MT18530	97159-1H000	MT18544	YH-1881	MT18569
XW4Z-19E616-BA	MT18567	89018378	MT18530	97159-2H000	MT18544	YH-1890	MT18569
XW4Z-19E616-CA	MT18567	89023402	MT18572	97159-2L000	MT18544	YH-1892	MT18569
77UZ-19E616-AA	MT18568	10364929	MT18595	97124-2H000	MT18545	YH-1865	MT18570
8L8Z-19E616-C	MT18569	15787031	MT18596	97154-2D000	MT18546	YH-1872	MT18570
9C3Z-19E616-B	MT18569	25770689	MT18597	97154-2G000	MT18547	7T4Z-19E616-C	MT18573
AL8Z-19E616-A	MT18569	15939657	MT18598	97159-3K000	MT18547	YH-1876	MT18573
AR3Z-19E616-C	MT18569	19130240	MT18598	97160-3K000	MT18547	YH-1877	MT18573
ZZ5Z-19E616-A	MT18569	19130407	MT18598	97159-2D000	MT18548	YH-1891	MT18575
5F9Z-19E616-EA	MT18570	25770690	MT18598	97162-1UAA0	MT18549	YH-1855	MT18576
7L1Z-19E616-A	MT18570	25770692	MT18598	CROSS	OUR #	YH-1864	MT18577
7T4Z-19E616-B	MT18573	89023388	MT18598	MEI		YH-1840	MT18579
YS4Z-19E616-AA	MT18574	25770691	MT18599	2387	MT18505	YH-1848	MT18579
AR3Z-19E616-A	MT18575	25740395	MT18600			YH-1873	MT18580
YW4Z-19E616-AA	MT18576	25740409	MT18601			YH-1856	MT18581

CROSS REFERENCE

CROSS	OUR #	CROSS	OUR #	CROSS	OUR #
MOTORCRAFT		SMP		VOLKSWAGON	
YH-1863	MT18583	F04030	MT18614	8D1-820-511B	MT18533
YH-1846	MT18584	F04034	MT18614	8D1-820-511F	MT18533
YH-1841	MT18585	F04035	MT18614	8D1-820-511E	MT18534
YH-1858	MT18585	F04025	MT18513	8D1-820-511G	MT18534
YH-1838	MT18586	F04019	MT18523	8D2-820-511C	MT18539
YH-1852	MT18587	F04027	MT18526		
YH-1839	MT18588	F04038	MT18526		
YH-1842	MT18590	J04029	MT18526		
YH-1844	MT18591	G04012	MT18544		
YH-1851	MT18592	G04013	MT18544		
YH-1843	MT18593	G17001	MT18544		
CROSS		G17002	MT18544		
MURRAY		G17006	MT18544		
655-1966	MT1800	G04014	MT18545		
CROSS		G17004	MT18546		
SMP		G17003	MT18547		
J04002	MT18502	G17005	MT18548		
F04005	MT18503	G04004	MT18550		
F04001	MT18505	G04005	MT18550		
F04006	MT18507	G04008	MT18550		
J04003	MT18508	J04018	MT18550		
J04001	MT18509	J04054	MT18551		
G04003	MT18510	G04002	MT18560		
J04012	MT18511	I04002	MT18560		
J04004	MT18514	I04003	MT18563		
F04021	MT18515	G04007	MT18564		
F04020	MT18516	G04001	MT18565		
F04004	MT18517	G04006	MT18567		
F04011	MT18519	J04062	MT18567		
F04014	MT18521	J04073	MT18567		
F04036	MT18521	J04044	MT18568		
F04018	MT18522	G04009	MT18569		
F04028	MT18522	J04010	MT18569		
F04030	MT18522	J04025	MT18569		
F04037	MT18522	J04057	MT18569		
F04050	MT18522	J04051	MT18570		
F04023	MT18524	J04022	MT18573		
F04052	MT18524	J04023	MT18573		
F04028	MT18525	G04010	MT18575		
F04015	MT18527	J04064	MT18576		
F04039	MT18527	J04049	MT18577		
F04031	MT18530	J04035	MT18579		
J04026	MT18541	J04039	MT18579		
J04004	MT18552	J04052	MT18580		
J04001	MT18553	J04045	MT18581		
J04005	MT18554	J04079	MT18583		
J04011	MT18554	J04061	MT18584		
J04016	MT18554	J04010	MT18585		
J04014	MT18555	J04046	MT18585		
J04013	MT18556	J04037	MT18586		
J04007	MT18557	J04036	MT18587		
J04006	MT18558	J04033	MT18588		
J04008	MT18561	J04040	MT18590		
J04015	MT18562	CROSS		OUR #	
F04002	MT18571	TOYOTA			
J04054	MT18571	87106-02010	MT18596		
J04021	MT18572	87106-06120	MT18596		
J04024	MT18572	87106-42050	MT18596		
J04047	MT18578	87106-60170	MT18596		
J04009	MT18594	87106-48160	MT18609		
YH-1800	MT18594	87106-48100	MT18543		
J04042	MT18595	87106-48160	MT18543		
J04043	MT18595	CROSS		OUR #	
J04048	MT18595	VOLKSWAGON			
J04053	MT18595	1J0-907-511	MT18535		
J04058	MT18595	1J1-907-511E	MT18536		
F04012	MT18614	1J1-907-511F	MT18537		
F04016	MT18614	1J1-907-511C	MT18538		
F04017	MT18614	1J1-907-511D	MT18540		
F04029	MT18614	1J1-907-511A	MT18532		